

Internet Embedded MCU W7100A Datasheet

Version 1.1.6



© 2012 WIZnet Co., Inc. All Rights Reserved. For more information, visit our website at <u>http://www.wiznet.co.kr</u>.

© Copyright 2012 WIZnet Co., Inc. All rights reserved.

1

Table of Contents

1		Overv	/iew	11
	1.1	Introd	duction	11
	1.2	W710	0A Features	11
	1.3	W710	0A Block Diagram & Features	12
		1.3.1	ALU (Arithmetic Logic Unit)	12
		1.3.2	TCPIPCore	14
	1.4	Pin De	escription	16
		1.4.1	Pin Layout	16
		1.4.2	Pin Description	17
		1.4.2	2.1 Configuration	18
		1.4.2	2.2 Timer	19
		1.4.2	2.3 UART	19
		1.4.2	2.4 DoCD [™] Compatible Debugger	19
		1.4.2	2.5 Interrupt / Clock	19
		1.4.2	2.6 GPIO	20
		1.4.2	2.7 Media Interface	21
		1.4.2	2.8 Network Indicator LED	22
		1.4.2	2.9 Power Supply Signal	22
	1.5	64pin	package description	24
		1.5.1	Difference between 100 and 64pin package	24
2		Memo	pry	26
	2.1	Code	Memory	27
		2.1.1	Code Memory Wait States	29
	2.2	Data	Memory	29
		2.2.1	Data Memory Wait States	29
	2.3	Exter	nal Data Memory Access	30
		2.3.1	Standard 8051 Interface	30
		2.3.2	Direct Interface	31
	2.4	Interr	nal Data Memory and SFR	32
	2.5	SFR d	efinition	33
		2.5.1	Program Code Memory Write Enable Bit	33
		2.5.2	Program Code Memory Wait States Register	34
		2.5.3	Data Pointer Extended Registers	35
		2.5.4	Data Pointer Registers	
		2.5.5	Clock Control Register	37
		2.5.6	Internal Memory Wait States Register	37

		2.5.7	Address Latch Enable Register	38
		2.5.8	External Memory Wait States Register	39
		2.5.9	Stack Pointer	39
		2.5.10	New & Extended SFR	39
		2.5.11	Peripheral Registers	42
3		Interr	upt	44
4		1/0 Pc	orts	48
5		Timer	°S	51
	5.1	Timer	s 0, 1	51
		5.1.1	Overview	51
		5.1.2	Interrupts	52
		5.1.3	Timer0 - Mode0	53
		5.1.4	Timer0 - Mode1	54
		5.1.5	Timer0 - Mode2	54
		5.1.6	Timer0 - Mode3	55
		5.1.7	Timer1 - Mode0	56
		5.1.8	Timer1 - Mode1	56
		5.1.9	Timer1 - Mode2	57
		5.1.10	Timer1 - Mode3	57
	5.2	Timer	2	58
		5.2.1	Overview	58
		5.2.2	Interrupts	59
6		UART		62
	6.1	Interr	upts	63
	6.2	Mode	D, Synchronous	64
	6.3	Mode	1, 8-Bit UART, Variable Baud Rate, Timer 1 or 2 Clock Source	65
	6.4	Mode	2, 9-Bit UART, Fixed Baud Rate	65
	6.5	Mode	3, 9-Bit UART, Variable Baud Rate, Timer1 or 2 Clock Source	. 66
	6.6	Exam	ples of Baud Rate Setting	66
7		Watch	ndog Timer	67
	7.1	Overv	'iew	67
	7.2	Interr	upts	67
	7.3	Watch	ndog Timer Reset	68
	7.4	Simpl	e Timer	69
	7.5	Syster	m Monitor	69
	7.6	Watch	ndog Related Registers	69
	7.7	Watch	ndog Control	70
		7.7.1	Clock Control	71

	7.8	Time	d Access Registers	
8		TCPI	PCore	
	8.1	Memo	огу Мар	
	8.2	Regis	ters list	
	8	2.1	Common Registers	
	8	2.2	SOCKET Registers	
	8.3	Regis	ter Description	85
	8	.3.1	Mode Register	85
	8	.3.2	SOCKET Registers	91
9		Funct	tional Description	
	9.1	Initia	llization	
	9.2	Data	Communication	
	9	.2.1	ТСР	
		9.2.	1.1 TCP SERVER	
		9.2.	1.2 TCP CLIENT	
	9	.2.2	UDP	
		9.2.2	2.1 Unicast & Broadcast	
		9.2.2	2.2 Multicast	
	9	.2.3	IPRAW	
	9	2.4	MACRAW	100
	,	2.7		
10	,		rical Specification	
10	10.1	Elect		
10		Elect Absol	rical Specification	
10	10.1	Elect Absol DC Cl	rical Specification	
10	10.1 10.2	Elect Absol DC Cl Powe	rical Specification lute Maximum Ratings haracteristics	
10	10.1 10.2 10.3	Elect Absol DC Cl Powe AC Cl	rical Specification lute Maximum Ratings haracteristics er consumption(Driving voltage 3.3V)	
10	10.1 10.2 10.3 10.4	Elect Absol DC Cl Powe AC Cl Cryst	rical Specification lute Maximum Ratings haracteristics er consumption(Driving voltage 3.3V) haracteristics	
10	10.1 10.2 10.3 10.4 10.5	Elect Absol DC Cl Powe AC Cl Cryst Trans	rical Specification lute Maximum Ratings haracteristics er consumption(Driving voltage 3.3V) haracteristics cal Characteristics	
	10.1 10.2 10.3 10.4 10.5	Elect Absol DC Cl Powe AC Cl Cryst Trans IR Re	rical Specification lute Maximum Ratings haracteristics er consumption(Driving voltage 3.3V) haracteristics al Characteristics former Characteristics	
11	10.1 10.2 10.3 10.4 10.5	Elect Absol DC Cl Powe AC Cl Cryst Trans IR Re Packa	rical Specification lute Maximum Ratings haracteristics er consumption(Driving voltage 3.3V) haracteristics former Characteristics flow Temperature Profile (Lead-Free)	
11	10.1 10.2 10.3 10.4 10.5 10.6	Elect Absol DC Cl Powe AC Cl Cryst Trans IR Re Packa Packa	rical Specification lute Maximum Ratings haracteristics er consumption(Driving voltage 3.3V) haracteristics al Characteristics sformer Characteristics flow Temperature Profile (Lead-Free) age Descriptions	
11	10.1 10.2 10.3 10.4 10.5 10.6	Elect Absol DC Cl Powe AC Cl Cryst Trans IR Re Packa Packa	rical Specification lute Maximum Ratings haracteristics er consumption(Driving voltage 3.3V) haracteristics flow Temperature Profile (Lead-Free) age Descriptions age type: LQFP 100	
11 12	10.1 10.2 10.3 10.4 10.5 10.6	Elect Absol DC Cl Powe AC Cl Cryst Trans IR Re Packa Packa Appe	rical Specification lute Maximum Ratings haracteristics er consumption(Driving voltage 3.3V) haracteristics flow Temperature Profile (Lead-Free) age Descriptions age type: LQFP 100 age type: QFN 64	
11 12	10.1 10.2 10.3 10.4 10.5 10.6 12.1 12.2	Elect Absol DC Cl Powe AC Cl Cryst Trans IR Re Packa Packa Appe Sumn	rical Specification lute Maximum Ratings haracteristics er consumption(Driving voltage 3.3V) haracteristics flow Temperature Stroken Str	
11 12	 10.1 10.2 10.3 10.4 10.5 10.6 12.1 12.2 13.1 13.2 	Elect Absol DC Cl Powe AC Cl Cryst Trans IR Re Packa Packa Appe Sumn	rical Specification lute Maximum Ratings haracteristics er consumption(Driving voltage 3.3V)	
11 12	10.1 10.2 10.3 10.4 10.5 10.6 12.1 12.2 13.1 13.2	Elect Absol DC Cl Powe AC Cl Cryst Trans IR Re Packa Packa Packa Appe Sumn 8-Bit	rical Specification lute Maximum Ratings haracteristics er consumption(Driving voltage 3.3V)	
11 12	10.1 10.2 10.3 10.4 10.5 10.6 12.1 12.2 13.1 13.2 13.1	Elect Absol DC Cl Powe AC Cl Cryst Trans IR Re Packa Packa Packa Appe Sumn 8-Bit 3.2.1	rical Specification lute Maximum Ratings haracteristics er consumption(Driving voltage 3.3V)	



13.3 10	6-Bit Arithmetic Functions	
13.3.	.1 Addition	
13.3.	.2 Subtraction	
13.3.	.3 Multiplication	
13.4 32	2-bit Arithmetic Functions	
13.4.	.1 Addition	
13.4.	.2 Subtraction	
13.4.	.3 Multiplication	



List of Figures

Figure 1.1 W7100A Block Diagram 12
Figure 1.2 Accumulator A Register
Figure 1.3 B Register 13
Figure 1.4 Program Status Word Register
Figure 1.5 PSW Register 13
Figure 1.6 TCPIPCore Block Diagram 14
Figure 1.7 W7100A Pin Layout 16
Figure 1.8 W7100A QFN 64 Pin Layout 17
Figure 1.9 Power Design
Figure 2.1 Code / Data Memory Connections
Figure 2.2. Boot Sequence Flowchart
Figure 2.3 APP Entry Process
Figure 2.4 Changing the code memory Status at RB = '0'
Figure 2.5 Data Memory Map
Figure 2.6 Standard 8051 External Pin Access Mode (EM[2:0] = "001") 30
Figure 2.7 Standard 8051 External Pin Access Mode (EM[2:0] = "011") 31
Figure 2.8 Direct 8051 External Pin Access Mode (EM[2:0] = "101")
Figure 2.9 Direct 8051 External Pin Access Mode (EM[2:0] = "111")
Figure 2.10 Internal Memory Map 32
Figure 2.11 SFR Memory Map 33
Figure 2.13 PWE bit of PCON Register
Figure 2.14 Code memory Wait States Register
Figure 2.12 Waveform for code memory Synchronous Read Cycle with Minimal Wait States
(WTST = '4')
Figure 2.13 Waveform for code memory Synchronous Write Cycle with Minimal Wait
Figure 2.13 waverorm for code memory synchronous write cycle with minimal wait
States(WTST = '4')
States(WTST = '4') 35
States(WTST = '4')35Figure 2.17 Data Pointer Extended Register35
States(WTST = '4')35Figure 2.17 Data Pointer Extended Register35Figure 2.18 Data Pointer Extended Register35
States(WTST = '4')35Figure 2.17 Data Pointer Extended Register35Figure 2.18 Data Pointer Extended Register35Figure 2.19 MOVX @RI Extended Register35
States(WTST = '4')35Figure 2.17 Data Pointer Extended Register35Figure 2.18 Data Pointer Extended Register35Figure 2.19 MOVX @RI Extended Register35Figure 2.20 Data Pointer Register DPTR036
States(WTST = '4')35Figure 2.17 Data Pointer Extended Register35Figure 2.18 Data Pointer Extended Register35Figure 2.19 MOVX @RI Extended Register35Figure 2.20 Data Pointer Register DPTR036Figure 2.21 Data Pointer 1 Register DPTR136
States(WTST = '4')35Figure 2.17 Data Pointer Extended Register35Figure 2.18 Data Pointer Extended Register35Figure 2.19 MOVX @RI Extended Register35Figure 2.20 Data Pointer Register DPTR036Figure 2.21 Data Pointer 1 Register DPTR136Figure 2.22 Data Pointer Select Register36
States(WTST = '4')35Figure 2.17 Data Pointer Extended Register35Figure 2.18 Data Pointer Extended Register35Figure 2.19 MOVX @RI Extended Register35Figure 2.20 Data Pointer Register DPTR036Figure 2.21 Data Pointer 1 Register DPTR136Figure 2.22 Data Pointer Select Register36Figure 2.23 Clock Control Register - STRETCH bits37

Figure 2.27 Second Byte of Internal Memory Wait States Register	39
Figure 2.28 Stack Pointer Register	39
Figure 2.29 PHY Status Register	39
Figure 2.30 Internal PHY Configuration Register	40
Figure 2.31 W7100A Configuration Register	41
Figure 2.32 Core clock count register	41
Figure 2.33 Core clock count register	41
Figure 2.34 Core clock count register	41
Figure 2.35 Core clock count register	42
Figure 3.1 Interrupt Enable Register	45
Figure 3.2 Interrupt Priority Register	45
Figure 3.3 Timer0, 1 Configuration Register	45
Figure 3.4 UART Configuration Register	46
Figure 3.5 Extended Interrupt Enable Register	46
Figure 3.6 Extended Interrupt Priority Register	46
Figure 3.7 Extended Interrupt Flag Register	47
Figure 3.8 Watchdog Control Register	47
Figure 4.1 Port0 Register	48
Figure 4.2 Port1 Register	48
Figure 4.3 Port2 Register	48
Figure 4.4 Port3 Register	48
Figure 4.5 Port0 Pull-down register	49
Figure 4.6 Port1 Pull-down register	49
Figure 4.7 Port2 Pull-down register	49
Figure 4.8 Port3 Pull-down register	50
Figure 4.9 Port0 Pull-up register	50
Figure 4.10 Port1 Pull-up register	50
Figure 4.11 Port2 Pull-up register	50
Figure 4.12 Port3 Pull-up register	50
Figure 5.1 Timer0, 1 Control Mode Register	52
Figure 5.2 Timer0, 1 Configuration Register	52
Figure 5.3 Interrupt Enable Register	52
Figure 5.4 Interrupt Priority Register	53
Figure 5.5 Timer0, 1 Configuration Register	53
Figure 5.6 Timer Counter0, Mode0: 13-Bit Timer/Counter	54
Figure 5.7 Timer/Counter0, Mode1: 16-Bit Timer/Counter	54
Figure 5.8 Timer/Counter0, Mode2: 8-Bit Timer/Counter with Auto-Reload	55
Figure 5.9 Timer/Counter0, Mode3: Two 8-Bit Timers/Counters	55

7

Figure 5.10 Timer/Counter1, Mode0: 13-Bit Timer/Counter	56
Figure 5.11 Timer/Counter1, Mode1: 16-Bit Timers/Counters	56
Figure 5.12 Timer/Counter1, Mode2: 8-Bit Timer/Counter with Auto-Reload	57
Figure 5.13 Timer2 Configuration Register	58
Figure 5.14 Timer/Counter2, 16-Bit Timer/Counter with Auto-Reload	5 9
Figure 5.15 Interrupt Enable Register – Timer2	59
Figure 5.16 Interrupt Priority Register – Timer2	60
Figure 5.17 Timer2 Configuration Register – TF2	60
Figure 5.18 Timer/Counter2, 16-Bit Timer/Counter with Capture Mode	60
Figure 5.19 Timer2 for Baud Rate Generator Mode	61
Figure 6.1 UART Buffer Register	62
Figure 6.2 UART Configuration Register	62
Figure 6.3 UART Bits in Power Configuration Register	63
Figure 6.4 UART Bits in Interrupt Enable Register	64
Figure 6.5 UART Bits in Interrupt Priority Register	64
Figure 6.6 UART Configuration Register	64
Figure 6.7 Timing Diagram for UART Transmission Mode0 (clk = 88.4736 MHz)	65
Figure 6.8 Timing Diagram for UART Transmission Mode1	65
Figure 6.9 Timing Diagram for UART Transmission Mode2	65
Figure 6.10 Timing Diagram for UART Transmission Mode3	66
Figure 6.10 Timing Diagram for UART Transmission Mode3 6 Figure 7.1 Watchdog Timer Structure 6	
	67
Figure 7.1 Watchdog Timer Structure	67 67
Figure 7.1 Watchdog Timer Structure	67 67 67
Figure 7.1 Watchdog Timer Structure 6 Figure 7.2 Interrupt Enable Register 6 Figure 7.3 Extended Interrupt Enable Register 6	67 67 67 68
Figure 7.1 Watchdog Timer Structure 6 Figure 7.2 Interrupt Enable Register 6 Figure 7.3 Extended Interrupt Enable Register 6 Figure 7.4 Extended interrupt Priority Register 6	67 67 67 68 68
Figure 7.1 Watchdog Timer Structure 6 Figure 7.2 Interrupt Enable Register 6 Figure 7.3 Extended Interrupt Enable Register 6 Figure 7.4 Extended interrupt Priority Register 6 Figure 7.5 Watchdog Control Register 6	67 67 68 68 70
Figure 7.1 Watchdog Timer Structure 6 Figure 7.2 Interrupt Enable Register 6 Figure 7.3 Extended Interrupt Enable Register 6 Figure 7.4 Extended interrupt Priority Register 6 Figure 7.5 Watchdog Control Register 6 Figure 7.6 Watchdog Control Register 6	67 67 68 68 70 71
Figure 7.1 Watchdog Timer StructureFigure 7.2 Interrupt Enable RegisterFigure 7.3 Extended Interrupt Enable RegisterFigure 7.4 Extended interrupt Priority RegisterFigure 7.5 Watchdog Control RegisterFigure 7.6 Watchdog Control RegisterFigure 7.7 Clock Control register - Watchdog bits	67 67 68 68 70 71 72
Figure 7.1 Watchdog Timer Structure6Figure 7.2 Interrupt Enable Register6Figure 7.3 Extended Interrupt Enable Register6Figure 7.4 Extended interrupt Priority Register6Figure 7.5 Watchdog Control Register6Figure 7.6 Watchdog Control Register7Figure 7.7 Clock Control register - Watchdog bits7Figure 8.1 TCPIPCore Memory Map7	67 67 68 68 70 71 72 99
Figure 7.1 Watchdog Timer Structure6Figure 7.2 Interrupt Enable Register6Figure 7.3 Extended Interrupt Enable Register6Figure 7.4 Extended interrupt Priority Register6Figure 7.5 Watchdog Control Register6Figure 7.6 Watchdog Control Register6Figure 7.7 Clock Control register - Watchdog bits7Figure 8.1 TCPIPCore Memory Map6Figure 8.2 SOCKET n Status transition6	67 67 68 68 70 71 72 99 06
Figure 7.1 Watchdog Timer Structure6Figure 7.2 Interrupt Enable Register6Figure 7.3 Extended Interrupt Enable Register6Figure 7.4 Extended interrupt Priority Register6Figure 7.5 Watchdog Control Register6Figure 7.6 Watchdog Control Register6Figure 7.7 Clock Control register - Watchdog bits7Figure 8.1 TCPIPCore Memory Map6Figure 8.2 SOCKET <i>n</i> Status transition6Figure 8.3 Calculate Physical Address10	67 67 68 68 70 71 72 99 06 13
Figure 7.1 Watchdog Timer Structure 6 Figure 7.2 Interrupt Enable Register 6 Figure 7.3 Extended Interrupt Enable Register 6 Figure 7.4 Extended interrupt Priority Register 6 Figure 7.5 Watchdog Control Register 6 Figure 7.6 Watchdog Control Register 6 Figure 7.7 Clock Control register - Watchdog bits 6 Figure 8.1 TCPIPCore Memory Map 6 Figure 8.2 SOCKET <i>n</i> Status transition 6 Figure 9.1 Allocation Internal TX/RX memory of SOCKET <i>n</i> 1	67 67 68 68 70 71 72 99 06 13 14
Figure 7.1 Watchdog Timer Structure6Figure 7.2 Interrupt Enable Register6Figure 7.3 Extended Interrupt Enable Register6Figure 7.4 Extended interrupt Priority Register6Figure 7.5 Watchdog Control Register6Figure 7.6 Watchdog Control Register6Figure 7.7 Clock Control register - Watchdog bits6Figure 8.1 TCPIPCore Memory Map6Figure 8.2 SOCKET n Status transition6Figure 8.3 Calculate Physical Address10Figure 9.1 Allocation Internal TX/RX memory of SOCKET n11Figure 9.2 TCP SERVER & TCP CLIENT11	 67 67 68 68 70 71 72 99 06 13 14 15
Figure 7.1 Watchdog Timer Structure 6 Figure 7.2 Interrupt Enable Register 6 Figure 7.3 Extended Interrupt Enable Register 6 Figure 7.4 Extended interrupt Priority Register 6 Figure 7.5 Watchdog Control Register 6 Figure 7.6 Watchdog Control Register 6 Figure 7.7 Clock Control register - Watchdog bits 7 Figure 8.1 TCPIPCore Memory Map 7 Figure 8.2 SOCKET <i>n</i> Status transition 6 Figure 9.1 Allocation Internal TX/RX memory of SOCKET <i>n</i> 17 Figure 9.3 "TCP SERVER & TCP CLIENT 17 Figure 9.3 "TCP SERVER" Operation Flow 17	67 67 68 68 70 71 72 99 06 13 14 15 22
Figure 7.1 Watchdog Timer Structure 6 Figure 7.2 Interrupt Enable Register 6 Figure 7.3 Extended Interrupt Enable Register 6 Figure 7.4 Extended interrupt Priority Register 6 Figure 7.5 Watchdog Control Register 6 Figure 7.6 Watchdog Control Register 6 Figure 7.7 Clock Control register - Watchdog bits 7 Figure 8.1 TCPIPCore Memory Map 7 Figure 8.2 SOCKET <i>n</i> Status transition 6 Figure 9.1 Allocation Internal TX/RX memory of SOCKET <i>n</i> 1 Figure 9.3 "TCP SERVER & TCP CLIENT 1 Figure 9.4 "TCP CLIENT" Operation Flow 1	 67 67 68 68 70 71 72 99 06 13 14 15 22 23
Figure 7.1 Watchdog Timer Structure 6 Figure 7.2 Interrupt Enable Register 6 Figure 7.3 Extended Interrupt Enable Register 6 Figure 7.4 Extended interrupt Priority Register 6 Figure 7.5 Watchdog Control Register 6 Figure 7.6 Watchdog Control Register 6 Figure 7.7 Clock Control register - Watchdog bits 6 Figure 8.1 TCPIPCore Memory Map 7 Figure 8.2 SOCKET n Status transition 6 Figure 9.1 Allocation Internal TX/RX memory of SOCKET n 1 Figure 9.3 "TCP SERVER & TCP CLIENT 1 Figure 9.4 "TCP CLIENT" Operation Flow 1 Figure 9.5 UDP Operation Flow 1	 67 67 68 68 70 71 72 99 06 13 14 15 22 23 25

8



Figure 9.9 MACRAW Operation Flow	134
Figure 9.10 The received MACRAW data format	135



List of Tables

1 Overview

1.1 Introduction

iMCU W7100A is the one-chip solution which integrates an 8051 compatible microcontroller, 64KB SRAM and hardwired TCP/IP Core for high performance and easy development.

The TCP/IP core is a market-proven hardwired TCP/IP stack with an integrated Ethernet MAC & PHY. The Hardwired TCP/IP stack supports the TCP, UDP, IPv4, ICMP, ARP, IGMP and PPPoE which has been used in various applications for years.

1.2 W7100A Features

- · Fully software compatible with industrial standard 8051
- Pipelined architecture which enables execution of instructions 4~5 times faster than a standard 8051
- 10BaseT/100BaseTX Ethernet PHY embedded
- · Power down mode supported for saving power consumption
- Hardwired TCP/IP Protocols: TCP, UDP, ICMP, IPv4 ARP, IGMP, PPPoE, Ethernet
- Auto Negotiation (Full-duplex and half duplex), Auto MDI/MDIX
- · ADSL connection with PPPoE Protocol with PAP/CHAP Authentication mode support
- · 8 independent sockets which are running simultaneously
- 32Kbytes Data buffer for the Network
- Network status LED outputs (TX, RX, Full/Half duplex, Collision, Link, and Speed)
- Not supports IP fragmentation
- · 2 Data Pointers (DPTRs) for fast memory blocks processing
- Advanced INC & DEC modes
- Auto-switch of current DPTR
- 64KBytes Data Memory (RAM)
- · 255Bytes data FLASH, 64KBytes Code Memory, 2KBytes Boot Code Memory
- · Up to 16M bytes of external (off-chip) data memory
- Interrupt controller
 - 2 priority levels
 - 4 external interrupt sources
- 1 Watchdog interrupt
- Four 8-bit I/O Ports
- Three timers/counters
- Full-duplex UART
- Programmable Watchdog Timer
- DoCD[™] compatible debugger
- High Product Endurance
 - Minimum 100,000 program/erase cycles
 - Minimum 10 years data retention










Figure 1.1 W7100A Block Diagram

The W7100A internal block diagram is shown in the Figure 1.1. Details of block functions are described as follows:

ALU - Performs arithmetic and logic operations during execution of an instruction. It contains accumulator (ACC), Program Status Word (PSW), B registers, and related logics such as arithmetic unit, logic unit, multiplier, and divider.

SFR - Controls the access of special registers. It contains standard and user defined registers and related logic. User defined external devices can be quickly accessed (read, write, modified) using all direct addressing mode instructions.

1.3.1 ALU (Arithmetic Logic Unit)

W7100A is fully compatible with the standard 8051 microcontroller, and maintains all instruction mnemonics and binary compatibility. W7100A incorporates many great architectural enhancements which enable the W7100A MCU to execute instructions with high speed.

The ALU of W7100A MCU performs extensive data manipulation and is comprised of the 8-bit arithmetic logic unit (ALU), an ACC (0xE0) register, a B (0xF0) register and a PSW (0xD0) register



ACC (0xE0)										
7	6	5	4	3	2	1	0	Reset		
ACC.7	ACC.6	ACC.5	ACC.4	ACC.3	ACC.2	ACC.1	ACC.0	0x00		
		Fig	jure 1.2 A	ccumulato	or A Regis	ter				

The B register is used during multiplication and division operations. In other cases, this register is used as normal SFR.

B (0xF0)									
7	6	5	4	3	2	1	0	Reset	
B.7	B.6	B.5	B.4	B.3	B.2	B.1	B.0	0x00	
			Figure	e 1.3 B R	egister				

The ALU performs arithmetic operations such as addition, subtraction, multiplication, and division, and other operations such as increment, decrement, BCD-decimal-add-adjust, and compare. Logic unit uses AND, OR, Exclusive OR, complement, and rotation to perform different operations. The Boolean processor performs bit operations such as set, clear, complement, jump-if-not-set, jump-if-set-and-clear, and move to/from carry.

	PSW (0xD0)										
7 6 5 4 3 2 1 0 Reset											
СҮ	AC	F0	RS1	RS0	OV	F1	Р	0x00			

Figure	14	Program	Status	Word	Register
riguic	1.7	riogram	Julus	word	Register

СҮ	Carry flag					
AC	Auxiliary carry					
FO	General purpose flag 0					
	Register bank select bits					
	RS[1:0] Function Description					
DC[1,0]	00 -Bank 0, data address 0x00 - 0x07					
RS[1:0]	01 -Bank 1, data address 0x08 - 0x0F					
	10 -Bank 2, data address 0x10 - 0x17					
	11 -Bank 3, data address 0x18 - 0x1F					
OV	Overflow flag					
F1	General purpose flag 1					
Р	Parity flag					

Figure 1.5 PSW Register

The PSW register contains several bits that can reflect the current state of MCU.



1.3.2 TCPIPCore




Figure 1.6 TCPIPCore Block Diagram

Ethernet PHY

The W7100A includes 10BaseT/100BaseTX Ethernet PHY. It supports half-duplex/full-duplex, auto-negotiation and auto-MDI/MDIX. It also supports 6 network indicator LED outputs such as Link, TX, RX status, Collision, speed and duplex.

TCPIP Engine

TCPIP Engine is a hardwired logic based network protocol which contains technology of WIZnet.

- 802.3 Ethernet MAC(Media Access Control)

This controls Ethernet access of CSMA/CD(\underline{C} arrier \underline{S} ense \underline{M} ultiple \underline{A} ccess with \underline{C} ollision \underline{D} etect). The protocol is based on a 48-bit source/destination MAC address.

PPPoE(Point-To-Point Protocol over Ethernet)

This protocol uses PPP service over Ethernet. The payload (PPP frame) is encapsulated inside an Ethernet frame during a transmission. When receiving, it de-capsulates the PPP frame. PPPoE supports PPP communication with PPPoE server and PAP/CHAP authentications.

- ARP(Address Resolution Protocol)

ARP is the MAC address resolution protocol by using IP address. This protocol exchanges ARP-reply and ARP-request from peers to determine the MAC address of each other



IP (Internet Protocol)

This protocol operates in the IP layer and provides data communication. IP fragmentation is not supported. It is not possible to receive the fragmented packets. All protocol number is supported except for TCP or UDP. In case of TCP or UDP, use the hardwired embedded TCPIP stack.

- ICMP(Internet Control Message Protocol)

ICMP is a protocol which provides information, unreachable destination. When a Pingrequest ICMP packet is received, a Ping-reply ICMP packet is sent.

- IGMPv1/v2(Internet Group Management Protocol version 1/2)

This protocol processes IGMP messages such as the IGMP Join/Leave. The IGMP is only enabled in UDP multicast mode. Only version 1 and 2 of IGMP logic is supported. When using a newer version of IGMP, IGMP should be manually implemented in the IP layer.

- UDP(User Datagram Protocol)

It is a protocol which supports data communication at the UDP layer. User datagram such as unicast, multicast, and broadcast are supported

- TCP(Transmission Control Protocol)

This protocol operates in the TCP layer and provides data communication. Both TCP server and client modes are supported.



- 1.4 Pin Description
- 1.4.1 Pin Layout

Package type: LQFP 100




Figure 1.7 W7100A Pin Layout

16



Package type: QFN 64




Figure 1.8 W7100A QFN 64 Pin Layout

1.4.2 Pin Description

The pin functionalities are described in the following table. There are no tri-state output pins and internal signals.

Туре	Description
I	Input
0	Output with 8mA driving current
10	Input/Output (Bidirectional)
Pu	Internal pulled-up with 4.7K Ω resistor
Pd	Internal pulled-down with $85K\Omega$ resistor



1.4.2.1 Configuration

Pin name	Pin nu	mber	1/0	Pu/Pd	Desc	cript	ion	
	100pin	64pin						
nRST	8	9	Ι	-	Global asynchronous reset, Active low			
TM3-0	1,2,	2,3,	Ι	Pd	Mus	t be	cor	nected to GND; value '0000'
	3,4	4,5						
PM2 - 0	70,	-	Ι	Pd	PHY	Мос	de	
	71,					PM		
	72				2	1	0	Description
								Normal Operation Mode
					0	0	0	Auto-negotiation enabled with all
								functionalities
					0	0	1	Auto-negotiation with 100 BASE-TX
								FDX/HDX ability
					0	1	0	Auto-negotiation with 10 BASE-T
						-	-	FDX/HDX ability
					0	1	1	Reserved
					1	0	0	Manual selection of 100 BASE-TX FDX
					1	0	1	Manual selection of 100 BASE-TX HDX
					1	1	0	Manual selection of 10 BASE-T FDX
					1	1	1	Manual selection of 10 BASE-T HDX
					FDX	: Fu	III-D	ouplex, HDX : Half-Duplex
BOOTEN	5	6	Ι	Pd	Boo	t Ena	able	e/Disable
					0 – E	Enab	le l	Jser Application mode
					Ju	mp	to (0x0000, the start address of user Code
					FLAS			
								oot mode
								ode in Boot ROM
PLOCK	77	51	0	-			k I	ine, It notifies when internal PLL is
					lock	ed		



1.4.2.2 Timer

Pin name	Pin number		I/0	Pu/Pd	Description
	100pin	64pin			
Timer0, 1	Interface				
Т0	9	-	Ι	-	Timer0 external clock input
T1	10	-	Ι	-	Timer1 external clock input
GATE0	11	-	Ι	-	Timer0 gate control
GATE1	12	-	Ι	-	Timer1 gate control
Timer2 Int	erface				
Т2	13	-	Ι	-	Timer2 external clock input
T2EX	14	-	Ι	-	Timer2 Capture/Reload trigger

1.4.2.3 UART

Pin name	Pin number		I/0	Pu/Pd	Description
	100pin	64pin			
RXD	15	10	Ι	-	Serial receiver
TXD	17	12	0	-	Serial transmitter

1.4.2.4 DoCD[™] Compatible Debugger

Pin name	Pin number		I/0	Pu/Pd	Description
	100pin	64pin			
DCDCLK	18	13	0	-	DoCD clock
DCDDI	19	14	Ι	-	DoCD data input
DCDDO	20	15	0		DoCD data output

1.4.2.5 Interrupt / Clock

Pin name	Pin number		1/0	Pu/Pd	Description
	100pin	64pin			
nINT0	22	17	I	-	External interrupt0
nINT1	23	-	I	-	External interrupt1
nINT2	24	-	I	-	External interrupt2
nINT3	25	-	Ι	-	External interrupt3
XTLNO	61	40	0	-	Crystal output for WIZnet Core, A parallel- resonant 25MHz crystal or ceramic is connected. If use oscillator, this pin can be floated.
XTLP0	62	41	I	-	Crystal input for WIZnet Core, A parallel-



					resonant 25MHz crystal or ceramic is connected. If use oscillator, this pin connected with 1.8V output of OSC.
XTLN1	67	45	0	-	Crystal output for MCU core, A parallel-resonant 11.0592MHz crystal or ceramic is connected. If oscillator is uesd, this pin can be floated.
XTLP1	66	44	I	-	Crystal input for MCU core, A parallel-resonant 11.0592MHz crystal or ceramic is connected. If oscillator is used, this pin is connected with 1.8V output of OSC.

1.4.2.6 GPIO

Pin name	Pin number		I/0	Pu/Pd	Description
	100pin	64pin			
P0.0	81	52	10	-	Port0 input/output, Ext Memory Data0, Addr0
P0.1	82	53	10	-	Port0 input/output, Ext Memory Data1, Addr1
P0.2	84	55	10	-	Port0 input/output, Ext Memory Data2, Addr2
P0.3	85	56	10	-	Port0 input/output, Ext Memory Data3, Addr3
P0.4	86	57	10	-	Port0 input/output, Ext Memory Data4, Addr4
P0.5	87	59	10	-	Port0 input/output, Ext Memory Data5, Addr5
P0.6	89	60	10	-	Port0 input/output, Ext Memory Data6, Addr6
P0.7	90	61	10	-	Port0 input/output, Ext Memory Data7, Addr7
P1.0	26	18	10	-	Port1 input/output, Ext Memory Addr0
P1.1	27	19	10	-	Port1 input/output, Ext Memory Addr1
P1.2	28	20	10	-	Port1 input/output, Ext Memory Addr2
P1.3	29	21	10	-	Port1 input/output, Ext Memory Addr3
P1.4	30	22	10	-	Port1 input/output, Ext Memory Addr4
P1.5	31	23	10	-	Port1 input/output, Ext Memory Addr5
P1.6	32	24	10	-	Port1 input/output, Ext Memory Addr6
P1.7	33	25	10	-	Port1 input/output, Ext Memory Addr7
P2.0	91	62	10	-	Port2 input/output, Ext Memory Addr8
P2.1	93	64	10	-	Port2 input/output, Ext Memory Addr9
P2.2	94	1	10	-	Port2 input/output, Ext Memory Addr10
P2.3	95	-	10	-	Port2 input/output, Ext Memory Addr11
P2.4	96	-	10	-	Port2 input/output, Ext Memory Addr12
P2.5	97	-	10	-	Port2 input/output, Ext Memory Addr13
P2.6	98	-	10	-	Port2 input/output, Ext Memory Addr14



P2.7	99	-	10	-	Port2 input/output, Ext Memory Addr15
P3.0	34	-	10	-	Port3 input/output, Ext Memory Addr16
P3.1	35	-	10	-	Port3 input/output, Ext Memory Addr17
P3.2	37	-	10	-	Port3 input/output, Ext Memory Addr18
P3.3	39	-	10	-	Port3 input/output, Ext Memory Addr19
P3.4	40	-	10	-	Port3 input/output, Ext Memory Addr20
P3.5	41	-	10	-	Port3 input/output, Ext Memory Addr21
P3.6	42	-	10	-	Port3 input/output, Ext Memory Addr22
P3.7	43	-	10	-	Port3 input/output, Ext Memory Addr23

Note: User can control the GPIO I/O driving voltage using PxPU/PxPD SFR.

Note: In that case, GPIO0~3 is used to transfer External memory address and data. Please refer to the '2.3 External Data Memory Access'

1.4.2.7 External Memory Interface

Pin name	Num	I/О Туре	Description
ALE	78	0	Data memory address bus [7:0] latch enable
nWR	79	OL	External data memory write
nRD	80	OL	External data memory read

Note: When user using External memory by standard 8051 interface, P0[7:0] can transfer Data[7:0] or Address[7:0] by ALE pin control.

Pin name	Pin number		I/O Pu/Pd		Description
	100pin	64pin			
TXON	52	32	0	-	TXON/TXOP Signal Pair, The differential data is
ТХОР	53	33	0	-	transmitted to the media on the TXON/TXOP
					signal pair
RXIN	55	35	I	-	RXIN/RXIP Signal Pair, The differential data from
RXIP	56	36	I	-	the media is received on the RXIN/RXIP Signal
					pair
RESETBG	59	38	I	-	PHY Off-chip resistor, Connect a resistor of 12.3
					$\mathrm{k}\Omega\pm1\%$ to the ground. Refer to the "Reference
					schematic"

1.4.2.8 Media Interface

For the best performance,

- 1. Make the length of RXIP / RXIN signal pair (RX) same if possible.
- 2. Make the length of TXOP / TXON signal pair (TX) same if possible.
- 3. Locate the RXIP and RXIN signal as near as possible.



- 4. Locate the TXOP and TXON signal as near as possible.
- 5. Locate the RX and TX signal pairs far from noisy signals such as bias resistor or crystal.
- 6. Keep regular between TX/RX signal pair.

For more details, refer to "W5100 Layout Guide.pdf."

Pin name	Pin nu	mber	1/0	Pu/Pd	Description	
	100pin	64pin				
SPDLED	45	27	0	-	Link speed LED	
					Low: 100Mbps	
					High: 10Mbps	
FDXLED	46	-	0	-	Full duplex LED	
					Low: Full-duplex	
					High: Half-duplex	
COLLED	47	-	0	-	Collision LED	
					Low: Collision detected (only half-duplex)	
RXLED	48	-	0	-	Receive activity LED	
					Low: Receive signal detected on RXIP/RXIN	
TXLED	49	-	0	-	Transmit activity LED	
					Low: Transmit signal detected on TXOP/TXON	
LINKLED	50	28	0	-	Link LED	
					Low: Link (10/100M) is detected	

1.4.2.9 Network Indicator LED

1.4.2.10 Power Supply Signal

Pin	Pin number I/C		1/0	Pu/	Description	
name	100pin	64pin		Pd		
VCC3A3	58, 75	37, 49	Power	-	Analog 3.3V power supply	
					Be sure to connect a 10uF tantalum capacitor	
					between VCC3A3 and GNDA in order to preven	
					power compensation	
VCC3V3	21,	16, 58	Power	-	Digital 3.3V power supply	
	38,				A 0.1uF decoupling capacitor should be connected	
	73,				between each pair of VCC and GND. A 1uH ferrite	
	87,				bead should be used to separate the VCC3V3 and	
	100				VCC3A3	
VCC1A8	54,	34, 42	Power	-	Analog 1.8V power supply	



			1		
	60,				A 10uF tantalum capacitor and a 0.1uF capacitor
	64				should be connected between VCC1A8 and GNDA
					to filter out core power noise
VCC1V8	16,	39,	Power	-	Digital 1.8V power supply
	44,	46,			Between each pair of VCC and GND, a 0.1uF
	68, 83	54, 11			decoupling capacitor should be connected
GNDA	51,	31,	Power	-	Analog ground
	57,	43, 50			Design the analog ground plane as wide as
	63,				possible during PCB layout
	65,				
	76				
GND	6,7,	7, 8,	Power	-	Digital ground
	36,	26,			Design the digital ground plane as wide as
	69, 92	47,63			possible during PCB layout
1V8O	74	48	Power	-	1.8V regulated output voltage
					1.8V/150mA power generated by internal power
					regulator which is used for core operation power
					(VCC1A8, VCC1V8).
					Between the 1V8O and GND, Be sure to connect a
					3.3uF tantalum capacitor for output frequency
					compensation and a 0.1uF capacitor for high
					frequency noise decoupling.
					1V80 is connected to VCC1V8, separated to 1uH
					inductor and connected to VCC1A8.
					<notice> 1V8O is the power supply for W7100A use</notice>
					only. This supply should not be connected with
					any other devices.




Figure 1.9 Power Design

1.5 64pin package description

1.5.1 Difference betweer	100	and	64pin	package
--------------------------	-----	-----	-------	---------

	1 1 8	
Difference	64 pin	100 pin
	T0, T1, GATE0, GATE1, T2, T2EX, nINT1, nINT2,	
Deleted nin	nINT3, FDXLED, COLLED, RXLED, TXLED, PM2,	
Deleted pin	PM1, PM0, EXTALE, EXTDATAWR, EXTDATARD,	-
	GPIO3[0:7], GPIO2[3:7]	
External memory	Х	0
PHY mode setting	only use SFR	use SFR or PM pins
GPIO	max 19pin	max 32pin

*Note: In case of 64pin package, the PHY mode is must be set by PHYCONF SFR. So, user must set the MODE_EN bit to enable the MODE2 ~ 0 bit configuration. Then set the MODE2 ~ 0 value and reset the PHY controlling the PHY_RSTn bit. After the reset the 64pin package chip will be successfully initialized and operate properly. When the user uses the 64pin package chip, the code below must be executed in chip initialize routine.

For more detailed information about the PHYCONF SFR, please refer to the section 2.5.10 'New & Extended SFR'.

Internet Embedded MCU W7100A Datasheet



PHYCONF |= 0x08; // MODE_EN bit enable
PHYCONF &= 0xF8; // MODE2 ~ 0 value is 0 (normal mode); Auto configuration mode
PHYCONF |= 0x20; // Set the PHY_RSTn bit (reset bit)
Delay(); // Delay for reset timing (refer to the section 10 'Reset Timing')
PHYCONF &= ~(0x20); // Clear the PHY_RSTn bit



2 Memory

The W7100A's memory is divided into two types of memories: "Code Memory" and "Data Memory". Each memory can use the memory lock function. If the lock is set, internal memory accessing from outside is denied and also cannot use the W7100A debugger. For more detailed information about the memory lock function, please refer to the "WizISP Program Guide". The memory structure of W7100A is roughly shown figure 2.1.




Figure 2.1 Code / Data Memory Connections

*Note:

We recommend the use of an external Power Supply Low Voltage Detector to prevent system malfunction during periods of insufficient power supply voltage.

It can be prevented Non-volatile Memory Corruption, SRAM Corruption and CPU Register Corruption. Please refer to the iMCU7100EVB's Schematic on <u>WIZnet website</u>.

(Example ICs : MAX811, MIC811, DS1811)



2.1 Code Memory

"Code Memory" consists the Boot ROM from 0x0000 to 0x07FF and Code FLASH from 0x0000 to 0xFFFF. After the system is reset, the W7100A always executes the code of Boot ROM at "Code Memory." According to the BOOTEN pin, the code of Boot ROM executes differently. Figure 2.2 shows the flow of Boot ROM code. After the booting, the system proceeds to either the ISP process or the APP Entry according to the BOOTEN pin. When ISP process is selected (BOOTEN = '1'), the ISP code of the Boot ROM will run. Otherwise (BOOTEN = '0'), the system jumps to the APP Entry without running the ISP code of Boot ROM.

ISP code is used for WizISP program when writing user code to code FLASH. And the APP Entry is used for running user application code. The APP Entry contains the 'memory map switching code' and the jumping code which jumps to the start address 0x0000 of the user application in Code FLASH memory. The memory map switching is as below.




Figure 2.2. Boot Sequence Flowchart

The initial state of W7100A has both 'Boot ROM / APP Entry' and FLASH as shown in Figure 2.3. But since the addresses of 'Boot ROM / APP Entry' and FLASH are overlapped, they use same address at 0x0000 ~ 0x07FF / 0xFFF7 ~ 0xFFFF. The iMCU W7100A respectively maps the 'Boot ROM / APP Entry' and FLASH(64K) to the code and data memory.

The user application code can be written to the FLASH(mapped to data memory). But in this state, the FLASH cannot be used as a code memory because this state is for writing user application code. To use the FLASH as a code memory, the memory map needs to be switched. To do this, user should select APP Mode by setting the BOOTEN pin to '0', and then the Boot ROM code jumps to APP Entry immediately. Next, the APP Entry un-maps the Boot ROM and maps the Code FLASH to code memory. After switching the code memory map, the APP Entry




Figure 2.3 APP Entry Process

jumps to start address of Code FLASH (0x0000). This flow is shown in Figure 2.3.

If the APP Mode is selected, the Code FLASH 64KB can be used as a code memory. But both FLASH and APP Entry are still overlapped at the same address. Therefore, to use all FLASH 64KB, the APP Entry must be un-mapped from "Code Memory." To un-map APP Entry, user should set RB bit in WCONF(0xFF) to '0' at the user startup code. Then the APP Entry is un-mapped as shown below.




Figure 2.4 Changing the code memory Status at RB = '0'

WCONF (0xFF)								
7	6	5	4	3	2	1	0	Reset
RB	ISPEN	EM2	EM1	EM0	Reserved	FB	BE	0x00



When the Code FLASH takes more than 0xFFF7, the below code must be inserted into startup code. If using this method, the W7100A immediately disables the APP Entry address after its system reset.

|--|

Set the BOOTEN pin to '0' and clear the **RB** bit of WCONF register at the startup code. Then the embedded Code FLASH 64KB memory of the W7100A can be completely used as a code memory.

2.1.1 Code Memory Wait States

The wait states are managed by internal WTST(0x92) register. The number of wait states is fixed by the value stored in the WTST register. Please refer to the section 2.5.10 'New & Extended SFR' for more details.

2.2 Data Memory

The W7100A contains 64KB of embedded RAM, 64KB of TCPIPCore and the 255Byte of the Data FLASH. The Data FLASH can be used for saving user IP, MAC, subnet mask or port number. Also the W7100A can address up to 16M bytes of external Data Memory. The figure below shows the Data Memory map. This memory is accessed by MOVX instructions only. The external memory can be extended by user.




Figure 2.5 Data Memory Map

2.2.1 Data Memory Wait States

The Data Memory wait states are managed by CKCON(0x8E). The number of wait states is

fixed to the value stored inside CKCON register. Please refer to the section 2.5.10 'New & Extended SFR' for more detailed information.

2.3 External Data Memory Access

The external address pin and data pin has two access modes. The first mode is to use latch to address line in standard 8051. And the second method is directly connecting all lines to address line. Also user can use address pin and data pin as GPIO (General Purpose I/O). Please refer to the section 10 'Electrical specification' for the speed of external memory accessing.

Mode	EM[2:0]	PO	P1	P2	P3
Standard 1	001	Addr[7:0]/Data[7:0]	GPIO	Addr[15:8]	GPIO
Standard 2	011	Addr[7:0]/Data[7:0]	GPIO	Addr[15:8]	Addr[23:16]
Direct 1	101	Data[7:0]	Addr[7:0]	Addr[15:8]	GPIO
Direct 2	111	Data[7:0]	Addr[7:0]	Addr[15:8]	Addr[23:16]

Tahlo	21	External	momory	220006	moda
Iable	Z. I	LALCINAI	I I CI I O I Y	access	moue

2.3.1 Standard 8051 Interface

This method is same as external interface of general 8051. But the range of accessible address is changed refer to the setting of EM[2:0] (External Memory Mode) which spaced WCONF(0xFF) of SFR register. When user sets the EM[2:0] to "001", the port0 is used as address/data bus and the port2 is used as upper side address (A[15:8]). The port1 and port3 is used as GPIO. It is shown the figure below.




Figure 2.6 Standard 8051 External Pin Access Mode (EM[2:0] = "001")

When user sets the EM[2:0] to "011", as in the previous case, the port0 is used as address/data bus and the port2 is used as upper side address (A[15:8]). But, since the port3 is used as topside address (A[23:16]), the range of accessible address is expanded. The



remained port1 is used as GPIO. It is shown the figure below.




Figure 2.7 Standard 8051 External Pin Access Mode (EM[2:0] = "011")

In the Standard 8051 External pin access mode, MCU controls the ALE (Address Latch Enable) signal to classify the address and data signal. User can configure the duration of ALE signal using the ALECON(0x9F) SFR. For more detailed information about ALECON, please refer to the section 2.5.10 'New & Extended SFR'.

2.3.2 Direct Interface

This method is directly connecting the data line to address line. When user sets the EM[2:0] to "101", the port0 is used as data line (D[7:0]) and the port1 is lower side address (A[7:0]) and the port2 is used as upper side address (A[15:8]). The remained port3 can be used as GPIO. Using this method, user can connect data line to address line without latch. It is shown the figure 2.8 as below.




Figure 2.8 Direct 8051 External Pin Access Mode (EM[2:0] = "101")



When user sets the EM[2:0] to "111", the port0, port1 and port2 has same usage in the previous case and the port3 is used as topside address (A[23:16]). In this method, there is no port to use GPIO. It is shown the figure below.




Figure 2.9 Direct 8051 External Pin Access Mode (EM[2:0] = "111")

2.4 Internal Data Memory and SFR

The Figure below shows the Internal Memory and Special Function Registers (SFR) map.

0xFF 0x80	Upper Internal RAM shared with Stack space (indirect addressing)	SFR Special Function Registers (direct addressing)			
0x7F 0x30		nared with Stack space			
0x2F 0x20	bit addres	sable area			
0x1F 0x00	4 banks, R0-R7 each				

Figure 2.10	Internal	Memory	Мар
-------------	----------	--------	-----

The lower internal RAM consists of four register banks with eight registers each, a bitaddressable segment with 128 bits (16 bytes) that begins at 0x20, and a scratchpad area with 208 bytes is embedded. With **indirect** addressing mode ranging from 0x80 to 0xFF, the highest 128 bytes is accessed as an internal memory. But with **direct** addressing mode ranging from 0x80 to 0xFF, this area is accessed as a SFR memory.

F8	EIP	DPSBK	2	0	-	Q	PHYCONF	WCONF
(FO	В	ISPID	ISPADDR	ISPADDR	ISPDATA	CKĊBK	DPXOBK	DPX1BK
E8	EIE		MXAX	P0_PU	P1_PU	P2_PU	P3_PU	PHY_IND
EO	ACC	8	î	PO_PD	P1_PD	P2_PD	P3_PD	
D8	WDCON	(CLK_CNTO	CLK_CNT1	CLK_CNT2	CLK_CNT3
DO	PSW	5		Ç.		3	3	
C8	T2CON		RLDL	RLDH	TL2	TH2	5 - 2	
:C0		l.	5		5	Reserved	8 8	TA
88	IP		0	0		5 V	8 22	
BO	P3	-	0	0		5 V	8 22	
A8	IE							
(AO	P2					1		
×98	SCON0	SBUF			INTWTST	EXTV	VTST	ALECON
×90	P1	EIF	WTST	DPX0		DPX1	10 12	
<88	TCON	TMOD	TL0	TL1	TH0	TH1	CKCON	
(80	PO	SP	DPLO	DPHO	DPL1	DPH1	DPS	PCON

Figure 2.11 SFR Memory Map

New SFR - New additional SFR, described in this section

Extended SFR - Extended from standard 8051, described in this section

Standard - standard 8051 SFR, described in this section

All of the SFR in the left hand side column ending with 0 or 8 are bit addressable.

2.5 SFR definition

WIZ<u>net</u>

The following section describes SFR of W7100A and its functions. For more detailed information about peripheral SFR, please refer to the section 2.5.11 'Peripheral SFR'.

2.5.1 Program Code Memory Write Enable Bit

Inside the PCON register, the Program Write Enable (PWE) bit is used to enable/disable Program Write signal activity during MOVX instructions.

When the PWE bit is set to logic '1', the "MOVX @DPTR, A" instruction writes the data from the accumulator register into the code memory addressed by using the DPTR register (active DPH:DPL)

The "MOVX @Rx, A" instruction writes the data from the accumulator register into code memory addressed by using the P2 register (bits 15:8) and Rx register (bits 7:0).

PCON (0x87)								
7	6	5	4	3	2	1	0	Reset
SMOD0	-	-	PWE	-	0	0	0	0x00
Figure 2.12 DW/E bit of DCON Degistor								

Figure 2.13 PWE bit of PCON Register

Note: 1. PCON.2 ~ PCON.0 bits are reserved. They must be set to '0'



2.5.2 Program Code Memory Wait States Register

Wait states register provides the information for code memory access time.

			V	VTST (O	x92)			
7	6	5	4	3	2	1	0	Reset
-	-	-	-	-	WTST.2	WTST.1	WTST.0	0x07

Figure 2.14 Code memory Wait States Register

Note: 1. These bits are considered during program fetches and MOVC instructions only. Since code memory write are performed by MOVX instruction, CKCON register regulates the CODE-WR pulse width.

2. Read cycle takes minimal 4 clock period and maximal 8 clock periods. Table 2.2 WTST Register Values

	able Ele Miler Register Taldes
WTST[2:0]	Access Time [clk]
7	8
6	7
5	6
4	5
3	Not Used
2	Not Used
1	Not Used
0	Not Used

During Instruction fetching, code memory can be accessed by MOVC instruction only. The code memory can be read with minimal 4 wait states. The timing diagrams are shown in the Figures below.




Figure 2.12 Waveform for code memory Synchronous Read Cycle with Minimal Wait State s (WTST = '4')

Note:

- 1. clk System clock frequency (88.4736 MHz)
 - 2. ADDRESS Address of the actual modified program byte
 - 3. CODE_RD Read signal of the code memory
 - 4. CODE Data write to the actual modified program byte



The code memory can be written by MOVX instruction with minimal 4 wait states. It allows W7100A core to operate with fast and slow code memory devices. The timing diagrams are shown in the Figure below.

clk	~		
ADDRESS		min 6 clk ADDRESS	→ X
CODE		Х DATA	min tclk+ X
CODE_WR	min tclk-	⇒la4 clk⇒	,
PRG	old value	max.4 clk. » X X	new value

Figure 2.13 Waveform for code memory Synchronous Write Cycle with Minimal Wait State s(WTST = '4')

Note:

- 1. clk System clock frequency (88.4736 MHz)
 - 2. ADDRESS Address of the actual modified program byte
 - 3. CODE Data write to the actual modified program byte
 - 4. CODE_WR Write signal of the code memory
 - 5. PRG State of the code memory

2.5.3 Data Pointer Extended Registers

Data Pointer Extended registers, DPX0, DPX1 and MXAX, hold the most significant part of memory addresses when accessing to data located above 64KB. After reset, DPX0, DPX1, and MXAX restores to the default value 0x00.

DPX0 (0x93)										
7	7 6 5 4 3		2	1	0	Reset				
DPXP.7	DPX.6	DPX.5	DPX.4	DPX.3	DPX.2	DPX.1	DPX.0	0x00		
Figure 2.17 Data Pointer Extended Register										
DPX1 (0x95)										
7	6	5	4	3	2	1	0	Reset		
DPX1.7	DPX1.6	DPX1.5 DPX1.4 DPX1.3 DPX		DPX1.2	DPX1.1	DPX1.0	0x00			
		Figure 2	2.18 Data	Pointer E	xtended R	egister				
MXAX (0xEA)										
7	6	5	4	3	2	1	0	Reset		
MXAM.7	MXAX.6	MXAX.5	MXAX.4	MXAX.3	MXAX.2	MXAX.1	MXAX.0	0x00		
		Figure	2.19 MOV	/X @RI Ex	tended Re	gister				
hon MOV	/X instructi	on usos DI		D1 rogisto	r the most	t significar	t part of	bo add		

When MOVX instruction uses DPTR0/DPTR1 register, the most significant part of the address A[23:16] is always equal to the content of DPX0(0x93)/DPX1(0x95). When MOVX instruction



uses R0 or R1 register, the most significant part of the address A[23:16] is always equal to the content of MXAX(0xEA) while another A[15:8] is always equal to P2(0xA0) contents.

2.5.4 Data Pointer Registers


Dual data pointer registers are implemented to speed up data block copying. DPTR0 and DPTR1 are located in four SFR addresses. Active DPTR register is selected by SEL bit (0x86.0). If the SEL bit set to '0', DPTR0 (0x83:0x82) is selected, otherwise DPTR1 (0x85:0x84) is selected.

								DP	TR0(0)x83:	0x82))					
	DPH0(0x83)							DPL0(0x82)							Reset		
	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0	0x0000
						Figur	e 2.2	20 Da	nta P	ointe	r Reç	gister	DPT	R0			
								DP	TR1(0)x85:	0x84))					
			[DPH1	(0x 85)					[OPL1((0x84)			Reset
	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0	0x0000
		Figure 2.21 Data Pointer 1 Register DPTR1															
									DPS	(0x8	6)						
		7		6		5		4		3		2		1		0	Reset
	10	ID1		D0	٦	SL	-			-		-		-		SEL	0x00
		Figure 2.22 Data Pointer Select Register															
0	ote:	TSL	- To	ggle	selea	ct en	able.	Whe	en TS	SL is	set,	this	bit t	oggle	es th	ne SEL	bit by exe
		uting the following instructions															

uting the following instructions. INC DPTR MOV DPTR, #data16 MOVC A, @A + DPTR MOVX @DPTR, A MOVX @DPTR, A MOVX A, @DPTR When TSL = 0, DPTR related instructions will not affect the state of the SEL bit. Unimplemented bit - Read as 0 or 1. Table 2.3 DPTR0, DPTR1 Operations

ID1	ID0	SEL = 0	SEL = 1			
0	0	INC DPTR	INC DPTR1			
 0	1	DEC DPTR	INC DPTR1			





2.5.5 Clock Control Register

Clock control register CKCON (0x8E) contains MD [2:0] bits which provide the information for the dedicated data memory read/write signal pulses width.

			CI	KCON (0x	8E)			
7	6	5	4	3	2	1	0	Reset
WD1	WD0	-	-	-	MD2	MD1	MDO	0x07
							_	

Figure 2.23 Clock Control Register - STRETCH bits

The dedicated data memory read/write signals are activated during MOVX instruction. The purpose of MD[2:0] is to adjust the communication speed with I/O devices such as slow RAM, LCD displays, etc. After reset, MD[2:0] will be restored to the default value of 0x07, which means that slow devices work properly. Users can change the MD[2:0] value to speed up/slow down the software execution. The value of MD[2:0] can be changed any time during program execution (e.g. between MOVX and different speed devices).

MD[2:0]	Pulse Width[clock]	
7	8	
2	3	
1	Not Used	
0	Not Used	

Table 2.	4 MI	D[2:0]	Bit	Values
----------	------	--------	-----	--------

This read/write pulse width must have a minimum of 3 clock cycle and a maximum of 8 clock cycle.

2.5.6 Internal Memory Wait States Register

Internal Memory Wait States Register INTWTST(0x9C) is used for setting the access time of internal 64KB RAM, TCPIPCore and 255Byte internal flash.



INTWTST (0x9C)

7	6	5	4	3	2	1	0	Reset
Ram	WTST	TCI	PIPCore W	TST	ł	lash WTS	Г	0xFF
		Figure 2.2	24 Interna	I Memory	, Wait Stat	es Registe	er	

rigure 2.21 internal memory wait otates Register

0 F D....

– Ram WTST: Set the 64Kbytes RAM access time, has two 2bit value 0 ~ 3.

- TCPIPCore WTST: Set the TCPIPCore access time, has 3bit value 0 ~ 7.

- Flash WTST: Set the internal flash access time, has 3bit value 0 ~ 7.

Internal ram WTST value means below access time in table 2.3.

	Table 2.5 Ram WIST Bit Values
WTST	Pulse Width[clock]
3	5
2	4
1	3
0	2

WITCT D'IL MAL

TCPIPCore, Internal flash WTST value means below access time in table 2.4.

	WTST	Pulse Width[clock]
	7	10
	6	9
	5	8
	4	7
	3	6
	2	5
	1	4
_	0	3

Table 2.6 TCPIPCore / Flash WTST Bit Values

2.5.7 Address Latch Enable Register

ALECON SFR is used for standard 8051 external pin access mode. The time duration of ALE (Address Latch Enable) signal can be controlled by ALECON SFR.

If we set the ALECON to 1, ALE signal will be down to '0' after 1 clock. If we set it to 'n', ALE signal maintains 1+n clock and down to '0'.

ALE maintain duration = ALECON value + 1 clock

The initial value of ALECON is 0xFF. User can configure this value depending on external device speed.



			AL	ECON (0x	(9F)			
7	6	5	4	3	2	1	0	Reset
AC.7	AC.6	AC.5	AC.4	AC.3	AC.2	AC.1	AC.0	0xFF
		Figure 2.25	5 Interna	Memory	Wait States	Reaister		

2.5.8 External Memory Wait States Register

EXTWTST SFR is used for configuring the timing of external memory access. Using the 16bit of this SFR user can control the value from 0 to 65535.

				EX	TWTSTO	(0x9D)			
	7	6	5	4	3	2	1	0	Reset
	EW.7	EW.6	EW.5	EW.4	EW.3	EW.2	EW.1	EW.0	0xFF
		Figure	2.26 First	Byte of	Internal	Memory	Wait States	Register	
				EX	TWTST1	(0x9E)			
	7	6	5	4	3	2	1	0	Reset
E	EW.15	EW.14	EW.13	EW.12	EW.11	EW.10	D EW.9	EW.8	0xFF

Figure 2.27 Second Byte of Internal Memory Wait States Register

2.5.9 Stack Pointer

The W7100A has an 8-bit stack pointer called SP(0x81) and is located in the internal RAM space.

				SP (0x81)				
7	6	5	4	3	2	1	0	Reset
SP. 7	SP.6	SP.5	SP. 4	SP. 3	SP.2	SP.1	SP.0	0x07

Figure 2.28 Stack Pointer Register

This pointer is incremented before data is stored in PUSH and CALL executions, and decremented after data is popped in POP, RET, and RETI executions. In other words, the Stack pointers always points to the last valid stack byte.

2.5.10 New & Extended SFR

PHY_IND(0xEF): PHY indicator register, shows the current state of internal PHY in W7100A.

			PF	IY_IND (0x	EF)			
7	ť	5 5	4	3	2	1	0	Reset
					FDX	SPD	LINK	0x00
			Figure 2.2	9 PHY Stat	us Registe	r		
Note:	FDX	: 0 - Full (duplex / 1	- Half dup	olex			
	SPD	: 0 - 100M	bps / 1 - ^	10Mbps				



LINK : 0 - The link is down / 1 - The link is up

ISPID(0xF1) : ID Register for ISP.

ISPADDR16(0xF2) : 16bit Address Register for ISP

ISPDATA(0xF4) : Data Register for ISP.

CKCBK(0xF5) : CKCON Backup Register.

DPX0BK(0xF6) : DPX0 Backup Register.

DPX1BK(0xF7) : DPX1 Backup Register.

DPSBK(0xF9) : DPX Backup Register.

RAMBA16(0xFA) : RAM Base Address Register.

RAMEA16(0xFC) : RAM End Address Register.

PHYCONF (0xFE): W7100A PHY operation mode, reset, power down configuration register PHYCONF (0xFE)

7	6	5	4	3	2	1	0	Reset
-	-	PHY_RSTn	PHY_PWDN	MODE_EN	MODE2	MODE1	MODE0	0x00

Figure 2.30 Internal PHY Configuration Register

Note: PHY_RSTn: Reset the Internal PHY of W7100A, if user want to reset the PHY usi ng this bit, set this bit '1' first, then manually clear to '0' after the reset time. About the reset time please refer to the section 10 'Elec trical Specification'.

PHY_PWDN: 1- Power down mode: turn off the embedded Ethernet PHY to save power consumption

0 - Normal operation mode.

MODE_EN : 1 - Configure W7100A operation mode using the MODE2 ~ 0 bit / 0 - d on't use MODE2 ~ 0 bit. In the QFN 64pin package, must use this bit and MODE2 ~ 0 bits to configure the operation mode of W7100A

MODE2 ~ 0: Please refer to the section 1.4.2 'Pin Description' PM2 ~ 0 pin settin g value, MODE2 ~ 0 bit are same as PM2 ~ 0 pin.

: Reserved, must be set to '0'

ex> usage of mode selection using MODE2 ~ 0

PHYCONF |= 0x08; // MODE_EN bit enable
PHYCONF &= 0xF8; // MODE2 ~ 0 value is 0 (normal mode); Auto configuration mode
PHYCONF |= 0x20; // Set the PHY_RSTn bit (reset bit)
Delay(); // Delay for reset timing(refer to the section 10 'Electrical Specification')
PHYCONF &= ~(0x20); // Clear the PHY_RSTn bit



				WCONF	(0xFF)			
7	6	5	4	3	2	1	0	Reset
RB	ISPEN	EM2	EM1	EMO	Reserved	FB	BE	0x00
		Figure	e 2.31 W7	100A Conf	iguration R	egister		
lote:								
RE	3 : 0 - No	Reboot /	1 - Rebo	ot after t	he ISP don	e (APP Er	ntry(0xFFF7	7 ~ 0xFFI
F	RD/WR Ena	ble)						
15	SPEN : 0	- Enable	ISP in Bo	ot built ir	W7100A /	/ 1 - Disa	ble	
E	M[2:0] :	External r	memory m	ode, plea	se refer to	the sect	ion 2.3 'Ex	ternal Da
N	lemory Acc	ess'.						
	FB :	FLASH Bus	sy Flag fo	r ISP. Read	d only.			
	BE :	Boot Enab	ole (1 - Bo	ot Runnin	g / 0 - Ap	ps Runnii	ng). Read	only.
	0(0xDC): V	V7100A cc	ore clock (count reai	ster bit0 ~	7.		
	- (<_CNTO (0				
7	,	-		-	-		•	
/	6	5	4	3	2	1	0	Reset
/ Bit7	Bit6	Bit5	Bit4	Bit3	2 Bit2	1 Bit1	0 Bit0	Reset 0x00
		Bit5	Bit4	Bit3	Bit2	Bit1		
Bit7	Bit6	Bit5 Fig	Bit4 ure 2.32 (Bit3 Core clock	Bit2 count reg	Bit1 ister	Bit0	0x00
Bit7 ote: Cl	Bit6 LK_CNT is	Bit5 Fig 32bit SFR	Bit4 ure 2.32 (, reset va	Bit3 Core clock lue is 0,	Bit2 count reg increase it	Bit1 ister s value a	Bit0 t every co	0x00
Bit7 lote: Cl his	Bit6 LK_CNT is s SFR is us	Bit5 Fig 32bit SFR sed for co	Bit4 ure 2.32 (, reset va unting cor	Bit3 Core clock lue is 0, re clock o	Bit2 count reg increase it r measurin	Bit1 ister s value a g time or	Bit0 t every co · clock.	0x00 re clock.
Bit7 lote: Cl his	Bit6 LK_CNT is s SFR is us	Bit5 Fig 32bit SFR sed for co	Bit4 ure 2.32 (, reset va unting cor	Bit3 Core clock lue is 0, re clock o	Bit2 count reg increase it	Bit1 ister s value a g time or	Bit0 t every co [.] clock.	0x00 re clock.
Bit7 ote: Cl his e	Bit6 LK_CNT is s SFR is us x> 1 secor	Bit5 Fig 32bit SFR sed for co nd = abou	Bit4 ure 2.32 (, reset va punting con t 88000000	Bit3 Core clock lue is 0, re clock o) clock co	Bit2 count reg increase it r measurin unt (core	Bit1 ister s value a g time or clock is a	Bit0 t every co [.] clock.	0x00 re clock.
Bit7 ote: Cl his e	Bit6 LK_CNT is s SFR is us x> 1 secor	Bit5 Fig 32bit SFR sed for co nd = abou	Bit4 ure 2.32 (, reset va ounting con t 88000000 pre clock (Bit3 Core clock lue is 0, re clock o Clock co count regi	Bit2 count reg increase it r measurin unt (core a ster bit8 ~	Bit1 ister s value a g time or clock is a	Bit0 t every co [.] clock.	0x00 re clock
Bit7 ote: Cl his e	Bit6 LK_CNT is s SFR is us x> 1 secor	Bit5 Fig 32bit SFR sed for co nd = abou	Bit4 ure 2.32 (, reset va ounting con t 88000000 pre clock (Bit3 Core clock lue is 0, re clock o) clock co	Bit2 count reg increase it r measurin unt (core a ster bit8 ~	Bit1 ister s value a g time or clock is a	Bit0 t every co [.] clock.	0x00 re clock
Bit7 lote: Cl his e CLKCNT	Bit6 LK_CNT is s SFR is us x> 1 secor O(OxDD): \	Bit5 Fig 32bit SFR sed for co nd = abou W7100A co 5	Bit4 ure 2.32 (, reset va ounting con t 88000000 pre clock o CLI 4	Bit3 Core clock lue is 0, re clock o clock co count regi <_CNT1 (0	Bit2 count reg increase it r measurin unt (core ster bit8 ~ xDD)	Bit1 ister s value a g time or clock is a - 15.	Bit0 t every co · clock. bout 88MH	0x00 re clock.
Bit7 lote: Cl his e	Bit6 LK_CNT is s SFR is us x> 1 secor 0(0xDD): \ 6	Bit5 Fig 32bit SFR sed for co nd = abou W7100A co 5 Bit13	Bit4 ure 2.32 (, reset va ounting con t 88000000 pre clock (CLI 4 Bit12	Bit3 Core clock lue is 0, re clock o clock co count regi <_CNT1 (0 3 Bit11	Bit2 count reg increase it r measurin unt (core ster bit8 ~ xDD) 2 Bit10	Bit1 ister s value a g time or clock is a 15. 15. 1 Bit9	Bit0 t every co clock. bout 88MH	0x00 re clock. z) <u>Reset</u>
Bit7 lote: Cl his e CLKCNT	Bit6 LK_CNT is s SFR is us x> 1 secor 0(0xDD): \ 6	Bit5 Fig 32bit SFR sed for co nd = abou W7100A co 5 Bit13	Bit4 ure 2.32 (, reset va ounting con t 88000000 pre clock (CLI 4 Bit12	Bit3 Core clock lue is 0, re clock o clock co count regi <_CNT1 (0 3 Bit11	Bit2 count reg increase it r measurin unt (core ster bit8 ~ xDD) 2	Bit1 ister s value a g time or clock is a 15. 15. 1 Bit9	Bit0 t every co clock. bout 88MH	0x00 re clock. z) <u>Reset</u>
Bit7 ote: Cl his e :LKCNT 7 Bit15	Bit6 LK_CNT is s SFR is us x> 1 secor 0(0xDD): \ 6 Bit14	Bit5 Fig 32bit SFR and for co and = abou W7100A co 5 Bit13 Fig	Bit4 ure 2.32 (, reset va unting cor t 88000000 ore clock (CLI 4 Bit12 ure 2.33 (Bit3 Core clock lue is 0, re clock o clock co count regi <_CNT1 (0 3 Bit11 Core clock	Bit2 count reg increase it r measurin unt (core ster bit8 ~ xDD) 2 Bit10 count reg	Bit1 ister s value a g time or clock is a 15. 15. 1 Bit9 ister	Bit0 t every co clock. bout 88MH	0x00 re clock. z) <u>Reset</u>
Bit7 ote: Cl his e LKCNT 7 Bit15	Bit6 LK_CNT is s SFR is us x> 1 secor 0(0xDD): \ 6 Bit14	Bit5 Fig 32bit SFR and for co and = abou W7100A co 5 Bit13 Fig	Bit4 ure 2.32 (, reset va ounting con t 88000000 ore clock (CLI A Bit12 ure 2.33 (ore clock (Bit3 Core clock lue is 0, re clock o clock co count regi CCNT1 (0 3 Bit11 Core clock	Bit2 count reg increase it r measurin unt (core ster bit8 ~ xDD) 2 Bit10 count reg ster bit16	Bit1 ister s value a g time or clock is a 15. 15. 1 Bit9 ister	Bit0 t every co clock. bout 88MH	0x00 re clock. z) <u>Reset</u>
Bit7 lote: Cl his e CLKCNT Bit15	Bit6 LK_CNT is s SFR is us x> 1 secor 0(0xDD): \ 6 Bit14 0(0xDE): \	Bit5 Fig 32bit SFR sed for co nd = abou W7100A co 5 Bit13 Fig W7100A co	Bit4 ure 2.32 (, reset va ounting con t 88000000 ore clock (Bit12 ure 2.33 (ore clock (CL	Bit3 Core clock lue is 0, re clock o clock co count regi CCNT1 (0 3 Bit11 Core clock count regi	Bit2 count reg increase it r measurin unt (core ster bit8 ~ xDD) 2 Bit10 count reg ster bit16 xDE)	Bit1 ister s value a g time or clock is a 15. 15. <u>1</u> Bit9 ister ~ 23.	Bit0 t every co clock. bout 88MH 0 Bit8	0x00 re clock. z) <u>Reset</u> 0x00
Bit7 lote: Cl his e CLKCNT 7 Bit15	Bit6 LK_CNT is s SFR is us x> 1 secor 0(0xDD): \ 6 Bit14	Bit5 Fig 32bit SFR and for co and = abou W7100A co 5 Bit13 Fig	Bit4 ure 2.32 (, reset va ounting con t 88000000 ore clock (CLI A Bit12 ure 2.33 (ore clock (Bit3 Core clock lue is 0, re clock o clock co count regi CCNT1 (0 3 Bit11 Core clock	Bit2 count reg increase it r measurin unt (core ster bit8 ~ xDD) 2 Bit10 count reg ster bit16	Bit1 ister s value a g time or clock is a 15. 15. 1 Bit9 ister	Bit0 t every co clock. bout 88MH	0x00 re clock z) Reset



CLKCNTO(0xDF): W7100A core clock count register bit24 ~ 31.

CLK_CNT3 (0xDF)								
7	6	5	4	3	2	1	0	Reset
Bit31	Bit30	Bit29	Bit28	Bit27	Bit26	Bit25	Bit24	0x00
Figure 2.25 Core cleak court register								

Figure 2.35 Core clock count register

2.5.11 Peripheral Registers

- PO, P1, P2, P3 : Port register. For detail information, please refer to the section 4 'I/O Ports' for the Functionality of I/O Ports.
- **TCON(0x88)** : Timer0, 1 configuration register. For detail information, please refer to the section 5.1 'Timer 0, 1' for the Functionality of Timer0 and Timer 1.
- **TMOD(0x89)** : Timer0, 1 control mode register. For detail information, please refer to the section 5.1 'Timer 0, 1' for the Functionality of Timer0 and Timer 1.
- THO(0x8C), TLO(0x8A) : Counter register of timer 0. For detail information, please refer to the section 5.1 'Timer 0, 1' for the Functionality of Timer0 and Timer 1.
- TH1(0x8D), TL1(0x8B) : Counter register of timer 1. For detail information, please refer to the section 5.1 'Timer 0, 1' for the Functionality of Timer0 and Timer 1.
- SCON(0x98) : UART Configuration Register. For detail information, please refer to the section 6 'UART' for the Functionality of UART.
- SBUF(0x99) : UART Buffer Register. For detail information, please refer to the section 6 'UART' for the Functionality of UART.
- **IE(0xA8)** : UART Bits in Interrupt Enable Register. For detail information, please refer to the section 6 'UART' for the Functionality of UART.
- **IP(0xB8)** : UART Bits in Interrupt Priority Register. For detail information, please refer to the section 6 'UART' for the Functionality of UART.
- TA(0xC7) : Timed Access Register. For detail information, please refer to the section 7 'Watchdog Timer' for Timed Access Registers of Watchdog Timer.
- T2CON(0xC8) : Timer 2 Configuration Register. For detail information, please refer to the section 5.2 'Timer 2' for the Functionality of Timer 2.
- RLDH(OxCB), RLDL(OxCA) : Capture Registers of Timer 2. For detail information, please refer to the section 5.2 'Timer 2' for the Functionality of Timer 2.
- TH2(0xCD), TL2(0xCC) : Counter Register of Timer 2. For detail information, please refer to the section 5.2 'Timer 2' for the Functionality of Timer 2.
- PSW(0xD0) : Program Status Word Register. For detail information, please refer to the



section 1.3.1 'ALU'.

WDCON(0xD8) : Watchdog Control Register. For detail information, please refer to the section 7 'Watchdog Timer'.



3 Interrupt

The functions of interrupt pins are described in the table below. All pins are unidirectional. There are no tri-state signals.

Pin	Active	Туре	Pu/Pd	Description
	Active	турс	Turru	Beschption
nINT0/FA6	Low/Falling	Ι	-	External interrupt 0
nINT1/FA7	Low/Falling	Ι	-	External interrupt 1
nINT2/FA8	Falling	Ι	-	External interrupt 2
nINT3/FA9	Falling	Ι	-	External interrupt 3
nINT4			-	Reserved
TCPIPCore	Falling	I	-	Interrupt Request Signal for TCPIPCore
(nINT5)				

The W7100A core is implemented with two levels of interrupt priority control. Each external interrupt can be in high or low level priority group by setting or clearing a bit in the IP(0xB8) and EIP(0xF8) registers. External interrupt pins are activated by a falling edge signal. Interrupt requests are sampled at the rising edge of the system's clock.

Interrupt	Function	Active	Flag Reset	Vector	Interrupt	Natural
Flag		Level/Edge			Number	Priority
IE0	Device pin INT0	Low/Falling	Hardware	0x03	0	1
TF0	Internal, Timer0	-	Hardware	0x0B	1	2
IE1	Device pin INT1	Low/Falling	Hardware	0x13	2	3
TF1	Internal, Timer1	-	Hardware	0x1B	3	4
TI & RI	Internal, UART	-	Software	0x23	4	5
TF2	Internal, Timer2	-	Software	0x2B	5	6
INT2F	Device Pin INT2	Falling	Software	0x43	8	7
INT3F	Device Pin INT3	Falling	Software	0x4B	9	8
INT4F	Reserved					
INT5F	Interrupt for	Falling	Software	0x5B	11	10
TCPIPCore	TCPIPCore					
WDIF	Internal,	-	Software	0x63	12	11
	WATCHDOG					

Table 3.2 W7100A Interrupt Summary

Each interrupt vector can be individually enabled or disabled by changing the corresponding



bit in IE(0xA8) and EIE(0xE8) registers. The IE register contains global interrupt system disable(0)/enable(1) bit called EA.

IE (0xA8)								
7	6	5	4	3	2	1	0	Reset
EA	-	ET2	ES	ET1	EX1	ET0	EX0	0x00
Figure 3.1 Interrupt Enable Register								
Note: EA - Enable global interrupt								
EX0 - Enable INTO interrupt								
	ETO -	Enable Tim	ner0 inter	rrupt				
	EX1 -	Enable INT	1 interru	pt				
ET1 - Enable Timer1 interrupt								
ES - Enable UART interrupt								
	ET2 -	Enable Tim	er2 inter	rrupt				

All these bits which generate interrupts can be set or cleared by software, with the same result by hardware. That is, interrupts can be generated or cancelled by software. The only exceptions are the request flags IEO and IE1. If the external interrupt 0 or 1 are programmed as level-activated, the IEO and IE1 are controlled by the external source pins nINTO/FA6 and nINT1/FA7 respectively.

7	6	5	4	3	2	1	0	Reset
-	-	PT2	PS	PT1	PX1	PT0	PX0	0x00
Figure 3.2 Interrupt Priority Register								
Not	e: PX0	- INTO prio	rity level	l control (high level	at 1)		
	PT0 -	Timer0 pri	ority leve	el control	(high leve	el at 1)		
PX1 - INT1 priority level control (high level at 1)								
	PT1 -	Timer1 pri	ority leve	el control	(high leve	el at 1)		
	PS - U	ART priorit	y level c	ontrol (hi	gh level a	t 1)		
	PT2 -	Timer2 pri	ority leve	el control	(high leve	el at 1)		
Unimplemented bit - Read as 0 or 1								
				TCON (0x	88)			

5 4 3 2 0 Reset 6 1 7 IT1 IE0 TF1 TR1 TF0 TR0 IE1 IT0 0x00 Figure 3.3 Timer0, 1 Configuration Register Note: ITO - INTO level (at 0)/edge (at 1) sensitivity IT1 - INT1 level (at 0)/edge (at 1) sensitivity

 IEO - INTO interrupt flag is automatically cleared when processor branches to



interrupt routine

- IE1 INT1 interrupt flag is automatically cleared when processor branches to interrupt routine
- TF0 Timer0 interrupt (overflow) flag. Automatically cleared when processor branches to interrupt routine

TF1 - Timer 1 interrupt (overflow) flag. Automatically cleared when processor branches to interrupt routine

SCON (0x98)								
7	6	5	4	3	2	1	0	Reset
SMO	SM1	SM2	REN	TB8	RB8	TI	RI	0x00

Figure 3.4 UART Configuration Register

Note: RI - UART receiver interrupt flag

TI - UART transmitter interrupt flag

EIE	(0xE8)
-----	--------

7	6	5	4	3	2	1	0	Reset		
-	-	-	EWDI	EINT5	EINT4	EINT3	EINT2	0x00		
	Figure 2.5 Extended Interrupt Enable Degister									

Figure 3.5 Extended Interrupt Enable Register

Note: EINT2 - Enable external INT2 Interrupt

EINT3 - Enable external INT3 Interrupt

EINT4 - Must be '0', if use the EIE register

EINT5 - Enable TCPIPCore Interrupt

EWDI - Enable WATCHDOG Interrupt

EIP	(0xF	8)
-----	------	----

7	6	5	4	3	2	1	0	Reset	
-	-	-	PWDI	PINT5	PINT4	PINT3	PINT2	0x00	
	Figure 3.6 Extended Interrupt Priority Register								
Note:	PINT2 - INT2 priority level control (high level at 1)								
	PINT3	PINT3 - INT3 priority level control (high level at 1)							
	PINT4	PINT4 - Must be set to '0', if use the EIP register							
	PINT5 - TCPIPCore Interrupt priority level control (high level at 1)								
	PWDI - WATCHDOG priority level control (high level at 1)								



EIF (0x91)									
7	6	5	4	3	2	1	0	Reset	
-	-	-	-	INT5F	INT4F	INT3F	INT2F	0x00	
Figure 3.7 Extended Interrupt Flag Register									
Ν	lote: INT2	INT2F - INT2 interrupt flag. Must be cleared by software							
	INT3F	INT3F - INT3 interrupt flag. Must be cleared by software							
	INT4F - Must be set to '0'. if use the EIF register								
	INT5	- TCPIPC	ore Interru	upt flag. Mi	ust be clea	ared by sof	tware		

WDCON	(0xD8)
10001	(0//00)

7	6	5	4	3	2	1	0	Reset
-	-	-	-	WDIF	WTRF	EWT	RWT	0x00

Figure 3.8 Watchdog Control Register

Note: WDIF - Watchdog Interrupt Flag. WDIF in conjunction with the Enable Wat chdog Interrupt bit (EIE.4) and EWT provides information such as whether the Watchdog Timer event has been encountered or not and what action should be taken. This bit must be cleared by sof tware before exiting the interrupt service routine. By using softwa re to enable the WDIF, a Watchdog interrupt is generated. Enable d software-set WDIF will generate a Watchdog interrupt. Timed Ac cess Register procedure can be used to modify this bit.



4 I/O Ports

The I/O port pin functionalities are described in the following table.

			Та	ble 4.1 I/	O Ports Pi	n Descript	ion		
	Pin	Active	Туре	Pu/Pd			Descriptio	on	
PC	[7:0]	-	Ю	-		Port	0 input / c	output	
P1	[7:0]	-	Ю	-		Port	1 input / c	output	
P2[7:0] - IO - Port2 input / output									
P3	[7:0]	-	Ю	-		Port	3 input / c	output	
·					P0 (0x80))			
	7	6	5	4	3	2	1	0	Reset
-	P0.7	P0.6	P0.5	P0.4	P0.3	P0.2	P0.1	P0.0	0xFF
				Figure	4.1 Port0	Register			
					P1 (0x90))			
	7	6	5	4	3	2	1	0	Reset
	P1.7	7 P1.6	P1.5	P1.4	P1.3	P1.2	P1.1	P1.0	0xFF
-				Figure	4.2 Port1	Register			
-					P2 (0xA0)				_
-	7	6	5	4	3	2	1	0	Reset
-	P2.7	P2.6	P2.5	P2.4	P2.3	P2.2	P2.1	P2.0	0xFF
				Figure	4.3 Port2	Register			
					P3 (0xB0))			
	7	6	5	4	3	2	1	0	Reset
	P3.7	7 P3.6	P3.5	P3.4	P3.3	P3.2	P3.1	P3.0	0xFF
-				Figure	4.4 Port3	Register			

Read and write accesses are performed in the I/O ports via their corresponding SFR: P0 (0x80), P1 (0x90), P2 (0xA0), and P3 (0xB0). Some port-reading instructions read from the data registers while others read from the port pin. The "Read-Modify-Write" instructions are directed to the data registers as shown below.



	ad mounty mitte methodiens
Instruction	Function Description
ANL	Logic AND
ORL	Logic OR
XRL	Logic exclusive OR
JBC	Jump if bit is set and cleared
CPL	Complement bit
INC, DEC	Increment, decrement byte
DJNZ	Decrement and jump if not zero
MOV Px.y, C	Move carry bit to bit y of port x
CLR Px.y	Clear bit y of port x
SETB Px.y	Set bit y of port x

Table 4.2 Read-Modify-Write Instructions

All other instructions read from a port exclusively through the port pins. All ports pin can be used as GPIO (General Purpose Input Output). The GPIO of W7100A is shown in the Figure below. The output driving voltage of GPIO is 0V or 3.3V according to the Px_PD/PU SFR value.

PO_PD(0xE3): GPIO0 Pull-down register, the value '1' pull-down the related pin.

			PO	_PD (0xE3)					
7	6	5	4	3	2	1	0	Reset		
Port0[7] Port0[6] Port0[5] Port0[4] Port0[3] Port0[2] Port0[1] Port0[0] 0x00										
	Figure 4.5 Port0 Pull-down register									

P1_PD(0xE4): GPIO1 Pull-down register, the value '1' pull-down the related pin.

	P1_PD (0xE4)									
7	6	5	4	3	2	1	0	Reset		
Port1[7] Port1[6] Port1[5] Port1[4] Port1[3] Port1[2] Port1[1] Port1[0] 0x00										
	Figure 4.6 Port1 Pull-down register									

Figure 4.6 Port1 Pull-down register

P2_PD(0xE5): GPIO2 Pull-down register, the value '1' pull-down the related pin.

			P2	_PD (0xE5)				
7	6	5	4	3	2	1	0	Reset	
Port2[7] Port2[6] Port2[5] Port2[4] Port2[3] Port2[2] Port2[1] Port2[0] 0x0									
Figure 4.7 Port2 Pull-down register									



P3_PD(0xE6): GPIO3 Pull-down register, the value '1' pull-down the related pin.

			J ,				•	
			P3	B_PD (0xE6)			
7	6	5	4	3	2	1	0	Reset
Port3[7]	Port3[6]	Port3[5]	Port3[4]	Port3[3]	Port3[2]	Port3[1]	Port3[0]	0x00
		Fig	ure 4.8 Po	ort3 Pull-de	own regist	er		
P0_PU(0	xEB): GPIO	0 Pull-up re	egister, the	e value '1'	means pul	I-up the re	lated pin.	
			PC)_PU (0xEB	3)			
7	6	5	4	3	2	1	0	Reset
Port0[7]	Port0[6]	Port0[5]	Port0[4]	Port0[3]	Port0[2]	Port0[1]	Port0[0]	0x00
		Fi	gure 4.9 I	Port0 Pull-	up registe	r		
			0					
21 PU(0	xEC): GPIO	1 Pull-up re	eaister the	e value '1'	means pul	l-up the re	lated pin	
		i i un up i		_PU (0xEC				
7	6	5	4	3	2	1	0	Reset
, Port1[7]		Port1[5]	Port1[4]	Port1[3]		Port1[1]	Port1[0]	0x00
	10111[0]						TUITIO	0,00
		FIÇ	jure 4.10	Port1 Pull	-up registe	5[
P2_PU(0	xED): GPIO	2 Pull-up r	egister, the	e value '1'	means pul	I-up the re	lated pin.	
			P2	2_PU (0xEC))			
7	6	5	4	3	2	1	0	Reset
Port2[7]	Port2[6]	Port2[5]	Port2[4]	Port2[3]	Port2[2]	Port2[1]	Port2[0]	0x00
		Fiç	gure 4.11	Port2 Pull	-up registe	er		
P3 PU(0	xEE): GPIO	3 Pull-up re	egister, the	e value '1'	means pul	l-up the re	lated pin.	
	,	·	-	B_PU (0xEE	-	I	•	
7	6	5	4	3	2	1	0	Reset
Port3[7]	Port3[6]	Port3[5]	Port3[4]	Port3[3]	Port3[2]	Port3[1]	Port3[0]	0x00
				Port3 Pull-				one e
		ΓIŲ	Jule 4.12		-up registe	;1		

50



5 Timers

The W7100A contains two 16-bit timers/counters, Timer0 and Timer 1. In the 'timer mode', the timer registers are incremented by every 12 CLK periods. In "counter mode", the timer registers are incremented during the falling transition on their corresponding input pins: T0 or T1. The input pins are sampled at every CLK period.

5.1 Timers 0, 1

5.1.1 Overview

The TimerO, 1 pin functionalities are described in the following table. All pins are unidirectional. There are no tri-state output pins and internal signals.

Pin	Active	Туре	Pu/Pd	Description	
T0/FCS	Falling	I	-	Timer0 clock	
GATE0/FOE	High	I	-	Timer0 clock	gate control
T1/FAE	Falling	I	-	Timer1 clock	
GATE1/FA0	High	I	-	Timer1 clock	gate control

Table 5.1	Timers (0, 1	Pin	Description
-----------	----------	------	-----	-------------

Timer0 and Timer 1 are fully compatible with the standard 8051 timers. Each timer consists of two 8-bit registers, TH0 (0x8C) and TL0 (0x8A), TH1 (0x8D) and TL1 (0x8B). The timers work in four modes which are described below.

M1	MO	Mode	Function Description
0	0	0	THx operates as a 8-bit timer/counter with a divided-by-32
			prescaler served by lower 5-bit of TLx
0	1	1	16-bit timer/counter. THx and TLx are cascaded.
1	0	2	TLx operates as a 8-bit timer/counter with 8bit auto-reload by
			THx.
1	1	3	TL0 is configured as a 8-bit timer/counter controlled by the
			standard Timer0 bits. TH0 is a 8-bit timer controlled by Timer 1
			control bits. Timer 1 holds its count.

Table 5.2 Timers 0, 1 Mode	Table	5.2	Timers	0,	1	Mode
----------------------------	-------	-----	--------	----	---	------



	Tim	ner1			Tim	ner0		
7	6	5	4	3	2	1	0	Reset
GATE	СТ	M1	MO	GATE	СТ	M1	MO	0x00

Figure 5.1 Timer0, 1 Control Mode Register

Note: GATE - Gating control

- 1: Timer x is enabled while GATEx pin is at high and TRx control b it is set
- 0: Timer x is enabled while TRx control bit is set

CT - Counter or timer select bit

- 1: Counter mode, Timer x clock source from Tx pin
- 0: Timer mode, internally clocked
- M1, M0 Mode select bits

TCON (C)x88)
---------	-------

7	6	5	4	3	2	1	0	Reset
TF1	TR1	TF0	TR0	IE1	IT1	IE0	IT0	0x00

Figure 5.2 Timer0, 1 Configuration Register

Note: TR0 - Timer0 run control bit

- 1: Enabled
- 0: Disabled

TR1 - Timer 1 run control bit

- 1: Enabled
- 0: Disabled

External input pins, GATEO and GATE1, can be programmed to function as a gate to facilitate pulse width measurements.

5.1.2 Interrupts

Timer0, 1 interrupt related bits are shown below. An interrupt can be toggled by the IE register, and priorities can be configured in the IP register.

				IE (0xA8)				
7	6	5	4	3	2	1	0	Reset
EA	-	ET2	ES	ET1	EX1	ET0	EX0	0x00

Figure 5.3 Interrupt Enable Register

Note: EA - Enable global interrupts

ET0 - Enable Timer0 interrupts

ET1- Enable Timer1 interrupts



IP (0xB8)									
7	6	5	4	3	2	1	0	Reset	
-	-	PT2	PS	PT1	PX1	PT0	PX0	0x00	
	Figure 5.4 Interrupt Priority Register								
Note:	PT0 - E	Enable glob	al interro	upts					
	PT1 -	Enable Tir	mer0 inte	errupts					
	Unimp	lemented	bit - Rea	d as 0 or	1				
				TCON (0	x88)				

					,			
7	6	5	4	3	2	1	0	Reset
TF1	TR1	TF0	TR0	IE1	IT1	IE0	IT0	0x00

Figure 5.5 Timer0, 1 Configuration Register

Note: TF0 - Timer0 interrupt (overflow) flag. Automatically cleared when proce ssor branches to interrupt routine

TF1 - Timer1 interrupt (overflow) flag. Automatically cleared when proces sor branches to interrupt routine

All of the bits which generate interrupts can be set or cleared by software, with the same result by hardware. That is, interrupts can be generated or cancelled by software.

Table 5.3 Timer() 1 interrupts

Interrupt	Function	Active	Flag Resets	Vector	Natural Priority			
Flag		Level/Edge						
TF0	Internal, Timer0	-	Hardware	0x0B	2			
TF1	Internal, Timer1	-	Hardware	0x1B	4			

5.1.3 Timer0 - Mode0

The Timer0 register is configured as a 13-bit register (8bit: Timer, 5bit: prescaler). As the all counts (valid bits) roll over from 1 to 0, Timer0 interrupt flag TF0 is set. The timer starts counting when TCON.4 =1 and either TMOD.3 = 0 or GATE0 = 1. By setting TMOD.3 = 1, the external input GATE0 can control Timer0 to manage the pulse width measurements. The 13-bit register consists of 8 bits TH0 and 5 bits of TL0. The upper 3 bits of TL0 should be ignored. Refer to the following Figure for details.






Figure 5.6 Timer Counter0, Mode0: 13-Bit Timer/Counter

5.1.4 Timer0 - Mode1

Mode1 is the same as Mode0, except that the timer register is running with all 16 bits. Mode1 is shown in the Figure below.




Figure 5.7 Timer/Counter0, Mode1: 16-Bit Timer/Counter

5.1.5 Timer0 - Mode2

Mode2 configures the timer register as a 8-bit counter TL0 with automatic reload as shown in the Figure below. During an overflow from TL0, it sets TF0 and reloads the contents of TH0 into TL0. TH0 remains unchanged after the reload is completed.






Figure 5.8 Timer/Counter0, Mode2: 8-Bit Timer/Counter with Auto-Reload

5.1.6 Timer0 - Mode3

In this mode, the TLO and THO are divided into two separate counters. The following Figure shows the logic for Timer0 running in Mode3. The TLO uses the Timer0 control bits: C/T, GATE, TRO, GATE0 and TFO. And the THO is locked into a timer function and uses TR1 and TF1 flags from Timer 1 and controls Timer 1 interrupt. Mode3 is used in applications which require an extra 8-bit timer/counter. When Timer0 is in Mode3, Timer 1 can be turned on/off by switching itself into Mode3, or can still be used by the serial channel as a baud rate generator, or in any application where interrupt from Timer 1 is not required.




Figure 5.9 Timer/Counter0, Mode3: Two 8-Bit Timers/Counters



5.1.7 Timer1 - Mode0

In this mode, the Timer1 register is configured as a 13-bit register (8bit: Timer, 5bit: prescaler). As the all counts (valid bits) roll over from 1 to 0, Timer 1 interrupt flag TF1 is set. The counted input is enabled to Timer 1 when TCON.6 = 1 and either TMOD.6 = 0 or GATE1 = 1. (Setting TMOD.7 = 1 allows Timer 1 controlled by external input GATE1, to facilitate pulse width measurements). The 13-bit register consists of 8 bits TH1 and the lower 5 bits of TL1. The upper 3 bits of TL1 are indeterminate and should be ignored. Refer to the following Figure for detail.




Figure 5.10 Timer/Counter1, Mode0: 13-Bit Timer/Counter

5.1.8 Timer1 - Mode1

Mode1 is the same as Mode0, except that the timer register is running with all 16 bits. Mode1 is shown in the Figure below.




Figure 5.11 Timer/Counter1, Mode1: 16-Bit Timers/Counters



5.1.9 Timer1 - Mode2

Mode2 configures timer register as 8-bit counter TL1, with automatic reload as shown in Figure below. Overflow from TL1 only sets TF1, but also automatically reloads TL1 with the contents of TH1. The reload leaves TH1 unchanged.




Figure 5.12 Timer/Counter1, Mode2: 8-Bit Timer/Counter with Auto-Reload

5.1.10 Timer1 - Mode3

Timer1 in Mode3 holds counting. The effect is the same as setting TR1 = 0 because it is used for Timer0-Mode3. For more detail, please refer to the section 5.1.6 'Timer0-Mode3'.



5.2 Timer2

5.2.1 Overview

The Timer2 pin functionalities are described in the following table. All pins are unidirectional. There are no tri-state output pins and internal signals.

Pin	Active	Туре	Pu/Pd	Description
T2/FA1	Falling	Ι	-	Timer2 external clock input
T2EX/FA2	Falling	Ι	-	Timer2 capture/reload trigger

Table	5.4	Timer2	Pin	Description
TUDIC	0.1	11111012		Description

Timer2 of W7100A is fully compatible with the standard 8051 Timer2. A total of five SFR are used to control Timer2 operation, TH2/TL2 (0xCD/0xCC) counter registers, RLDH/RLDL (0xCB/0xCA) capture registers, and T2CON (0xC8) control register. Timer2 works under three modes selected by T2CON bits as shown in the table below.

RCLK, TCLK	CPRL2	TR2	Function Description
0	0	1	16-bit auto-reload mode. TF2 bit is set when Timer2
			overflows. TH2 and TL2 registers are reloaded with 16-
			bit value from RLDH and RLDL.
0	1	1	16-bit capture mode. TF2 bit is set when Timer2
			overflows. When EXEN2=1 and T2EX pin is on the falling
			edge, TH2 and TL2 register values are stored into RLDH
			and RLDL.
1	Х	1	Baud rate generator for UART interface
Х	Х	0	Timer2 is off.

Table 5.5 Timer2 Modes

T2CON	(0xC8)

7	6	5	4	3	2	1	0	Reset		
TF2	EXF2	RCLK	TCLK	EXEN2	TR2	CT2	CPRL2	0x00		
Figure 5.13 Timer2 Configuration Register										
Note:	EXF2 -	indicates	a Falling	edge in t	he T2EX	pin when	EXEN2=1.	Must be o		
eared by software										
	RCLK - Receive clock enable									
	0: UART receiver is clocked by Timer1 overflow pulses									
		1: UART r	eceiver i	s clocked	by Timer2	2 overflov	v pulses			
	TCLK -	Transmit	clock ena	able						
	0: UART transmitter is clocked by Timer1 overflow pulses									



- 1: UART transmitter is clocked by Timer2 overflow pulses
- EXEN2 Enable T2EX pin functionality
 - 0: Ignore T2EX events
 - 1: Allow capture or reload as a result of T2EX pin falling edge
 - TR2 Start/Stop Timer2
 - 0: Stop
 - 1: Start
 - CT2 Timer/Counter select
 - 0: Internally clocked timer
 - 1: External event counter. Clock source is T2 pin
- CPRL2 Capture/Reload select
 - 0: Automatic reload occurs when Timer2 overflow or falling edge of the T2EX pin with EXEN2=1. When RCLK or TCLK is set, this bit is ignored and automatic reload when Timer2 overflows.
 - 1: On the falling edge of T2EX pin, capture is activated when EXEN 2=1.





Figure 5.14 Timer/Counter2, 16-Bit Timer/Counter with Auto-Reload

5.2.2 Interrupts

The interrupt bits for Timer2 are shown below. An interrupt can be toggled by the IE register, and priorities can be configured by the IP register.





Note: EA - Enable global interrupts

ET2 - Enable Timer2 interrupts

	IP (0xB8)									
7	6	5	4	3	2	1	0	Reset		
-	-	PT2	PS	PT1	PX1	PT0	PX0	0x00		
Note		Figure 5. Timer2 int	errupt p	5	el control					

T2CON	(0xC8)
12001	

7	6	5	4	3	2	1	0	Reset	
TF2	EXF2	RCLK	TCLK	EXEN2	TR2	CT2	CPRL2	0x00	
Figure 5.17 Timer2 Configuration Register – TF2									

Note: TF2 - Timer2 interrupt (overflow) flag. It must be cleared by software. T his flag will not be set when either RCLK or TCLK is set.




Figure 5.18 Timer/Counter2, 16-Bit Timer/Counter with Capture Mode

All of the bits that generate interrupts can be set or cleared by software, with the same result by hardware. That is, interrupts can be generated or cancelled by software.



	Table 5.6 Timer2 Interrupt										
Interrupt	Function	Active	Flag Resets	Vector	Natural Priority						
Flag		Level/Edge									
TF2	Internal, Timer2	-	Software	0x2B	6						

Interrupt is generated at the falling edge of T2EX pin with EXEN2 bit enabled.

Using the 0x2B vector, EXF2 is set by this interrupt, but the TF2 flag remains unchanged.




Figure 5.19 Timer2 for Baud Rate Generator Mode



6 UART

The UART of W7100A operates in full duplex mode which is capable of receiving and transmitting at the same time. Since the W7100A is double-buffered, the receiver is capable of receiving data while the first byte of the buffer is not read. During a read operation, the SBUF reads from the receive register. On the other hand, SBUF loads the data into the transmit register during a send operation. The UART has 4 different modes which include one in synchronous mode and three in asynchronous modes. Modes 2 and 3 include a special feature for multiprocessor communication. This feature is enabled by setting the SM2 bit in the SCON register. The master processor sends out the first address byte which identifies the target slave. An address byte differs from a data byte in that the 9th bit is 1 in an address byte and 0 in a data byte. With SM2 = 1, no slave will be interrupted by a data byte, while an address byte will interrupt all slaves. The addressed slave will clear its SM2 bit and prepare to receive the data bytes that will be coming. The slaves that were not being addressed leave their SM2 set and ignore the incoming data.

The pin functionalities of UART are described in the following table.

Pin	Active	Туре	Pu/Pd	Description
RXD	-	Ι	Pu	Serial receiver input / output
TXD	-	0	-	Serial transmitter

Table 6.1 UART Pin Description

The UART of W7100A is fully compatible with the standard 8051 UART. The UART related registers are: SBUF (0x99), SCON (0x98), PCON (0x87), IE (0xA8) and IP (0xB8). The UART data buffer (SBUF) consists of two registers: transmit and receive. When data is written into the SBUF transmit register, the sending process begins. Similarly, data is read from the receive register during the receiving process.

SBUF (0x99)									
7	6	5	4	3	2	1	0	Reset	
SB7	SB6	SB5	SB4	SB3	SB2	SB1	SB0	0x00	
	Figure 6.1 UART Buffer Register								
	SCON (0x98)								
7	6	5	4	3	2	1	0	Reset	
SMO	SM1	SM2	REN	TB8	RB8	TI	RI	0x00	
		Figur	e 6.2 UAF	RT Configu	ration Re	gister			
Note:	SM2 -	Enable a	multiproc	essor con	nmunicatio	on feature	è		
	SM1 - Set baud rate								
	SMO - Set baud rate								



SM0

SM1

REN - '1' : enable serial receive

'0': disable serial receive

TB8 - The 9th transmitted data bit in Modes 2 and 3. This bit is enabled depending on the MCU's operation (parity check, multiprocessor communication, etc.),

RB8 - In Modes 2 and 3, it is the 9th bit of data received. In Mode1, if S M2 is 0, RB08 is a stop bit. In Mode0, this bit is not used.

The UART modes are presented in the table below.

 Table 6.2 UART Modes

 Mode
 Description
 Baud Rate

 0
 Shift register
 focc/12

0	0	0	Shift register	f _{osc} /12
0	1	1	8-bit UART	Variable
1	0	2	9-bit UART	f _{osc} /32 or /64
1	1	3	9-bit UART	Variable

The UART baud rates are presented below.

Table 6.3 UART Baud Rates

Mode	Baud Rate				
Mode0	f _{osc} /12				
Mode1,3	Time1 overflow rate or Timer2 overflow rate				
Mode2	$SMOD0 = 0 \qquad f_{OSC}/64$				
	$SMOD0 = 1 f_{OSC}/32$				

The SMOD0 bit is located in the PCON register.

				PCON ()x87)			
7	6	5	4	3	2	1	0	Reset
SMODO	SMOD1	-	PWE	-	0	0	0	0x00
	Figur	ro 4 2 1	IADT Dite	in Dowor	Configurat	tion Dogist	or	

Figure 6.3 UART Bits in Power Configuration Register

Note: SMOD0 - Bit for UART baud rate


Unimplemented bit - Read as 0 or 1

Bits 2-0 must be written as 0

6.1 Interrupts

UART interrupt related bits are shown below. An interrupt can be toggled by the IE register, and priorities can be configured by the IP register.





Note: ES - RI & TI interrupt enable flag

				IP (OxE	38)			
7	6	5	4	3	2	1	0	Reset
-	-	PT2	PS	PT1	PX1	PT0	PX0	0x00

Figure 6.5 UART Bits in Interrupt Priority Register

Note: SMOD0 - Bit for UART baud rate

Unimplemented bit - Read as 0 or 1

SCON (0x98)									
7	6	5	4	3	2	1	0	Reset	
SMO	SM1	SM2	REN	TB08	RB08	TI	RI	0x00	
Figure 6.6 UART Configuration Register									

Note: TI - Transmit interrupt flag, automatically set after completion of a serial transfer. It must be cleared by software.

RI - Receive interrupt flag, automatically set after completion of a serial reception. It must be cleared by software.

All of the bits that generate interrupts can be set or cleared by software, with the same result by hardware. That is, interrupts can be generated or cancelled by software.

		Table 6.4 UAF	RT Interrupt		
Interrupt	Function	Active	Flag Resets	Vector	Natural Priority
Flag		Level/Edge			
TI & RI	Internal, UART	-	software	0x23	5

6.2 Mode0, Synchronous

TXD output is a shift clock. The baud rate is fixed at 1/12 of the CLK clock frequency. Eight bits are transmitted with LSB first. Reception is initialized by setting the flags in SCON as follows: RI = 0 and REN = 1.

clk		mmm	mmm	nonnon		лаплолити				nnnnnnnn
clk/12	۸	Λ	Δ_	٨	Λ	٨	Λ	Λ	٨	٨
SUF_write		- 5-C			1	50.34			55102	2.67
send	36 									
BUF_shift		-81	Λ.	٨	Λ.	A	Λ	٨	٨	٨
		100					120 X 120 X		1	07 /

Figure 6.7 Timing Diagram for UART Transmission Mode0 (clk = 88.4736 MHz)

6.3 Mode1, 8-Bit UART, Variable Baud Rate, Timer 1 or 2 Clock Source

The pin RXD serves as an input while TXD serves as an output for the serial communication. 10 bits are transmitted in the following sequence: a start bit (always 0), 8 data bits (LSB first), and a stop bit (always 1). During data reception, a start bit synchronizes the transmission. Next, the 8 data bits can be accessed by reading SBUF, and the stop bit triggers the flag RB08 in SFR SCON (0x98). The baud rate is variable and dependent on Timer 1 or Timer 2 mode. To enable Timer 2 clocking, set the TCLK and RCLK bits which are located in the T2CON (0xC8) register.

x_clk JF_write	^	1	٨		Λ_		Λ		Λ		_/_		Λ_		Λ_		Λ_		Λ.	Λ
end F_shift			٨		٨		Λ		Л		Л		Л		٨		٨		7	
XD XD ti	_	START	Г	DO	X	D1	X	D2	χ	D3	X	D4	X	D5	X	D6	X	07	7	STOP

Figure 6.8 Timing Diagram for UART Transmission Mode1

6.4 Mode2, 9-Bit UART, Fixed Baud Rate

This mode is almost identical to Mode1 except that the baud rate is fixed at 1/32 or 1/64 of CLK clock frequency, and 11 bits are transmitted or received in the following sequence: A start bit (0), 8 data bits (LSB first), a programmable 9th bit, and a stop bit (1). The 9th bit can be used to control the parity of the UART interface. During a transmission, the TB08 bit in SCON is outputted as the 9th bit. While receiving data, the 9th bit changes the RB08 bit in SCON.

tx_clk BUF_write		8	٨		Λ		٨		Λ		Λ_		Λ		Λ		Λ		Λ		Λ_	Λ_
send UF_shift			٨		Λ.		Л		٨		٨		٨		٨		Λ		Λ		7	
RXD TXD ti	7	START	Г	DO	x	D1	r	D2	r	D3	x	D4	I	D5	χ	D6	X	D7	X	TB8	7	STOP

Figure 6.9 Timing Diagram for UART Transmission Mode2



6.5 Mode3, 9-Bit UART, Variable Baud Rate, Timer1 or 2 Clock Source

The only difference between Mode2 and Mode3 is the baud rate in Mode3 is variable. Data reception is enabled when REN = 1. The baud rate is variable and dependent on Timer 1 or Timer 2 mode. To enable Timer 2 clocking, set the TCLK and RCLK bits which are located in the T2CON (0xC8) register.

1x_clk 8UF_write	1	8	٨		Λ		٨		Λ		Λ		Λ		٨		Λ		٨		Λ	Λ_
send BUF_shift			٨		٨		٨		٨		٨		٨		٨		٨		٨		7	
RXD TXD ti	7	START	Г	DO	X	D1	r	D2	X	D3	<u>)</u>	D4	I	D5	χ	D6	X	D7	X	TB8	7	STOP

Figure 6.10 Timing Diagram for UART Transmission Mode3

6.6 Examples of Baud Rate Setting

Tabla	4 E	Evamples	of	Doud	Data	Cotting
lable	0.5	Examples	UI	Dauu	каге	setting

	Timer 1	/ Mode2	Timer 2
Baud Rate(bps)	TH1(0)x8D)	RLDH(0xCB), RLDL(0xCA)
	SMOD = '0'	SMOD = '1'	
2400	160(0xA0)	64(0x40)	64384(0XFB80)
4800	208(0xD0)	160(0xA0)	64960(0xFDC0)
9600	232(0xE8)	208(0xD0)	65248(0xFEE0)
14400	240(0xF0)	224(0xE0)	65344(0XFF40)
19200	244(0xF4)	232(0xE8)	65392(0XFF70)
28800	248(0xF8)	240(0xF0)	65440(0xFFA0)
38400	250(0xFA)	244(0xF4)	65464(0XFFB8)
57600	252(0xFC)	248(0xF8)	65488(0xFFD0)
115200	254(0xFE)	252(0xFC)	65512(0xFFE8)
230400	255(0xFF)	254(0xFE)	65524(0xFFF4)

Note: Baud Rate calculation formula

Using Timer1 - Baud Rate = ($2^{SMOD} / 32$) * (Clock Frequency / 12(256 - TH1))

Using Timer2 - Baud Rate = Clock Frequency / (32 * (65536 - (RLDH, RLDL)))



7 Watchdog Timer

7.1 Overview

The Watchdog Timer is driven by the main system clock that is supplied by a series of dividers as shown in the Figure below. The divider output is selectable and determines the timeout intervals. When the timeout is reached, an interrupt flag will be set, and if enabled, a reset will be occurred. When interrupt enable bit and global interrupt are enabled, the interrupt flag will activate the interrupts. The reset and interrupt are completely discrete functions that may be acknowledged separately, together or even ignored depending on the application.




Figure 7.1 Watchdog Timer Structure

7.2 Interrupts

Watchdog interrupt related bits are shown below. An interrupt can be turned on/off by the IE (0xA8) and EIE (0xE8) registers, and high/low priorities can be set in the EIP EIP (0xF8) register. The IE contains global interrupt system disable (0) / enable (1) bit called EA.

				IE (0xA8)			
7	6	5	4	3	2	1	0	Reset
EA	-	ET2	ES	ET1	EX1	ET0	EX0	0x00
		Fig	ure 7.2 I	nterrupt E	nable Reg	ister		
				EIE (0xE8	3)			
7	6	5	4	3	2	1	0	Reset
-	-	-	EWDI	EINT5	EINT4	EINT3	EINT2	0x00
		Figure 7	.3 Extend	ded Interru	upt Enable	e Register		
Note:	EA - E	Enable glob	oal interr	upt				
	EWDI ·	- Enable W	/atchdog	interrupt				



7	6	5	4	3	2	1	0	Reset						
-	_	-	PWDI	PINT5	PINT4	PINT3	PINT2	0x00						
	Figure 7.4 Extended interrupt Priority Register													
Note	: PWDI	- Watchd	og priority	level cor	itrol (high	level at	1)							

Unimplemented bit - Read as 0 or 1

7	6	5	4	3	2	1	0	Reset
-	-	-	-	WDIF	WTRF	EWT	RWT	0x00

Figure 7.5 Watchdog Control Register

Note: WDIF - Watchdog Interrupt Flag. WDIF in conjunction with Enable Watchd og Interrupt bit (EIE.4) and EWT, indicates if a watchdog timer e vent has occurred and what action should be taken. This bit mu st be cleared by software before exiting the interrupt service ro utine or another interrupt is generated. Setting WDIF in software will generate a watchdog interrupt if enabled. User must use 'Ti med Access Register' when clear this WDIF bit. Please refer to the section 7.8 'Timed Access' procedure.

All of the bits that generate interrupts can be set or cleared by software, with the same result by hardware. That is, interrupts can be generated or cancelled by software.

		Table 7.1 Watchdog Ir	nterrupt		
Interrupt Flag	Function	Active Level/Edge	Flag Reset	Vector	Natural Priority
WDIF	Internal,	-	Software	0x63	11
	Watchdog				

7.3 Watchdog Timer Reset

The Watchdog Timer reset operates as follows. Once the timeout interval is initialized, the system restarts the Watchdog first by using RWT. Then, the reset mode is enabled by the EWT (Enable Watchdog Timer reset = WDCON.1) bit. Before the timer reaches the user selected terminal value, the software can set the RWT (Reset Watchdog Timer = WDCON.0) bit. If RWT is set before the timeout is reached, the timer will start over. If the timeout is reached without RWT being set, the Watchdog will reset the MCU. The Hardware automatically clears RWT after sets the RWT by software. When a reset occurs, the WTRF (Watchdog Timer reset Flag = WDCON.2) will automatically set to indicate the cause of the reset; however, software must clear this bit manually.



7.4 Simple Timer

The Watchdog Timer is a free running timer. In timer mode with reset disabled (EWT = 0) and interrupt functions disabled (EWDI = 0), the timer counts up to pre-programmed interval in WD[1:0] which will enable the Watchdog interrupt flag. By resetting the RWT bit, this timer can operate in polled timeout mode. The WDIF bit can be cleared by software or reset. The Watchdog interrupt is available for application which requires a long timer. The interrupt is enabled by using the EWDI (Enable WatchDog timer Interrupt = EIE.4) bit. When a timeout occurs, the Watchdog Timer will set the WDIF bit (WDCON.3), and an interrupt will occur if the global interrupt enable (EA) is set. Note that WDIF is set to 512 clocks before a potential Watchdog reset. The Watchdog interrupt flag indicates the source of the interrupt, and must be cleared by software. When the Watchdog interrupt is used properly, the Watchdog reset allows the interrupt software to monitor the system for any errors.

7.5 System Monitor

If the EWT bit of WDCON was set, W7100A will reset when a Watchdog timeout occurs. User can use the Watchdog timer as a system monitor using this function. For example, assuming that an unexpected code was running, there is no RWT clear routine because this code is not designed by user; resulting a Watchdog timeout to occur, and the W7100A will reset. User can escape unexpected state by using this method.

7.6 Watchdog Related Registers

The Watchdog Timer has several SFR bits that are used during its operation. These bits can be utilized as a reset source, interrupt source, software polled timer or any combination of the three. Both the reset and interrupt have status flags. The Watchdog also has a bit which restarts the timer. The table below shows the bit locations with descriptions.

Bit Name	Register	Bit Position	Description
EWDI	EIE	EIE.4	Enable Watchdog Timer Interrupt
PWDI	EIP	EIP.4	Priority of Watchdog Timer Interrupt
WD[1:0]	CKCON	CKCON.7-6	Watchdog Interval
RWT	WDCON	WDCON.0	Reset Watchdog Timer
EWT		WDCON.1	Enable Watchdog Timer reset
WTRF		WDCON.2	Watchdog Timer reset flag
WDIF		WDCON.3	Watchdog Interrupt flag

Table	7.2	Summary	for	Watchdog	Related	Bits
-------	-----	---------	-----	----------	---------	------

The Watchdog Timer is not disabled during a Watchdog timeout reset, but it restarts the timer. Control bits that support Watchdog operation are described in next subsections.



7.7 Watchdog Control

Watchdog control bits are described below. Please note that access (write) to this register has to be performed using '7.8 Timed Access Registers' procedure.

WDCON (0xD8)								
7	6	5	4	3	2	1	0	Reset
-	-	-	-	WDIF	WTRF	EWT	RWT	0x00
		Figu	re 7.6	Watchdog C	Control Reg	jister		
Note:	WTRF	- Watchdo	og Time	r reset Fla	g. A Watcł	ndog Time	r reset h	as occurre
		when th	is flag	is enabled;	however,	when usir	ng softwa	re to enab
		this fla	ig, the	Watchdog t	timer reset	t is not tr	iggered.	During a r
		et, this	flag is	cleared ot	herwise it	should be	e cleared	by softwa
		The Wa	atchdog	Timer has	no effect	on this b	it if EWT	bit is cle
ed.								
EWT - Enable the Watchdog Timer reset. This bit controls the Watchdog								
Timer to reset the microcontroller, and has no effect on the abil								
ity of the Watchdog Timer to generate a Watchdog interrupt. Tim								
ed Access procedure must be used to modify this bit.								
0 : Watchdog Timer timeout does not reset microcontroller								
		1 : Wa	atchdog	Timer time	eout resets	microcor	ntroller	
	RWT	- Reset th	e Watc	hdog Timer	. Setting F	WT resets	s the Wat	chdog Tim
		count.	Timed	Access pro	cedure mu	ist be foll	owed to	enable th
		bit befo	re the	Watchdog 🗅	Timer expi	res, reset	or interr	upt will b
		generate	ed if th	e RWT is e	nabled.			
	Unim	plemented	bit - F	Read as 0 o	or 1			

The table below summarizes Watchdog control bits and the functions.

			Table 7.3 Watchdog Bits and Actions
EWT	EWDI	WDIF	Result
Х	Х	0	No Watchdog event.
0	0	1	Watchdog timeout has expired. No interrupt has been generated.
0	1	1	Watchdog interrupt has occurred.
1	0	1	Watchdog timeout has expired. No interrupt has been generated.
			Watchdog Timer reset will occur in 512 clock periods (CLK pin) if
			RWT is not strobed.
1	1	1	Watchdog interrupt has occurred. Watchdog Timer reset will
			occur in 512 clock periods (CLK pin) if RWT is not set using Timed
			Access procedure.



7.7.1 Clock Control

The Watchdog timeout selection is made using bits WD[1:0] as shown in the Figure below.

				CKCO	N (0x8E)			
7	6	5	4	3	2	1	0	Reset
W	D1 WC	- 00	-	-	MD2	MD1	MDO	0x03

Figure 7.7 Clock Control register - Watchdog bits

Clock control register CKCON(0x8E) contains WD[1:0] bits to select Watchdog Timer timeout period. The Watchdog is clocked directly from the CLK pin. The Watchdog has four timeout selections based on the input CLK clock frequency as shown in the Figure 7.1. The selections are a pre-selected number of clocks.

*W7100A clock frequency = 88.4736MHz

_		Table 7:1 Materialog	
	WD[1:0]	Watchdog Interval	Number of Clocks
	00	2 ¹⁷	131072
	01	2 ²⁰	1048576
	10	2 ²³	8388608
	11	2 ²⁶	67108864
_			

Table 7.4 Watchdog Intervals

Note that the time period shown above is for the interrupt events. When the reset is enabled, it will activate 512 clocks later regardless of the interrupt. Therefore, the actual Watchdog timeout is the number of clocks chosen from Watchdog intervals plus 512 clocks (always CLK pin).

7.8 Timed Access Registers

Since the WDCON is timed access register, user must use following procedure when set a value to WDCON. TA is an SFR addressed 0xC7.

MOV TA, #0xAA

MOV TA, #0x55

;Any direct addressing instruction writing timed access register

User always use this sequence every setting the WDCON

Table 7.5 Timed Access Registers

Register name	Description
WDCON(0xD8)	Watchdog configuration



8 TCPIPCore

8.1 Memory Map

TCPIPCore is composed of Common Register, SOCKET Register, TX Memory, and RX Memory as shown below.




Figure 8.1 TCPIPCore Memory Map

8.2 Registers list

8.2.1 Common Registers

Address offset	Symbol	Description
0xFE0000	MR	Mode Register
0xFE0001	GAR0	
0xFE0002	GAR1	GAR (Gateway Address Register)
0xFE0003	GAR2	GAR (Galeway Address Register)
0xFE0004	GAR3	
0xFE0005	SUBRO	SUBR (Subnet Mask Register)
0xFE0006	SUBR1	SUBR (SUBHEL MASK REGISTER)



		•
0xFE0007	SUBR2	
0xFE0008	SUBR3	
0xFE0009	SHAR0	
0xFE000A	SHAR1	
0xFE000B	SHAR2	
0xFE000C	SHAR3	SHAR (Source Hardware Address Register)
0xFE000D	SHAR4	
0xFE000E	SHAR5	
0xFE000F	SIPRO	
0xFE0010	SIPR1	
0xFE0011	SIPR2	- SIPR (Source IP Address Register)
0xFE0012	SIPR3	
0xFE0013		Reserved
0xFE0014		Reserved
0xFE0015	IR	Interrupt Register
0xFE0016	IMR	Interrupt Mask Register
0xFE0017	RTR0	PTD (Potransmission Timoout value Posistor)
0xFE0018	RTR1	RTR (Retransmission Timeout-value Register)
0xFE0019	RCR	RCR (Retransmission Retry-count Register)
0xFE001A		Reserved
0xFE001B		
0xFE001C	PATRO	PART (PPPoE Authentication Register)
0xFE001D	PATR1	
0xFE001E	PPPALGO	PPPoE Authentication Algorithm Register
0xFE001F	VERSIONR	W7100A Version Register
0xFE0020		
~		Reserved
0xFE0027		
0xFE0028	PTIMER	PPP Link Control Protocol Request Timer Register
0xFE0029	PMAGIC	PPP LCP Magic Number Register
0xFE002A		
~		Reserved
0xFE002F		
0xFE0030	INTLEVELO	- INTLEVEL (Interrupt Low Level Timer Register)
	INTLEVEL1	intervel (interrupt com cover finier Register)

Internet Embedded MCU W7100A Datasheet



0xFE0032		Decement
0xFE0033		Reserved
0xFE0034	IR2	SOCKET Interrupt Register

8.2.2 SOCKET Registers

	NET Register	
Address offset	Symbol	Description
0xFE4000	S0_MR	SOCKET 0 Mode Register
0xFE4001	SO_CR	SOCKET 0 Command Register
0xFE4002	S0_IR	SOCKET 0 Interrupt Register
0xFE4003	SO_SR	SOCKET 0 SOCKET Status Register
0xFE4004	S0_PORT0	S0_PORT (SOCKET 0 Source Port Register)
0xFE4005	S0_PORT1	
0xFE4006	SO_DHAR0	
0xFE4007	S0_DHAR1	
0xFE4008	S0_DHAR2	SO DUAD (SOCKET O Destination Hardware Address Desister)
0xFE4009	SO_DHAR3	S0_DHAR (SOCKET 0 Destination Hardware Address Register)
0xFE400A	SO_DHAR4	
0xFE400B	SO_DHAR5	
0xFE400C	S0_DIPR0	
0xFE400D	S0_DIPR1	S0_DIPR (SOCKET 0 Destination IP Address Register)
0xFE400E	S0_DIPR2	SU_DIFK (SUCKET U DEStination IF Address Register)
0xFE400F	SO_DIPR3	
0xFE4010	S0_DPORT0	S0_DPORT (SOCKET 0 Destination Port Register)
0xFE4011	S0_DPORT1	SO_DPORT (SOCKET & Destination Port Register)
0xFE4012	S0_MSSR0	S0_MSSR (SOCKET 0 Maximum Segment Size Register)
0xFE4013	S0_MSSR1	SO_MSSR (SOCKET O Maximum segment size Register)
0xFE4014	S0_PROTO	SOCKET 0 Protocol of IP Header Field Register in IP raw
0X1 24014	30_FR010	mode
0xFE4015	S0_TOS	SOCKET 0 IP Type of Service(TOS) Register
0xFE4016	S0_TTL	SOCKET 0 IP Time to Live(TTL) Register
0xFE4017 ~ 0xFE401D		Reserved

Internet Embedded MCU W7100A Datasheet

74

0xFE401E	SO_RXMEM_SIZE	SOCKET 0 Receive Memory Size Register
0xFE401E	SO_TXMEM_SIZE	SOCKET 0 Transmit Memory Size Register
0xFE401F 0xFE4020	S0_TXIVIEIVI_SIZE	SOCKET O TRANSITIC METHOLY SIZE REGISTER
0xFE4020 0xFE4021	S0_TX_FSR0	S0_TX_FSR (SOCKET 0 Transmit Free Memory Size Register)
0xFE4021 0xFE4022	S0_TX_F3RT	S0_TX_RD0
0xFE4022 0xFE4023	S0_TX_RD0	(SOCKET 0 Transmit Memory Read Pointer Register)
0xFE4023	S0_TX_WR0	
0xFE4024	S0_TX_WR0	S0_TX_WR (SOCKET 0 Transmit Memory Write Pointer Register)
0xFE4025		
0xFE4020	SO_RX_RSR0	S0_RX_RSR (SOCKET 0 Received Data Size Register)
	SO_RX_RSR1	-
0xFE4028	SO_RX_RD	SO_RX_RD
0xFE4029	SO_RX_RD1	(SOCKET 0 Receive Memory Read Pointer Register)
0xFE402A	SO_RX_WR	SO_RX_WR
0xFE402B	SO_RX_WR1	(SOCKET 0 Receive Memory Write Pointer Register)
0xFE402C	SO_IMR	SOCKET 0 Interrupt Mask Register
0xFE402D	S0_FRAG0	SO_FRAG
0xFE402E	S0_FRAG1	(SOCKET 0 Fragment Field Value in IP Header Register)
0xFE402F		
UXFE402F		Reserved
0xFE40FF		iteserveu
0xFE4100	S1_MR	SOCKET 1 Mode Register
0xFE4101	S1_CR	SOCKET 1 Command Register
0xFE4102	S1_IR	SOCKET 1 Interrupt Register
0xFE4103	S1_SR	SOCKET 1 SOCKET Status Register
0xFE4104	S1_PORT0	S1_DODT (SOCKET 1 Source Dort Degister)
0xFE4105	S1_PORT1	S1_PORT (SOCKET 1 Source Port Register)
0xFE4106	S1_DHAR0	
0xFE4107	S1_DHAR1	
0xFE4108	S1_DHAR2	
0xFE4109	S1_DHAR3	S1_DHAR (SOCKET 1 Destination Hardware Address Register)
0xFE410A	S1_DHAR4	
0xFE410B	S1_DHAR5	
0xFE410C	S1_DIPR0	
0xFE410D	S1_DIPR1	S1_DIPR (SOCKET 1 Destination IP Address Register)
	1	



0xFE410E	S1_DIPR2	
0xFE410F	S1_DIPR3	
0xFE4110	S1_DPORT0	
0xFE4111	S1_DPORT1	S1_DPORT (SOCKET 1 Destination Port Register)
0xFE4112		
0xFE4113		S1_MSSR (SOCKET 1 Maximum Segment Size Register)
0xFE4114	S1_PROTO	SOCKET 1 Protocol of IP Header Field Register in IP raw mode
0xFE4115	S1_TOS	SOCKET 1 IP Type of Service(TOS) Register
0xFE4116	S1_TTL	SOCKET 1 IP Time to Live(TTL) Register
0xFE4117		
~		Reserved
0xFE411D		
0xFE411E	S1_RXMEM_SIZE	SOCKET 1 Receive Memory Size Register
0xFE411F	S1_TXMEM_SIZE	SOCKET 1 Transmit Memory Size Register
0xFE4120	S1_TX_FSR0	S1_TX_FSR (SOCKET 1 Transmit Free Memory Size Register)
0xFE4121	S1_TX_FSR1	ST_TA_TSR (SOCKET T Transmit Tree Memory Size Register)
0xFE4122	S1_TX_RD0	S1_TX_RD
0xFE4123	S1_TX_RD1	(SOCKET 1 Transmit Memory Read Pointer Register)
0xFE4124	S1_TX_WR0	S1_TX_WR
0xFE4125	S1_TX_WR1	(SOCKET 1 Transmit Memory Write Pointer Register)
0xFE4126	S1_RX_RSR0	S1_RX_RSR
0xFE4127	S1_RX_RSR1	(SOCKET 1 Received Data Size Register)
0xFE4128	S1_RX_RD0	S1_RX_RD
0xFE4129	S1_RX_RD1	(SOCKET 1 Receive Memory Read Pointer Register)
0xFE412A	S1_RX_WR0	S1_RX_WR (SOCKET 1 Receive Memory Write Pointer
0xFE412B	S1_RX_WR1	Register)
0xFE412C	S1_IMR	SOCKET 1 Interrupt Mask Register
0xFE412D	S1_FRAG0	S1_FRAG
0xFE412E	S1_FRAG1	(SOCKET 1 Fragment Field Value in IP Header Register)
0xFE412F		
~		Reserved
0xFE41FF		
0xFE4200	S2_MR	SOCKET 2 Mode Register
0xFE4201	S2_CR	SOCKET 2 Command Register
0xFE4202	S2_IR	SOCKET 2 Interrupt Register



0xFE4203	S2_SR	SOCKET 2 SOCKET Status Register
0xFE4204	S2_PORT0	
0xFE4205	S2_PORT1	S2_PORT (SOCKET 2 Source Port Register)
0xFE4206	S2_DHAR0	
0xFE4207	S2_DHAR1	
0xFE4208	S2_DHAR2	
0xFE4209	S2_DHAR3	S2_DHAR (SOCKET 2 Destination Hardware Address Register)
0xFE420A	S2_DHAR4	
0xFE420B	S2_DHAR5	
0xFE420C	S2_DIPR0	
0xFE420D	S2_DIPR1	
0xFE420E	S2_DIPR2	S2_DIPR (SOCKET 2 Destination IP Address Register)
0xFE420F	S2_DIPR3	
0xFE4210	S2_DPORT0	S2 DDODT (SOCKET 2 Destination Dart Desister)
0xFE4211	S2_DPORT1	S2_DPORT (SOCKET 2 Destination Port Register)
0xFE4212	S2_MSSR0	S2_MSSR (SOCKET 2 Maximum Segment Size Register)
0xFE4213	S2_MSSR1	SZ_MSSR (SOCKET Z MAXIMUM Segment Size Register)
0xFE4214	S2_PROTO0	S2_PROTO (SOCKET 2 Protocol of IP Header Field Register in
0XFE4214	S2_PROTO1	IP raw mode)
0xFE4215	S2_TOS	SOCKET 2 IP Type of Service(TOS) Register
0xFE4216	S2_TTL	SOCKET 2 IP Time to Live(TTL) Register
0xFE4217 ~ 0xFE421D		Reserved
0xFE421E	S2_RXMEM_SIZE	SOCKET 2 Receive Memory Size Register
0xFE421E	S2_TXMEM_SIZE	SOCKET 2 Transmit Memory Size Register
0xFE4220	S2_TX_FSR0	
0xFE4221	S2_TX_FSR1	S2_TX_FSR (SOCKET 2 Transmit Free Memory Size Register)
0xFE4222	S2_TX_RD0	S2_TX_RD
0xFE4223	S2_TX_RD1	(SOCKET 2 Transmit Memory Read Pointer Register)
0xFE4224	S2_TX_WR0	S2_TX_WR
0xFE4225	S2_TX_WR1	(SOCKET 2 Transmit Memory Write Pointer Register)
0xFE4226	S2_RX_RSR0	S2 DV DSD (SOCKET 2 Descined Data Size Devictor)
0xFE4227	S2_RX_RSR1	S2_RX_RSR (SOCKET 2 Received Data Size Register)



1		
0xFE4228	S2_RX_RD0	S2_RX_RD
0xFE4229	S2_RX_RD1	(SOCKET 2 Receive Memory Read Pointer Register)
0xFE422A	S2_RX_WR0	S2_RX_WR
0xFE422B	S2_RX_WR1	(SOCKET 2 Receive Memory Write Pointer Register)
0xFE422C	S2_IMR	SOCKET 2 Interrupt Mask Register
0xFE422D	S2_FRAG0	SOCKET 2 Fragment Field Value in IP Header Register
0xFE422E	S2_FRAG1	
0xFE422F ~ 0xFE42FF		Reserved
0xFE4300	S3_MR	SOCKET 3 Mode Register
0xFE4301	S3_CR	SOCKET 3 Command Register
0xFE4302	S3_IR	SOCKET 3 Interrupt Register
0xFE4303	S3_SR	SOCKET 3 SOCKET Status Register
0xFE4304	S3_PORT0	S3_PORT (SOCKET 3 Source Port Register)
0xFE4305	S3_PORT1	35_PORT (SOCKET S Source Port Register)
0xFE4306	S3_DHAR0	
0xFE4307	S3_DHAR1	
0xFE4308	S3_DHAR2	S3_DHAR (SOCKET 3 Destination Hardware Address Register)
0xFE4309	S3_DHAR3	
0xFE430A	S3_DHAR4	S3_DHAR (SOCKET 3 Destination Hardware Address Register)
0xFE430B	S3_DHAR5	
0xFE430C	S3_DIPR0	
0xFE430D	S3_DIPR1	S2 DIDD (SOCKET 2 Destinction ID Address Desister)
0xFE430E	S3_DIPR2	S3_DIPR (SOCKET 3 Destination IP Address Register)
0xFE430F	S3_DIPR3]
0xFE4310	S3_DPORT0	S2 DDODT (SOCKET 2 Destination Port Desister)
0xFE4311	S3_DPORT1	S3_DPORT (SOCKET 3 Destination Port Register)
0xFE4312	S3_MSSR0	S2 MSSD (SOCKET 2 Maximum Segment Size Degister)
0xFE4313	S3_MSSR1	S3_MSSR (SOCKET 3 Maximum Segment Size Register)
0xFE4314	S3_PROTO	SOCKET 3 Protocol of IP Header Field Register in IP raw mode
0xFE4315	S3_TOS	SOCKET 3 IP Type of Service(TOS) Register



0xFE4316	SO_TTL	SOCKET 3 IP Time to Live(TTL) Register
0xFE4317		
~		Reserved
0xFE431D		
0xFE431E	S3_RXMEM_SIZE	SOCKET 3 Receive Memory Size Register
0xFE431F	S3_TXMEM_SIZE	SOCKET 3 Transmit Memory Size Register
0xFE4320	S3_TX_FSR0	S3_TX_FSR (SOCKET 3 Transmit Free Memory Size Register)
0xFE4321	S3_TX_FSR1	35_TX_13K (SOCKET 3 Transmit Tree Memory Size Register)
0xFE4322	S3_TX_RD0	S3_TX_RD
0xFE4323	S3_TX_RD1	(SOCKET 3 Transmit Memory Read Pointer Register)
0xFE4324	S3_TX_WR0	S3_TX_WR
0xFE4325	S3_TX_WR1	(SOCKET 3 Transmit Memory Write Pointer Register)
0xFE4326	S3_RX_RSR0	S3_RX_RSR (SOCKET 3 Received Data Size Register)
0xFE4327	S3_RX_RSR1	35_NA_NSN (SOCKET S NECENVER Data SIZE REGISTER)
0xFE4328	S3_RX_RD0	S3_RX_RD
0xFE4329	S3_RX_RD1	(SOCKET 3 Receive Memory Read Pointer Register)
0xFE432A	S3_RX_WR0	S3_RX_WR
0xFE432B	S3_RX_WR1	(SOCKET 3 Receive Memory Write Pointer Register)
0xFE432C	S3_IMR	SOCKET 3 Interrupt Mask Register
0xFE432D	S3_FRAG0	SOCKET 3 Fragment Field Value in IP Header Register
0xFE432E	S3_FRAG1	Socker 5 Hagment Heid Valde in in Header Register
0xFE432F		
~		Reserved
0xFE43FF		
0xFE4400	S4_MR	SOCKET 4 Mode Register
0xFE4401	S4_CR	SOCKET 4 Command Register
0xFE4402	S4_IR	SOCKET 4 Interrupt Register
0xFE4403	S4_SR	SOCKET 4 SOCKET Status Register
0xFE4404	S4_PORT0	
0xFE4405	S4_PORT1	S4_PORT (SOCKET 4 Source Port Register)
0xFE4406	S4_DHAR0	
0xFE4407	S4_DHAR1	
0xFE4408	S4_DHAR2	S4_DHAR (SOCKET 4 Destination Hardware Address Register)
0xFE4409	S4_DHAR3	
0xFE440A	S4_DHAR4	

Internet Embedded MCU W7100A Datasheet



0xFE440B	S4_DHAR5	
0xFE440C	S4_DIPR0	
0xFE440D	S4_DIPR1	S4_DIPR (SOCKET 4 Destination IP Address Register)
0xFE440E	S4_DIPR2	54_DIFK (SOCKET 4 Destination if Address Register)
0xFE440F	S4_DIPR3	
0xFE4410	S4_DPORT0	S4_DPORT (SOCKET 4 Destination Port Register)
0xFE4411	S4_DPORT1	34_DPORT (SOCKET 4 Destination Port Register)
0xFE4412	S4_MSSR0	S4 MSSD (SOCKET 4 Maximum Sagmant Size Degister)
0xFE4413	S4_MSSR1	S4_MSSR (SOCKET 4 Maximum Segment Size Register)
0xFE4414	S4_PROTO	SOCKET 4 Protocol of IP Header Field Register in IP raw mode
0xFE4415	S4_TOS	SOCKET 4 IP Type of Service(TOS) Register
0xFE4416	S4_TTL	SOCKET 4 IP Time to Live(TTL) Register
0xFE4417		
~		Reserved
0xFE441D		
0xFE441E	S4_RXMEM_SIZE	SOCKET 4 Receive Memory Size Register
0xFE441F	S4_TXMEM_SIZE	SOCKET 4 Transmit Memory Size Register
0xFE4420	S4_TX_FSR0	S4_TX_FSR (SOCKET 4 Transmit Free Memory Size Register)
0xFE4421	S4_TX_FSR1	34_TA_I SK (SOCKET 4 Transmit Tree Memory Size Register)
0xFE4422	S4_TX_RD0	S4_TX_RD
0xFE4423	S4_TX_RD1	(SOCKET 4 Transmit Memory Read Pointer Register)
0xFE4424	S4_TX_WR0	S4_TX_WR
0xFE4425	S4_TX_WR1	(SOCKET 4 Transmit Memory Write Pointer Register)
0xFE4426	S4_RX_RSR0	SA DY DSD (SOCKET A Dessived Data Size Degister)
0xFE4427	S4_RX_RSR1	S4_RX_RSR (SOCKET 4 Received Data Size Register)
0xFE4428	S4_RX_RD0	S4_RX_RD
0xFE4429	S4_RX_RD1	(SOCKET 4 Receive Memory Read Pointer Register)
0xFE442A	S4_RX_WR0	S4_RX_WR
0xFE442B	S4_RX_WR1	(SOCKET 4 Receive Memory Write Pointer Register)
0xFE442C	S4_IMR	SOCKET 4 Interrupt Mask Register
0xFE442D	S4_FRAG0	SOCKET 4 Fragment Field Value in IP Header Register
0xFE442E	S4_FRAG1	SOUND A FLAGHIER FIELD VALUE IN IF FIELDUEL REGISTER



OxFE442F ~ OxFE44FF		Reserved
0xFE4500	S5_MR	SOCKET 5 Mode Register
0xFE4501	S5_CR	SOCKET 5 Command Register
0xFE4502	S5_IR	SOCKET 5 Interrupt Register
0xFE4503	S5_SR	SOCKET 5 SOCKET Status Register
0xFE4504	S5_PORT0	S5_PORT (SOCKET 5 Source Port Register)
0xFE4505	S5_PORT1	
0xFE4506	S5_DHAR0	
0xFE4507	S5_DHAR1	
0xFE4508	S5_DHAR2	S5_DHAR (SOCKET 5 Destination Hardware Address Register)
0xFE4509	S5_DHAR3	SS_DHAR (SOCKET S DESCINATION HAR WARE AUDRESS REGISTER)
0xFE450A	S5_DHAR4	
0xFE450B	S5_DHAR5	
0xFE450C	S5_DIPR0	
0xFE450D	S5_DIPR1	S5_DIPR (SOCKET 5 Destination IP Address Register)
0xFE450E	S5_DIPR2	S5_DIPR (SOCKET 5 Destination IP Address Register)
0xFE450F	S5_DIPR3	35_DIFK (SOCKET 5 Destination if Address Register)
0xFE4510	S5_DPORT0	S5_DPORT (SOCKET 5 Destination Port Register)
0xFE4511	S5_DPORT1	35_DFORT (SOCKET 5 Destination Fort Register)
0xFE4512	S5_MSSR0	S5_MSSR (SOCKET 5 Maximum Segment Size Register)
0xFE4513	S5_MSSR1	SS_MOOK (SOOKET S MAXIMAIN SEGMENT SIZE REgister)
0xFE4514	S5_PROTO	SOCKET 5 Protocol of IP Header Field Register in IP raw mode
0xFE4515	S5_TOS	SOCKET 5 IP Type of Service(TOS) Register
0xFE4516	S5_TTL	SOCKET 5 IP Time to Live(TTL) Register
0xFE4517		
~		Reserved
0xFE451D		
0xFE451E	S5_RXMEM_SIZE	SOCKET 5 Receive Memory Size Register
0xFE451F	S5_TXMEM_SIZE	SOCKET 5 Transmit Memory Size Register
0xFE4520	S5_TX_FSR0	S5_TX_FSR (SOCKET 5 Transmit Free Memory Size Register)
0xFE4521	S5_TX_FSR1	



S5_TX_RD0	S5_TX_RD
S5_TX_RD1	(SOCKET 5 Transmit Memory Read Pointer Register)
S5_TX_WR0	S5_TX_WR
S5_TX_WR1	(SOCKET 5 Transmit Memory Write Pointer Register)
S5_RX_RSR0	S5_RX_RSR (SOCKET 5 Received Data Size Register)
S5_RX_RSR1	
S5_RX_RD0	S5_RX_RD
S5_RX_RD1	(SOCKET 5 Receive Memory Read Pointer Register)
S5_RX_WR0	S5_RX_WR
S5_RX_WR1	(SOCKET 5 Receive Memory Write Pointer Register)
S5_IMR	SOCKET 5 Interrupt Mask Register
S5_FRAG0	S5_FRAG
S5_FRAG1	(SOCKET 5 Fragment Field Value in IP Header Register)
	Reserved
S6_MR	SOCKET 6 Mode Register
S6_CR	SOCKET 6 Command Register
S6_IR	SOCKET 6 Interrupt Register
S6_SR	SOCKET 6 SOCKET Status Register
S6_PORT0	S6 DODT (SOCKET 6 Source Dart Degister)
S6_PORT1	S6_PORT (SOCKET 6 Source Port Register)
S6_DHAR0	
S6_DHAR1]
S6_DHAR2	1
S6_DHAR3	S6_DHAR (SOCKET 6 Destination Hardware Address Register)
S6_DHAR4	1
S6_DHAR5	1
S6_DIPR0	
S6_DIPR1	
	S6_DIPR (SOCKET 6 Destination IP Address Register)
JU_DIFKZ	
S6_DIPR2	
	S5_TX_RD1 S5_TX_WR0 S5_TX_WR1 S5_RX_RSR0 S5_RX_RSR1 S5_RX_RD1 S5_RX_RD1 S5_RX_WR0 S5_RX_WR0 S5_RX_WR1 S5_RX_WR1 S5_RX_WR1 S5_RX_WR1 S5_RX_WR1 S5_RX_WR1 S5_RAG1 S5_FRAG1 S5_FRAG1 S6_R S6_CR S6_R S6_S6_R S6_S6_R S6_PORT0 S6_PORT1 S6_DHAR1 S6_DHAR2 S6_DHAR3 S6_DHAR4 S6_DHAR5

82



0xFE4611	S6_DPORT1	
0xFE4611 0xFE4612	S6_MSSR0	
		S6_MSSR (SOCKET 6 Maximum Segment Size Register)
0xFE4613	S6_MSSR1	
0xFE4614	S6_PROTO	SOCKET 6 Protocol of IP Header Field Register in IP raw
		mode
0xFE4615	S6_TOS	SOCKET 6 IP Type of Service(TOS) Register
0xFE4616	S6_TTL	SOCKET 6 IP Time to Live(TTL) Register
0.4554/17		
0xFE4617		Descrived
~ 0xFE461D		Reserved
UXFE401D		
0xFE461E	S6_RXMEM_SIZE	SOCKET 6 Receive Memory Size Register
0xFE461F	S6_TXMEM_SIZE	SOCKET 6 Transmit Memory Size Register
0xFE4620	S6_TX_FSR0	
0xFE4621	S6_TX_FSR1	S6_TX_FSR (SOCKET 6 Transmit Free Memory Size Register)
0xFE4622	S6_TX_RD0	S6_TX_RD
0xFE4623	S6_TX_RD1	(SOCKET 6 Transmit Memory Read Pointer Register)
0xFE4624	S6_TX_WR0	S6_TX_WR
0xFE4625	S6_TX_WR1	(SOCKET 6 Transmit Memory Write Pointer Register)
0xFE4626	S6_RX_RSR0	S6_RX_RSR (SOCKET 6 Received Data Size Register)
0xFE4627	S6_RX_RSR1	SU_KA_KSK (SUCKET U RECEIVED Data Size Register)
0xFE4628	S6_RX_RD0	S6_RX_RD
0xFE4629	S6_RX_RD1	(SOCKET 6 Receive Memory Read Pointer Register)
0xFE462A	S6_RX_WR0	S6_RX_WR
0xFE462B	S6_RX_WR1	(SOCKET 6 Receive Memory Write Pointer Register)
0xFE462C	S6_IMR	SOCKET 6 Interrupt Mask Register
0xFE462D	S6_FRAG0	S6_FRAG
0xFE462E	S6_FRAG1	(SOCKET 6 Fragment Field Value in IP Header Register)
0xFE462F		
~		Reserved
0xFE46FF		
0xFE4700	S7_MR	SOCKET 7 Mode Register
0xFE4701	S7_CR	SOCKET 7 Command Register

Internet
Embedded
MCU
W7100A
Datasheet



0xFE4702	S7_IR	SOCKET 7 Interrupt Register		
0xFE4703	S7_SR	SOCKET 7 SOCKET Status Register		
0xFE4704	S7_PORT0	S7_PORT (SOCKET 7 Source Port Register)		
0xFE4705	S7_PORT1			
0xFE4706	S7_DHAR0			
0xFE4707	S7_DHAR1			
0xFE4708	S7_DHAR2			
0xFE4709	S7_DHAR3	S7_DHAR (SOCKET 7 Destination Hardware Address Register)		
0xFE470A	S7_DHAR4			
0xFE470B	S7_DHAR5			
0xFE470C	S7_DIPR0			
0xFE470D	S7_DIPR1	CZ DIDD (COCI/CT Z Destinction ID Address Desister)		
0xFE470E	S7_DIPR2	S7_DIPR (SOCKET 7 Destination IP Address Register)		
0xFE470F	S7_DIPR3			
0xFE4710	S7_DPORT0	S7 DDODT (SOCKET 7 Destination Dart Degister)		
0xFE4711	S7_DPORT1	S7_DPORT (SOCKET 7 Destination Port Register)		
0xFE4712	S7_MSSR0	S7_MSSR (SOCKET 7 Maximum Segment Size Register)		
0xFE4713	S7_MSSR1	37_M33K (300KET 7 Maximum Segment Size Register)		
0xFE4714	S0_PROTO	SOCKET 7 Protocol of IP Header Field Register in IP raw mode		
0xFE4715	S7_TOS	SOCKET 7 IP Type of Service(TOS) Register		
0xFE4716	S7_TTL	SOCKET 7 IP Time to Live(TTL) Register		
0xFE4717				
~		Reserved		
0xFE471D				
0xFE471E	S7_RXMEM_SIZE	SOCKET 7 Receive Memory Size Register		
0xFE471F	S7_TXMEM_SIZE	SOCKET 7 Transmit Memory Size Register		
0xFE4720	S7_TX_FSR0	S7_TX_FSR (SOCKET 7 Transmit Free Memory Size Register)		
0xFE4721	S7_TX_FSR1			
0xFE4722	S7_TX_RD0	S7_TX_RD		
0xFE4723	S7_TX_RD1	(SOCKET 7 Transmit Memory Read Pointer Register)		
0xFE4724	S7_TX_WR0	S7_TX_WR		
0xFE4725	S7_TX_WR1	(SOCKET 7 Transmit Memory Write Pointer Register)		
0xFE4726	S7_RX_RSR0	S7_RX_RSR (SOCKET 7 Received Data Size Register)		
0xFE4727	S7_RX_RSR1			



0xFE4728	S7_RX_RD0	S7_RX_RD
0xFE4729	S7_RX_RD1	(SOCKET 7 Receive Memory Read Pointer Register)
0xFE472A	S7_RX_WR0	S7_RX_WR
0xFE472B	S7_RX_WR1	(SOCKET 7 Receive Memory Write Pointer Register)
0xFE472C	S7_IMR	SOCKET 7 Interrupt Mask Register
0xFE472D	S7_FRAG0	S7_FRAG
0xFE472E	S7_FRAG1	(SOCKET 7 Fragment Field Value in IP Header Register)
0xFE472F		
~		Reserved
0xFE47FF		

8.3 Register Description

8.3.1 Mode Register

MR (Mode Register) [R/W] [0xFE0000] [0x00]

This register is used for S/W reset, ping block mode and PPPoE mode.

7	6	5	4	3	2	1	0
RST			РВ	PPPoE			

Bit	Symbol	Description
		S/W Reset
7	RST	If this bit is '1', internal register will be initialized. It will be automatically
		cleared after reset.
6	Reserved	Reserved
5	Reserved	Reserved
		Ping Block Mode
4	PB	0 : Disable Ping block
4	FD	1 : Enable Ping block
		If the bit is set as '1', there is no response to the ping request.
		PPPoE Mode
		0 : Disable PPPoE mode
3	PPPoF	1 : Enable PPPoE mode
5	FFFUL	If a user uses ADSL without router or etc, the bit should be set as '1' to
		connect to ADSL Server. For more detail, refer to the application note,
		"How to connect ADSL".
2	Reserved	Reserved
1	Reserved	Reserved
0	Reserved	Reserved



GAR (Gateway IP Address Register) [R/W] [0xFE0001 - 0xFE0004] [0x00]

This Register sets up the default gateway address.

Ex) In case of "192.168.0.1"

0xFE0001	0xFE0002	0xFE0003	0xFE0004
192 (0xC0)	168 (0xA8)	0 (0x00)	1 (0x01)

SUBR (Subnet Mask Register) [R/W] [0xFE0005 - 0xFE0008] [0x00]

This register sets up the subnet mask address.

Ex) In case of "255.255.255.0"

0xFE0005	0xFE0006	0xFE0007	0xFE0008
255 (0xFF)	255 (0xFF)	255 (0xFF)	0 (0x00)

SHAR (Source Hardware Address Register) [R/W] [0xFE0009 - 0xFE000E] [0x00]

This register sets up the Source Hardware address.

Ex) In case of "00.08.DC.01.02.03"

0xFE0009	0xFE000A	0xFE000B	0xFE000C	0xFE000D	0xFE000E
0x00	0x08	0xDC	0x01	0x02	0x03

SIPR (Source IP Address Register) [R/W] [0xFE000F - 0xFE0012] [0x00]

This register sets up the Source IP address.

Ex) In case of "192.168.0.2"

0xFE000F	0xFE0010	0xFE0011	0xFE0012
192 (0xC0)	168 (0xA8)	0 (0x00)	2 (0x02)

IR (Interrupt Register) [R] [0xFE0015] [0x00]

This register is accessed by the MCU of W7100A to determine the cause of an interrupt. As long as any IR bit is set, the INT5(nINT5: TCPIPcore interrupt) signal is asserted low, and it will not go high until all bits is cleared in the **Interrupt Register**.

7	6	5	4	3	2	1	0
CONFLICT	UNREACH	PPPoE	Reserved	Reserved	Reserved	Reserved	Reserved

Bit	Symbol	Description
		IP Conflict
7	CONFLICT	When the ARP request has the same IP address as the Source IP address,
		this bit is set as '1'. It can be cleared to '0' by writing '1' to this bit.
4	UNREACH	Destination unreachable
6	UNKEACH	W7100A will receive ICMP(Destination Unreachable) packet if non-existing



		destination IP address is transmitted during a UDP data transmission. The
		UNREACH bit will be set as '1'. This bit can be cleared to '0' by writing '1'
		to this bit.
		PPPoE Connection Close
5	PPPoE	In the PPPoE Mode, '1' is set if the PPPoE connection is closed. This bit can
		be cleared to '0' by writing '1' to this bit.
4	Reserved	Reserved
3	Reserved	Reserved
2	Reserved	Reserved
1	Reserved	Reserved
0	Reserved	Reserved

IMR (Interrupt Mask Register) [R/W] [0xFE0016] [0x00]

The Interrupt Mask Register is used for masking interrupts. Each interrupt mask bit corresponds to a bit in the Interrupt Register2 (IR2). If an interrupt mask bit is set, an interrupt will be issued whenever the corresponding bit in the IR2 is set. If the bit of IMR is set as '0', corresponding interrupt will not be triggered by the enabled bit in the IR2.

7	6	5	4	3	2	1	0
S7_INT	S6_INT	S5_INT	S4_INT	S3_INT	S2_INT	S1_INT	SO_INT

Bit	Symbol	Description
7	S7_INT	IR(S7_INT) Interrupt Mask
6	S6_INT	IR(S6_INT) Interrupt Mask
5	S5_INT	IR(S5_INT) Interrupt Mask
4	S4_INT	IR(S4_INT) Interrupt Mask
3	S3_INT	IR(S3_INT) Interrupt Mask
2	S2_INT	IR(S2_INT) Interrupt Mask
1	S1_INT	IR(S1_INT) Interrupt Mask
0	SO_INT	IR(S0_INT) Interrupt Mask

RTR (Retry Time-period Register) [R/W] [0xFE0017 - 0xFE0018] [0x07D0]

This register sets the period of timeout. Value 1 means 100us. The default timeout is 200ms which has a value of 2000 (0x07D0).

Ex) For	400ms	configuration,	set	as	4000(0x0FA0)
---------	-------	----------------	-----	----	--------------

0xFE0017	0xFE0018
0x0F	0xA0

Re-transmission will occur if there is no response or response is delayed from the remote



peer.

RCR (Retry Count Register) [R/W] [0xFE0019] [0x08]

This register sets the number of re-transmission. If retransmission occurs more than the number of retries recorded in RCR, a Timeout Interrupt will occur. (TIMEOUT bit of SOCKET n Interrupt Register (Sn_IR) is set as '1')

In TCP communication, the value of Sn_SR is changed to 'SOCK_CLOSED' at the same time with Sn_IR(TIMEOUT) = '1'. Not in TCP communication, only Sn_IR(TIMEOUT) = '1'.

The timeout of W7100A can be configurable with RTR and RCR. W7100A's timeout has ARP and TCP retransmission timeout.

At the ARP(Refer to RFC 826, <u>http://www.ietf.org/rfc.html</u>) retransmission timeout, W7100A automatically sends ARP-request to the peer's IP address in order to acquire MAC address information (used for communication of IP, UDP, or TCP). As waiting for ARP-response from the peer, if there is no response during the time set in RTR, timeout occurs and ARP-request is re-transmitted. It is repeated as many as 'RCR + 1' times.

Even after ARP-request retransmissions are repeated 'RCR + 1' times, if there is no ARP-response, the final timeout occurs and Sn_IR(TIMEOUT) becomes '1'.

The value of final timeout (ARP_{TO}) of ARP-request is as below.

$ARP_{TO} = (RTR X 0.1ms) X (RCR + 1)$

During the TCP packet retransmission timeout, W7100A transmits TCP packets (SYN, FIN, RST, DATA packets) and waits for the acknowledgement (ACK) during the time set in RTR and RCR. If there is no ACK from the peer, timeout occurs and TCP packets (sent earlier) are retransmitted. The retransmissions are repeated as many as 'RCR + 1' times. Even after TCP packet retransmissions are repeated 'RCR +1' times, if there is no ACK from the peer, final timeout occurs and Sn_SSR is changed to 'SOCK_CLOSED" at the same time with Sn_IR(TIMEOUT) = '1'

The value of final timeout (TCP_{TO}) of TCP packet retransmission can be calculated as below,

 $TCP_{TO} = \left(\begin{array}{c} M \\ \Sigma(RTR X 2^{N}) + ((RCR-M) X RTR_{MAX}) \end{array}\right) X 0.1ms$ $N \quad : \quad \text{Retransmission count}, \quad 0 \le N \le M$ $M \quad : \quad \text{Minimum value when RTR X 2}^{(M+1)} > 65535 \text{ and } 0 \le M \le RCR$ $RTR_{MAX} : \quad \text{RTR X 2}^{M}$

Ex) When RTR = 2000(0x07D0), RCR = 8(0x0008), ARP_{TO} = 2000 X 0.1ms X 9 = 1800ms = 1.8s



TCP_{TO} = (0x07D0 + 0x0FA0 + 0x1F40 + 0x3E80 + 0x7D00 + 0xFA00 + 0xFA00 + 0xFA00 + 0xFA00) X 0.1ms

= (2000 + 4000 + 8000 + 16000 + 32000 + ((8 - 4) X 64000)) X 0.1ms

= 318000 X 0.1ms = 31.8s

PATR (Authentication Type in PPPoE mode) [R] [0xFE001C-0xFE001D] [0x0000]

This register notifies the type of authentication used to establish the PPPoE connection. W7100A supports two types of Authentication method - PAP and CHAP.

Value	Authentication Type			
0xC023	PAP			
0xC223	СНАР			

PPPALGO (Authentication Algorithm in PPPoE mode)[R][0xFE001E][0x00]

This register notifies the authentication algorithm used for the PPPoE connection. For detail information, please refer to PPPoE application note.

PTIMER (PPP Link Control Protocol Request Timer Register) [R/W] [0xFE0028] [0x28]

This register indicates the duration of LCP Echo Request being sent. Value 1 is about 25ms.

Ex) in case that PTIMER is 200,

200 * 25(ms) = 5000(ms) = 5 seconds

PMAGIC (PPP Link Control Protocol Magic number Register) [R/W] [0xFE0029][0x00]

This register is used in the Magic number option during LCP negotiation. Refer to the application note of W5100, "How to connect ADSL".

VERSIONR (W7100A Chip Version Register)[R][0xFE001F][0x02]


This register is W7100A chip version register.

INTLEVEL (Interrupt Low Level Timer Register)[R/W][0xFE0030 - 0xFE0031][0x0000]

The INTLEVEL register sets the Interrupt Assert wait time(I_{AWT}). It configures internal INT5 signal Low Assert waiting time until next interrupt. If user wants to use TCP/IP Core interrupt, INTLEVEL register must be set higher than 0x2B00. Or the TCP/IP Core interrupt can be ignored.

I_{AWT} = (INTLEVEL0 + 1) * PLL_CLK (when INTLEVEL0 > 0)

WIZnet



- a. At the socket 0, assume an interrupt occurs (S0_IR(3) = '1') and corresponding IR2 bit is set as '1' (IR(S0_IR) = '1'). Then the internal INT5 signal is asserted low.
- b. Also assume an interrupt continually occurs (S1_IR(0) = '1') on the socket1 and corresponding IR bit set as '1' (IR(S1_IR) = '1').
- c. When the Host clears S0_IR(S0_IR = 0x00), the corresponding IR2 bit is also cleared (IR(S0_IR) = '0'). Internal INT5 signal will be de-asserted high(deactivated) from low(activated).
- d. When the S1_IR is cleared, but the corresponding IR2 is not 0x00 because of socket1 interrupt, internal INT5 signal should be asserted low.

However, as INTLEVEL is 0x000F, the internal INT5 signal is asserted after the I_{AWT} (16 PLL_CLK) time.

IR2 (W7100A SOCKET Interrupt Register)[R/W][0xFE0034][0x00]

IR2 is a Register which notifies the host that a W7100A SOCKET interrupt has occurred. When an interrupt occurs, the related bit in IR2 is enabled. In this case, the INT5 (nINT5: TCPIPcore interrupt) signal is asserted low until all of the bits of IR2 is '0'. Once the IR2 register is cleared out by using the Sn_IR bits, the INT5 signal is asserted high.

7	6	5	4	3	2	1	0
S7_INT	S6_INT	S5_INT	S4_INT	S3_INT	S2_INT	S1_INT	SO_INT

Bit	Symbol	Description
		Occurrence of SOCKET 7 Interrupt
7		When an interrupt occurs at SOCKET 7, it becomes '1'. This interrupt
	S7_INT	information is applied to S7_IR. This bit is automatically cleared when
		S7_IR is cleared to 0x00 by host.
4	C4 INT	Occurrence of SOCKET 6 Interrupt
6	S6_INT	When an interrupt occurs at SOCKET 6, it becomes '1'. This interrupt



		information is applied to S6_IR. This bit is automatically cleared when
		S6_IR is cleared to 0x00 by host.
		Occurrence of SOCKET 5 Interrupt
		When an interrupt occurs at SOCKET 5, it becomes '1'. This interrupt
5	S5_INT	information is applied to S5_IR. This bit is automatically cleared when
		S5_IR is cleared to 0x00 by host.
		Occurrence of SOCKET 4 Interrupt
		When an interrupt occurs at SOCKET 4, it becomes '1'. This interrupt
4	S4_INT	information is applied to S4_IR. This bit is automatically cleared when
		S4_IR is cleared to 0x00 by host.
-		Occurrence of SOCKET 3 Interrupt
		When an interrupt occurs at SOCKET 3, it becomes '1'. This interrupt
3	S3_INT	information is applied to S3_IR. This bit is automatically cleared when
		S3_IR is cleared to 0x00 by host.
		Occurrence of SOCKET 2 Interrupt
	CO INT	When an interrupt occurs at SOCKET 2, it becomes '1'. This interrupt
2	S2_INT	information is applied to S2_IR. This bit is automatically cleared when
		S2_IR is cleared to 0x00 by host.
		Occurrence of SOCKET 1 Interrupt
	C1 INT	When an interrupt occurs at SOCKET 1, it becomes '1'. This interrupt
1	S1_INT	information is applied to S1_IR. This bit is automatically cleared when
		S1_IR is cleared to 0x00 by host.
		Occurrence of SOCKET 0 Interrupt
		When an interrupt occurs at SOCKET 0, it becomes '0'. This interrupt
0	SO_INT	information is applied to S0_IR. This bit is automatically cleared when
		S0_IR is cleared to 0x00 by host.

8.3.2 SOCKET Registers

Sn_MR (SOCKET *n* Mode Register)[R/W][0xFE4000 + 0x100n][0x0000]

This register configures the protocol type or option of SOCKET *n*.

7	6	5	4	3	2	1	0
MULTI		ND / MC		P3	P2	P1	P0

Bit	Symbol	Description
		Multicasting
7	MULTI	0 : disable Multicasting
		1 : enable Multicasting



		This only applies to UDP case(P3-P0 : "0010")							
		To use multicasting, write multicast group address and port number to							
		SOCKET <i>n</i> destination IP and port register respectively before using the							
		OPEN command.							
		MAC Filter							
6	MF	0: disable MAC filteri	ng						
0	IVIF	1: enable MAC filterin	ng						
		Filters the MAC addre	esses ex	cept ow	n MAC a	nd broa	dcasting MAC address.		
		Use No Delayed ACK							
		0 : Disable No Delaye	d ACK o	ption					
		1 : Enable No Delayed	d ACK op	otion,					
		This only applies to T	CP case	(P3-P0	: "0001	")			
		If this bit is set as	s '1', <i>I</i>	АСК рас	cket is	immedi	ately transmitted after		
		receiving data packe	et from	a peer	. If this	s bit is	cleared, ACK packet is		
5	ND/MC	transmitted according to internal timeout mechanism.							
5		Multicast							
		0 : using IGMP version 2							
		1 : using IGMP version 1							
		This bit is valid when MULTI bit is enabled and UDP mode is used (P3-P0 :							
		"0010").							
		In addition, multicast can be used to send out the version number in IGMP							
		messages such as Joir	n/Leave	/Report	to mult	icast-gr	oup		
4	Reserved	Reserved							
		Protocol							
3	P3	Sets up corresponding	g SOCKE	T as TCF	P, UDP, c	or IP RAV	V mode		
		Symbol	P3	P2	P1	P0	Meaning		
2	P2	Sn_MR_CLOSE	0	0	0	0	Closed		
2	P2	Sn_MR_TCP	0	0	0	1	ТСР		
		Sn_MR_UDP	0	0	1	0	UDP		
1	P1	Sn_MR_IPRAW	0	0	1	1	IPRAW		
		S0_MR_MACRAW	0	1	0	0	MAC RAW		
		S0_MR_PPPoE	0	1	0	1	PPPoE		
	DO	S0_MR_MACRAW and	SO_MR_I	PPPoE ar	re valid	only in S	SOCKET 0.		
0	P0	SO_MR_PPPoE is temp	orarily	used for	PPPoE	server c	onnection/Termination.		
		After connection is es	stablish	ed, it ca	n be uti	lized as	another protocol.		



Sn_CR (SOCKET *n* Command Register)[R/W][0xFE4001 + 0x100n][0x00]

This is used to set the command for SOCKET *n* such as OPEN, CLOSE, CONNECT, LISTEN, SEND, and RECEIVE. After W7100A identifies the command, the Sn_CR register is automatically cleared to 0x00. Even though Sn_CR is cleared to 0x00, the command is still being processed. To verify whether the command is completed or not, please check the Sn_IR or Sn_SR registers.

Value	Symbol	Description			
		SOCKET n is	initialized and opened a	ccording to the protocol	selected in
		Sn_MR (P3:I	P0). The table below show	ws the value of Sn_SR co	rresponding
		to Sn_MR			
			Sn_MR(P3:P0)	Sn_SR	
0x01	OPEN		Sn_MR_CLOSE(0x00)	-	
0,01	OFEN		Sn_MR_TCP(0x01)	SOCK_INIT(0x13)	
			Sn_MR_UDP(0x02)	SOCK_UDP(0x22)	
			Sn_MR_IPRAW(0x03)	SOCK_IPRAW(0x32)	
			S0_MR_MACRAW(0x04)	SOCK_MACRAW(0x42)	
			S0_MR_PPPoE(0x05)	SOCK_PPPoE(0x5F)	
		This is valid	only in TCP mode (Sn_MI	R(P3:P0) = Sn_MR_TCP).	
		In this mod	de, the SOCKET <i>n</i> is co	nfigured as a TCP serve	er which is
		waiting for connection-request (SYN packet) from any "TCP CLIENT".			
		The Sn_SR register changes the state from SOCK_INIT to			K_INIT to
		SOCKET_LIS	TEN.		
		When a cl	ient's connection reque	st is successfully estab	lished, the
0x02	LISTEN	Sn_SR char	nges from SOCK_LISTEN	to SOCK_ESTABLIESHE	D and the
		Sn_IR(0) be	comes '1'. On the othe	er hand, Sn_IR(3) is set	as '1' and
		Sn_SR chan	ges to SOCK_CLOSED du	iring a connection failu	re(SYN/ACK
		packet faile	ed to transfer)		
		cf> If the o	destination port of the	TCP Client does not exi	st during a
		connection	request, W7100A will tr	ansmit a RST packet ar	nd Sn_SR is
		unchanged.			
		This mode	is only valid in TCP mod	le and operates the SOC	CKET <i>n</i> as a
		TCP client.			
0x04	CONNECT	A connect-r	equest (SYN packet) is se	ent to the TCP server by	connecting
0,04	CONNECT	to the IP	address and port stored	d in destination addres	s and port
		registers (Si	n_DIPR0 and Sn_DPORT0)		
		When a cl	ient's connection reque	st is successfully estab	lished, the

		Sn_SR register is changed to SOCK_ESTABLIESHED and the Sn_IR(0)
		becomes '1'.
		In the following cases, the connect-request fails
		- When a ARP timeout occurs (Sn_IR(s)='1') because the
		Destination Hardware Address is not acquired through the ARP
		process
		- When a SYN/ACK packet is not received and TCP timeout
		(Sn_IR(3)) is'1'
		- When a RST packet is received instead of a SYN/ACK packet
		Above three cases, Sn_SR is changed to SOCK_CLOSED.
		Only valid in TCP mode
		Regardless of "TCP SERVER" or "TCP CLIENT", this disconnect the
		process
		- Active close : it transmits disconnect-request(FIN packet) to
		the connected peer
		- Passive close : When FIN packet is received from peer, a FIN
0x08	DISCON	packet is replied back to the peer
		when FIN/ACK packet is received, Sn_SR is changed to SOCK_CLOSED.
		When a disconnect request is not received, TCP_{TO} occurs $(Sn_IR(3)='1')$
		and Sn_SR is changed to SOCK_CLOSED.
		cf> If CLOSE is used instead of DISCON, only Sn_SR is changed to
		SOCK_CLOSED without disconnect-process(disconnect-request). If a RST
		packet is received from a peer during communication, Sn_SR is
		unconditionally changed to SOCK_CLOSED.
0x10	CLOSE	Closes SOCKET n.
		Sn_SR is changed to SOCK_CLOSED.
		SEND command transmits remained (not transmitted) data buffered in
0x20	SEND	the TX memory. For more details, please refer to SOCKET <i>n</i> TX Free Size
		Register (Sn_TX_FSR), SOCKET <i>n</i> TX Write Pointer Register(Sn_TX_WR),
		and SOCKET <i>n</i> TX Read Pointer Register(Sn_TX_RD).
		Used in UDP mode only
		The basic operation is same as SEND. Normally SEND operation needs
0x21	SEND ΜΔC	Destination Hardware Address which can be retrieved by the ARP
	SEND_MAC	(Address Resolution Protocol) process. SEND_MAC uses SOCKET <i>n</i>
		Destination Hardware Address(Sn_DHAR) that is chosen by the user
		without going through the ARP process.
0x22	SEND_KEEP	Used in TCP mode

WIZnet

94



	It checks the connection status by sending the keep alive packet. If the			
	connection has no response from peers or is terminated, the Timeou			
		interrupt will occur.		
	RECV	RECV processes the data received by using a RX read pointer		
		register(Sn_RX_RD).		
0x40		For more detail, please refer to 9.2.1.1 SERVER mode Receiving Process		
0x40		with SOCKET n RX Received Size Register (Sn_RX_RSR), SOCKET n RX		
		Write Pointer Register(Sn_RX_WR), and SOCKET <i>n</i> RX Read Pointer		
		Register(Sn_RX_RD).		

Below commands are only valid for SOCKET 0 and SO_MR(P3:P0) = SO_MR_PPPoE.

For more detail refer to the W5100 application note "How to use ADSL".

Value	Symbol	Description
0x23	PCON	ADSL connection begins by transmitting PPPoE Discovery Packet
0x24	PDISCON	Closes ADSL connection
0x25	PCR	In each phase, it transmits REQ message
0x26	PCN	In each phase, it transmits NAK message
0x27	PCJ	In each phase, it transmits REJECT message

Sn_IR (SOCKET n Interrupt Register)[R/W][0xFE4002 + 0x100n][0x00]

Sn_IR register provides information such as the type of interrupt (establishment, termination, receiving data, timeout) used in SOCKET n. When an interrupt occurs and the mask bit of Sn_IMR is '1', the interrupt bit of Sn_IR becomes '1'.

In order to clear the Sn_IR bit, the host should write the bit as '1'. When all the bits of Sn_IR is cleared ('0'), IR(n) is automatically cleared. It occurs the INT5 signal (nINT5: TCPIPCore interrupt) to MCU.

7	6	5	4	3	2	1	0
PRECV	PFAIL	PNEXT	SEND_OK	TIMEOUT	RECV	DISCON	CON

Bit	Symbol	Description			
7	PRECV	PP Receive Interrupt, when the option which is not supported is			
/		received			
6	PFAIL	PPP Fail Interrupt, when PAP Authentication is failed			
		PPP Next Phase Interrupt, when the phase is changed during ADSL			
5		connection process			
4	SENDOK	SEND OK Interrupt, when the SEND command is completed			



3	TIMEOUT	TIMEOUT Interrupt, when ARP timeout or TCP timeout occurs	
2	RECV	Receive Interrupt, whenever data packet is received from a peer	
1	DISCON	isconnect Interrupt, when FIN of FIN/ACK packet is received from a	
		peer	
0	CON	Connect Interrupt occurs only one time when changing the SOCKET	
0		status to SOCK_Established	

Sn_IMR (SOCKET n Interrupt Mask Register)[R/W][0xFE402C + 0x100n][0xFF]

It configures the interrupt of SOCKET *n* so as to notify to the host. Interrupt mask bit of Sn_IMR corresponds to interrupt bit of Sn_IR. If interrupt occurs in any SOCKET and the bit is set as '1', its corresponding bit of Sn_IR is set as '1'. When the bits of Sn_IMR and Sn_IR are '1', IR(*n*) becomes '1'. At this time, if IMR(*n*) is '1', the interrupt is issued to the host. ('/INT' signal is asserted low)

7	6	5	4	3	2	1	0
PRECV	PFAIL	PNEXT	SEND_OK	TIMEOUT	RECV	DISCON	CON

Bit	Symbol	Description
7	PRECV	Sn_IR(PRECV) Interrupt Mask
/		Valid only in case of 'SOCKET = 0' & 'SO_MR(P3:P0) = SO_MR_PPPoE'
6	PFAIL	Sn_IR(PFAIL) Interrupt Mask
0		Valid only in case of 'SOCKET = 0' & 'SO_MR(P3:P0) = SO_MR_PPPoE'
5	PNEXT	Sn_IR(PNEXT) Interrupt Mask
5		Valid only in case of 'SOCKET = 0' & 'SO_MR(P3:P0) = SO_MR_PPPoE'
4	SENDOK	Sn_IR(SENDOK) Interrupt Mask
3	TIMEOUT	Sn_IR(TIMEOUT) Interrupt Mask
2	RECV	Sn_IR(RECV) Interrupt Mask
1	DISCON	Sn_IR(DISCON) Interrupt Mask
0	CON	Sn_IR(CON) Interrupt Mask

Sn_SR (SOCKET n Status Register)[R][0xFE4003 + 0x100n][0x00]

This register provides the status of SOCKET *n*. SOCKET status are changed when using the Sn_CR register or during packet transmission/reception.

Value	Symbol	Description	
0x00	SOCK_CLOSED	When DISCON or CLOSE command is used, or ARP_{TO} , or TC	
		occurs, the state changes to SOCK_CLOSED regardless of	
		previous value.	

The table below describes the different states of SOCKET *n*

0x13	SOCK_INIT	In this state, the SOCKET <i>n</i> is opened in TCP mode and initialized the first step of TCP connection establishment.
		Now, the user can use the LISTEN and CONNECT commands.
		When Sn_MR(P3:P0) is Sn_MR_TCP and the OPEN command is
		used, the stage changes to SOCK_INIT.
0x14	SOCK_LISTEN	SOCKET n operates in TCP Server Mode and waits for a
0714	SOCK_LISTEN	connection-request (SYN packet) from a "TCP CLIENT".
		When the LISTEN command is used, the stage changes to
		SOCK_LISTEN
		Once the connection is established, the SOCKET state
		changes from SOCK_LISTEN to SOCK_ESTABLISHED;however,
		if the connection fails, TCP_{TO} occurs (Sn_IR(TIME_OUT) = '1')
		and the state changes to SOCK_CLOSED.
0x17	SOCK_ESTABLISHED	When a SYN packet is received from a TCP client, the socket
		changes from the SOCK_LISTEN or CONNECTS state to the
		SOCK_ESTABLISHED state. At this stage, DATA packets can be
		exchanged by using the SEND or RECV command.
0x1C	SOCK_CLOSE_WAIT	In this case, a disconnect-request (FIN packet) is received
		from a peer. Although the TCP connection is half-closed,
		data packet can still be transferred. In order to complete
		the TCP disconnection, the DISCON command should be
		used. When a socket is closed without going through the
		disconnection-process, the CLOSE command should be used.
0x22	SOCK_UDP	The socket is opened in UDP mode. The SOCKET status is
		changed to SOCK_UDP when Sn_MR(P3:P0) is Sn_MR_UDP
		and OPEN command is used. Unlike TCP mode, the SOCKET
		in UDP mode can transfer data without establishing a
		connection (3 way handshake)
0x32	SOCK_IPRAW	The socket is opened in IPRAW mode. The SOCKET status is
		change to SOCK_IPRAW when Sn_MR(P3:P0) is Sn_MR_IPRAW
		and OPEN command is used. IP Packet can be transferred
		without a connection similar to the UDP mode.
0x42	SOCK_MACRAW	SOCKETO is opened in MACRAW mode. The SOCKET status is
		change to SOCK_MACRAW when S0_IMR(P3:P0) is
		S0_MR_MACRAW and S0_CR = OPEN. MAC packet(Ethernet
		frame) can be transferred similar to UDP mode.
0x5F	SOCK_PPPOE	SOCKET 0 is opened in PPPoE mode. The SOCKET status is

Ver. 1.1.6



changed to SOCK_PPPoE when S0_MR(P3:P0) = S0_MR_PPPoE
and SO_CR = OPEN.

Below table shows the temporary status which can be observed when changing the Sn_SR.

Value	Symbol	Description
0x15	SOCK_SYNSENT	This status indicates that a connect-request(SYN packet) is
		sent to a "TCP SERVER".
		SYNSENT is an intermediate state between SOCK_INT and
		SOCK_ESTABLISHED. If connect-accept(SYN/ACK packet) is
		received from a "TCP SERVER", the SOCKET status
		automatically changes to SOCK_ESTBLISHED. However, if
		SYN/ACK packet is not received before TCP timeout occurs
		(Sn_IR(TIMEOUT)='1'), the status is changed to
		SOCK_CLOSED.
0x16	SOCK_SYNRECV	This status indicate that a connect-request(SYN packet) is
		received from a "TCP CLIENT".
		The socket status changes to SOCK_ESTABLISHED when
		W7100A successfully transmits connect-accept (SYN/ACK
		packet) to a "TCP CLIENT". If W7100A fails to send and TCP_{TO}
		occurs (Sn_IR(TIMEOUT)='1'), the status is changed to
		SOCK_CLOSED.
0x18	SOCK_FIN_WAIT	These statues show the process of terminating a connection.
0x1A	SOCK_CLOSING	If the termination succeeds or Timeout interrupt is asserted,
0X1B	SOCK_TIME_WAIT	the socket status is changed to SOCK_CLOSED.
0X1D	SOCK_LAST_ACK	
0x01	SOCK_ARP	This status indicates an ARP-request is being transmitted to
		a peer in order to acquire destination hardware address.
		It appears when the SEND command is used in UDP, IP RAW,
		and TCP mode, the socket status changes to SOCK_ARP.
		If the hardware address is successfully acquired from the
		destination (ARP-response is received), the socket status
		changes to SOCK_UDP, SOCK_IPRAW or SOCK_SYNSENT.
		On the other hand, when W7100A fails to acquire the
		hardware address and an ARP timeout occurs
		(Sn_IR(TIMEOUT)= '1'), the socket status returns to the
		previous state in UDP mode and IP RAW mode. In TCP mode,
		the socket status goes to the SOCK_CLOSED state.






Figure 8.2 SOCKET n Status transition

SEND/RECV

Sn_PORT (SOCKET *n* Source Port Register)[R/W][(0xFE4004 + 0x100n) - (0xFE4005 + 0x100n)][0x0000]

It sets source port number.

It is valid when SOCKET *n* is used as TCP or UDP mode, and ignored when used as other modes.

It should be set before OPEN command.

Ex) In case of SOCKET 0 port = 5000(0x1388), configure as below,



0xFE4004 0xFE4005 0x13 0x88

Sn_DHAR (SOCKET *n* Destination Hardware Address Register)[R/W][(0xFE4006 + 0x100n) - (0xFE400B + 0x100n)][FF.FF.FF.FF.FF]

It sets or is set as destination hardware address of SOCKET *n*. Also, if SOCKET 0 is used for PPPoE mode, S0_DHAR sets as PPPoE server hardware an address that is already known.

When using SEND_MAC command at the UDP or IPRAW mode, it sets the destination hardware address of SOCKET *n*. At the TCP, UDP and IPRAW mode, Sn_DHAR is set as destination hardware address that is acquired by ARP-process of CONNECT or SEND command. The host can acquire the destination hardware address through Sn_DHAR after successfully performing CONNET or SEND command.

When using PPPoE-process of W7100A, PPPoE server hardware address is not required to be set.

However, even if PPPoE-process of W7100A is not used, but implemented by yourself with MACRAW mode, in order to transmit or receive the PPPoE packet, PPPoE server hardware address(acquired by your PPPoE-process), PPPoE server IP address, and PPP session ID should be set, and MR(PPPoE) also should be set as '1'.

S0_DHAR sets the PPPoE server hardware address before the OPEN command. PPPoE server hardware address which is set by S0_DHAR is applied to PDHAR after performing the OPEN command. The configured PPPoE information is internally valid even after the CLOSE command.

EX) In case of SOCKET 0 Destination Hardware address = 00.08.DC.01.02.10, config uration is as below,

0xFE4006	0xFE4007	0xFE4008	0xFE4009	0xFE400A	0xFE400B
0x00	0x08	0xDC	0x01	0x02	0x10

Sn_DIPR (SOCKET *n* Destination IP Address Register)[R/W][(0xFE400C + 0x100n) - (0xFE400F + 0x100n)][00.00.00.00]

It sets or is set as destination IP address of SOCKET *n*. If SOCKET 0 is used as PPPoE mode, S0_DIPR0 sets PPPoE server with an IP address that is already known.

It is valid only in TCP, UDP, IPRAW or PPPoE mode, but ignored in MACRAW mode.

In the TCP mode, when operating as "TCP CLIENT" it sets the IP address of the "TCP SERVER" before performing the CONNECT command and when operating as "TCP SERVER", it internally sets the IP address of the "TCP CLIENT" after successfully establishing connection.

In UDP or IPRAW mode, set the destination IP address in the Sn_DIPR for transmitting UDP or IPRAW DATA packets before performing SEND or SEND_MAC command. At the PPPoE mode, S0_DIPR sets as PPPoE server IP address that is already known.



Ex) In case of SOCKET 0 Destination IP address = 192.168.0.11, configure as below,

0xFE400C	0xFE400D	0xFE400E	0xFE400F
192 (0xC0)	168 (0xA8)	0 (0x00)	11 (0x0B)

Sn_DPORT (SOCKET *n* Destination Port Register)[R/W][(0xFE4010 + 0x100n) - (0xFE4011 + 0x100n)][0x0000]

The destination port number is set in the Sn_DPORT of SOCKET *n*. If SOCKET 0 is used as PPPoE mode, S0_DPORT0 sets PPP session ID that is already known.

It is valid only in TCP, UDP or PPPoE mode, and ignored in other modes.

At the TCP mode, when operating as "TCP CLIENT", it listens for the port number of the "TCP SERVER" before performing the CONNECT command.

At the UDP mode, the destination port number is set in the Sn_DPORT to be used for transmitting UDP DATA packets before performing SEND or SEND_MAC command.

At the PPPoE mode, the PPP session ID that is already known is set in the S0_DPORT. PPP session ID (set by S0_DPORT0) is applied to PSIDR after performing the OPEN command.

Ex) In case of SOCKET 0 Destination Port = 5000(0x1388), configure as below,

0xFE4010	0xFE4011
0x13	0x88

Sn_MSSR (SOCKET *n* Maximum Segment Size Register)[R/W][(0xFE4012 + 0x100n) - (0xFE4013 + 0x100n)][0x0000]

It sets the MTU (Maximum Transfer Unit) of SOCKET *n* or notifies the MTU that is already set. It supports TCP or UDP mode. When using PPPoE (MR(PPPoE)='1'), the MTU of the TCP or UDP mode is assigned in the range of the MTU of PPPoE.

At the IPRAW or MACRAW, MTU is not processed internally, but the default MTU is used. Therefore, when transmitting data bigger than the default MTU, the host should manually divide the data into the default MTU unit.

Reset value is 0 in the SOCKET initialization process, but the MSSR is changed to the smaller value between the user setting value and default value. If there is no user setting value, MSSR is changed to default value.

At the TCP or UDP mode, if transmitting data is bigger than the MTU, W7100A automatically divides the data into the MTU unit.

MTU is known as MSS in the TCP mode. By selecting from the Host-Written-Value and the peer's MSS, MSS is automatically set as the smaller value through the TCP connection process.

At the UDP mode, there is no connection-process of TCP mode, and Host-Written-Value is just used. When communicating with the peer having a different MTU, W7100A is able to receive ICMP (Fragment MTU) packets. So, the user should close the SOCKET, set FMTU as



Mode	Normal (MR(PPPoE)='0')		PPPoE (MR(PPPoE)='1')	
would	Default MTU	Range	Default MTU	Range
ТСР	1460	1 ~ 1460	1452	1 ~ 1452
UDP	1472	1 ~ 1472	1464	1 ~ 1464
IPRAW	1480		1472	
MACRAW	15		14	

Sn_MSSR and retry the communication with the OPEN command.

Ex) In case of SOCKET 0 MSS = 1460(0x05B4), configure as below,

0xFE4012 0xFE4013 0x05 0xB4

Sn_PROTO (SOCKET *n* Protocol Number Register)[R/W][0xFE4014 + 0x100n][0x00]

It is a 1 byte register that sets the protocol number field of the IP header at the IP layer. It is valid only in IPRAW mode, and ignored in other modes. Sn_PROTO is set before OPEN command. When SOCKET *n* is opened in IPRAW mode, it transmits and receives the data of the protocol number set in Sn_PROTO. Sn_PROTO can be assigned in the range of $0x00 \sim 0xFF$, but W7100A does not support TCP(0x06) and UDP(0x11) protocol number

Protocol number is defined in IANA(Internet assigned numbers authority). For the detail, refer to online document (http://www.iana.org/assignments/protocol-numbers).

Ex) Internet Control Message Protocol(ICMP) = 0x01, Internet Group Management Pr otocol = 0x02

Sn_TOS (SOCKET n TOS Register)[R/W][0xFE4015 + 0x100n][0x00]

It sets the TOS(Type of Service) field of the IP header at the IP layer. It should be set before the OPEN command. Refer to <u>http://www.iana.org/assignments/ip-parameters</u>.

Sn_TTL (SOCKET n TTL Register)[R/W][0xFE4016 + 0x100n][0x80]

It sets the TTL(Time To Live) field of the IP header at the IP layer. It should be set before the OPEN command. Refer to <u>http://www.iana.org/assignments/ip-parameters</u>.

Sn_RXMEM_SIZE (SOCKET *n* Receive Memory Size Register)[R/W][0xFE401E + 0x100n][0x02]

It configures the internal RX Memory size of each SOCKET. RX Memory size of each SOCKET is configurable in the size of 1, 2, 4, 8, 16Kbytes. 2Kbytes is assigned when reset. Sn_RXMEM_SIZE_{SUM}(sum of Sn_RXMEM_SIZE) of each SOCKET should be 16KB.



Ex1) SOCKET 0 : 8KB, SOCKET 1 : 2KB

0xFE401E 0xFE411E

0x08	0x02

Ex2) SOCKET 2 : 1KB, SOCKET 3 : 1KB

0xFE421E 0xF	E431E
0x01 0)x01

Ex3) SOCKET 4 : 1KB, SOCKET 5 : 1KB

OxFE441E	0xFE451E
0x01	0x01

Ex4) SOCKET 6 : 1KB, SOCKET 7 : 1KB

0xFE461E	0xFE471E
0x01	0x01

As shown above ex1) ~ ex4), total size of each SOCKET's RX memory (Sn_RXMEM_S IZE_{SUM}) is 16Kbytes.

Sn_TXMEM_SIZE (SOCKET *n* Transmit Memory Size Register)[R/W][0xFE401F + 0x100n][0x02]

It configures the internal TX Memory size of each SOCKET. TX Memory size of each SOCKET is configurable in the size of 1, 2, 4, 8, 16Kbytes. 2Kbytes is assigned when reset. Sn_TXMEM_SIZE_{SUM}(summation of Sn_TXMEM_SIZE) of each SOCKET should be 16KB.

Ex5) SOCKET 0 : 4KB, SOCKET 1 : 1KB

0xFE401F	0xFE411F
0x04	0x01

Ex6) SOCKET 2 : 2KB, SOCKET 3 : 1KB

0xFE421F	0xFE431F
0x02	0x01

Ex7) SOCKET 4 : 2KB, SOCKET 5 : 2KB

0xFE441F	0xFE451F
0x02	0x02



Ex8) SOCKET 6 : 2KB, SOCKET 7 : 2KB

 0xFE461F
 0xFE471F

 0x02
 0x02

As shown above ex5) ~ ex8), total size of each SOCKET's TX memory (Sn_TXMEM_S IZE_{SLIM}) is 16Kbytes.

Sn_TX_FSR (SOCKET *n* TX Free Size Register)[R][(0xFE4020 + 0x100n) - (0xFE4021 + 100n)][0x0000]

It notifies the available size of the internal TX memory (the byte size of transmittable data) of SOCKET *n*. The host can't write data as a size bigger than Sn_TX_FSR. Therefore, be sure to check Sn_TX_FSR before transmitting data, and if your data size is smaller than or the same as Sn_TX_FSR, transmit the data with SEND or SEND_MAC command after copying the data.

At the TCP mode, if the peer checks the transmitted DATA packet (if DATA/ACK packet is received from the peer), Sn_TX_FSR is automatically increased by the size of that transmitted DATA packet. At the other modes, when Sn_IR(SENDOK) is '1', Sn_TX_FSR is automatically increased by the size of the transmitted data.

Ex) In case of 2048(0x8000) in S0_TX_FSR0

0xFE4020	0xFE4021
0x08	0x00

Sn_TX_RD (SOCKET *n* TX Read Pointer Register)[R][(0xFE4022 + 0x100n) - (0xFE4023 + 0x100n)][0x0000]

This register shows the address of the last transmission finishing in the TX memory. With the SEND command of SOCKET *n* Command Register, it transmits data from the current Sn_TX_RD to the Sn_TX_WR and automatically updates after transmission is finished. Therefore, after transmission is finished, Sn_TX_RD and Sn_TX_WR will have the same value. When reading this register, the user should read the upper bytes (0xFE4022, 0xFE4122, 0xFE4222, 0xFE4322, 0xFE4522, 0xFE4522, 0xFE4622, 0xFE4522) first and lower bytes (0xFE4023, 0xFE4123, 0xFE4223, 0xFE4233, 0xFE4523, 0xFE4523,

Sn_TX_WR (SOCKET *n* TX Write Pointer Register)[R/W][(0xFE4024 + 0x100n) - (0xFE4025 + 0x100n)][0x0000]

This register offers the location information of where the transmission data should be written. When reading this register, the user should read the upper bytes (0xFE4024, 0xFE4124, 0xFE4224, 0xFE4324, 0xFE4524, 0xFE4524, 0xFE4624, 0xFE4724) first and the lower bytes (0xFE4025, 0xFE4125, 0xFE4225, 0xFE4325, 0xFE4425, 0xFE4525, 0xFE4625, 0xFE4725) later to get the correct value.



Ex) In case of 2048(0x0800) in S0_TX_WR,

0xFE4024	0xFE4025
0x08	0x00

But this value itself is not the physical address to write. So, the physical address should be calculated as follows: (Refer to the W7100A Driver code)

- SOCKET n TX Base Address (SBUFBASEADDRESS(n)) and SOCKETN TX Mask Address (SMASK(n)) are calculated on Sn_TXMEM_SIZE(n) value. Refer to the Pseudo code of the Initialization if detail is needed.
- 2. The bitwise-AND operation of two values and Sn_TX_WR and SMASK(*n*) gives the result of the offset address (dst_mask) in TX memory range of the SOCKET.
- 3. Two values dst_mask and SBUFBASEADDRESS(*n*) are added together to give the result of the physical address (dst_ptr).

Now, write the transmission data to dst_ptr as large as the user wants. (* There may be a case where it exceeds the TX memory of the upper-bound of the SOCKET while writing. In this case, write the transmission data to the upper-bound, and change the physical address to the SBUFBASEADDRESS(*n*). Next, write the rest of the transmission data.)

After that, be sure to increase the Sn_TX_WR value by the size of writing data. Finally, give the SEND command to Sn_CR (SOCKET *n* Command Register). Refer to the pseudo code of the transmission part on TCP Server mode if the detail is needed.




Figure 8.3 Calculate Physical Address

Sn_RX_RSR (SOCKET *n* RX Received Size Register)[R][(0xFE4026 + 0x100n) - (0xFE4027 + 0x100n)][0x0000]

It informs the user of the byte size of the received data in Internal RX Memory of SOCKET *n*. As this value is internally calculated with the values of Sn_RX_RD and Sn_RX_WR, it is automatically changed by RECV command of SOCKET *n* Command Register(Sn_CR) and receives data from the remote peer. When reading this register, the user should read the upper byte(0xFE4026, 0xFE4126, 0xFE4226, 0xFE4226, 0xFE4326, 0xFE4426, 0xFE4526, 0xFE4626,

© Copyright 2012 WIZnet Co., Inc. All rights reserved.

WIZ<u>net</u>



0xFE4726) first and lower byte(0xFE4027, 0xFE4127, 0xFE4227, 0xFE4327, 0xFE4427, 0xFE4527, 0xFE4627, 0xFE4727) later to get the correct value.

Ex) In case of 2048(0x0800) in S0_RX_RSR,

0xFE4026	0xFE4027
0x08	0x00

The total size of this value can be decided according to the value of RX Memory Size Register.

Sn_RX_RD (SOCKET *n* Read Pointer Register)[R/W][(0xFE4028 + 0x100n) - (0xFE4029 + 0x100n)][0x0000]

This register offers the location information to read the receiving data. When reading this register, user should read the upper byte (0xFE4028, 0xFE4128, 0xFE4228, 0xFE4328, 0xFE4428, 0xFE4528, 0xFE4628, 0xFE4728) first and lower byte (0xFE4029, 0xFE4129, 0xFE4229, 0xFE4329, 0xFE4329, 0xFE4529, 0xFE4629, 0xFE4729) later to get the correct value.

Ex) In case of 2048(0x0800) in S0_RX_RD,

0x0428	0x0429
0x08	0x00

But this value itself is not the physical address to read. So, the physical address should be calculated as follows: (Refer to the W7100A Driver code)

- 1. SOCKET *n* RX Base Address (RBUFBASEADDRESS(*n*)) and SOCKET *n* RX Mask Address (RMASK(*n*)) are calculated on Sn_RXMEM_SIZE(*n*) value.
- 2. The bitwise-AND operation of two values, Sn_RX_RD and RMASK(*n*) gives the result of the offset address (src_mask), in the RX memory range of the SOCKET.
- 3. Two values src_mask and RBUFBASEADDRESS(*n*) are added together to give the result of the physical address(src_ptr).

Now, read the receiving data from src_ptr as large as the user wants. (* There may be a case where it exceeds the RX memory upper-bound of the SOCKET while reading. In this case, read the receiving data to the upper-bound, and change the physical address to the RBUFBASEADDRESS(*n*). Next, read the rest of the receiving data.)

After that, be sure to increase the Sn_RX_RD value by the size of the reading data. (* Must not increase more than the size of received data. So must check Sn_RX_RSR before receiving process.) Finally, give RECV command to Sn_CR(SOCKET *n* Command Register).

Refer to the pseudo code of the receiving part on TCP Server mode if the detail is needed.

Sn_RX_WR (SOCKET *n* RX Write Pointer Register)[R/W][(0xFE402A + 0x100n) - (0xFE402B + 0x100n)][0x0000]

This register offers the location information to write the receive data. When reading this register, the user should read upper bytes (0xFE402A, 0xFE412A, 0xFE422A, 0xFE432A,

(0xFE442A, 0xFE452A, 0xFE462A, 0xFE472A) first and lower bytes (0xFE402B, 0xFE412B,	
(0xFE422B, 0xFE432B, 0xFE442B, 0xFE452B, 0xFE462B, 0xFE472B) later to get the correct	
,	value.	
	F_{V} in case of 2048(0)(0)(0) in S0 DV MD	

Ex) In case of 2048(0x0800) in S0_RX_WR,

WIZnet

0xFE402A	0xFE402B
0x08	0x00

Sn_FRAG (SOCKET *n* Fragment Register)[R/W][(0xFE402D + 0x100n) - (0xFE402E + 0x100n)][0x4000]

It sets the Fragment field of the IP header at the IP layer. W7100A does not support the packet fragment at the IP layer. Even though Sn_FRAG is configured, IP data is not fragmented, and not recommended either. It should be configured before performing OPEN command.

Ex) Sn_FRAG0 = 0x4000 (Don't Fragment)

0xFE	402D	0xFE402E
0x	40	0x00

Internet Embedded MCU W7100A Datasheet



9 Functional Description

Since the W7100A internally contains the 8051 compatible MCU and TCP/IP core, it can run standalone without other devices to Ethernet application. In this section, both the initialization of the W7100A and the communication method for each protocol (TCP, UDP, IPRAW and MACRAW) based on Pseudo code will be introduced.

9.1 Initialization

The initialization of W7100A has three steps which setup the 8051 MCU, the network information and the internal TX/RX memory.

- STEP 1 : Initializes MCU
- 1. Interrupt setting

Set the enable / disable state of interrupt such as the general 8051. Detail information of the setting refers to the section 3 'Interrupt'.

2. Memory Access timing setting

The memory access timing can be set by using two registers which are CKCON (0x8E) and WTST (0x92) registers. The CKCON (0x8E) can control the data memory access timing and the WTST (0x92) can control the code memory access timing. Both two registers can set their value from 0 to 7. But in the W7100A, CKCON can set the value 1~7 and WTST can set the value 4~7 only. The other values of both registers are not used. If the user sets the value to an unused value, the W7100A cannot run properly. Detail information can be found in the section 2.5 'SFR definition'.

Ex) Setting: interrupt disabled, 2 clocks access time with data memory, 7 clocks access time with code memory.

EA = 0;		// Disable all interrupts
	CKCON = 0x01;	// Set data memory access time
	WTST = 0x06;	// Set code memory access time

- 3. Serial baud rate, register and interrupt setting for serial communication
- For the serial communication, related registers of W7100A should be set.
 The registers of W7100A for serial communication are TMOD, PCON and SCON as below.
 - ① TMOD(89H): Decide the timer/counter mode for serial communication.

GATE C/T M ₁	M ₀ GATE	C/T	M_1	Mo	
-------------------------	---------------------	-----	-------	----	--



M ₁	Mo	Mode
0	0	0
0	1	1
1	0	2
1	1	3

Table 9.1 Timer / Counter Mode

(2) PCON(87H): Decide the SMOD bit which is the control flag of the serial transmission rate.

SMOD	-	-	-	-	-	-	-
------	---	---	---	---	---	---	---

Table	92	Baud	rate
Table	7.2	Dauu	rate

Mode SMOD = '0'		SMOD = '1'
1 2	A half of Overflow of the	Overflow of the
1, 3	Timer/Counter 1	Timer/Counter 1
2 A quarter of the XTAL		A half of the XTAL

③ SCON(98H): For control and observe the UART.

SM0 SM1 SM2 REN TB8 RB8 TI R
--

Table 9.3 Mode of UART

SMo	SM ₁	Mode
0	0	0
0	1	1
1	0	2
1	1	3

 SM_2 : Used in Mode2, 3. Assume that this bit set to 1, if the 9th bit of received data

bit is '1', receive the data. Or the bit is '0' ignore the data.

REN: Receive enable bit ('1'; Receive enable).

 TB_8 : In the mode2, 3, 8th bit of transmitted data.

 RB_8 : In the mode2, 3, 8th bit of received data.

TI: Transmission complete interrupt flag.

- RI: Reception complete interrupt flag.
- 2) Interrupt state should be set when initializing the serial communication.

Since the serial communication uses interrupt, user must disable the related interrupts when initializing the serial communication.

3) The baud rate should be set to the value which the user will use. Baud rate value for the



timer of W7100A refers to the section 6.6 'Examples of Baud Rate Setting'.

The calculation of baud rate for the timer is as below

① Calculation formula of timer1

TH1 = 256 - ((K * 88.4736MHz) / (384 * baud rate))

K = '1' at SMOD = '0', K = '2' at SMOD = '1'

② Calculation formula of timer2

(RCAP2H, RCAP2L) = 65536 - (88.4736MHz / (32 * baud rate))

Ex) Using timer mode2, SMOD = 1, Clock speed = 88.4736MHz, Baud rate = 115200.

ET1= 0;	// Timer1 INT disable
TMOD = 0x20;	// TIMER MODE2
PCON = 0x80;	// SMOD = 1
TH1 = 0xFC;	// x2 115200(SMOD = 1) at 88.4736MHz
TR1 = 1;	// Start the TIMER1
SCON = 0x50;	// Serial MODE1, REN = 1, TI = 0, RI = 0
ES = 0;	// Serial interrupt disable
RI = 0;	// Receive interrupt disable
TI = 0;	// Transmit interrupt disable

4) If user uses TCPIP Core interrupt, the INTLEVEL register must be set to the value more than 0x2B00 because of internal TCPIP Core interrupt routine.

Ex) Set the INTLEVEL register to 0x2B00

IINCHIP_WRITE (INTLEVELO, 0	x2B) ;	//write high byte of INTLEVEL TCPIPCore register
IINCHIP_WRITE (INTLEVEL0 + 1,	0x0	0);//write low byte of INTLEVEL TCPIPCore register

• STEP 2 : Setting Network Information

1. Basic network information setting for communication:

It must be set the basic network information.

① SHAR(Source Hardware Address Register)

It is prescribed that the source hardware addresses, which is set by SHAR, use unique hardware addresses (Ethernet MAC address) in the Ethernet MAC layer. The IEEE manages the MAC address allocation. The manufacturer which produces the network device allocates the MAC address to product.

Details on MAC address allocation refer to the website as below.

http://www.ieee.org/, http://standards.ieee.org/regauth/oui/index.shtml

② GAR(Gateway Address Register)

- ③ SUBR(Subnet Mask Register)
- ④ SIPR(Source IP Address Register)



Set the retransmission time & count when the packet transmission fails.
 To set the retransmission time, the registers should be set as below.

1 RTR(Retry Time-value Register), In the RTR, '1' means '100us'.

2 RCR(Retry Count Register)

• STEP 3 : Allocation Internal TX/RX Memory for SOCKET n

Total configurable maximum size of TX, RX memory is 16 Kbytes. User can freely set the memory size to 1KB, 2KB, 4KB, 8KB and 16KB within 16Kbytes each 8 sockets. But the sum of TX or RX memory cannot be set more than 16Kbytes. ($TX_{max} = 16KB$, $RX_{max} = 16KB$)

```
In case of, assign 2KB rx, tx memory per SOCKET
{
gS0_RX_BASE = 0xFE0000(Chip base address) + 0xFEC000(Internal RX buffer address); // Set
base address of RX memory for SOCKET 0
Sn_RXMEM_SIZE(ch) = (uint8 *) 2; // Assign 2K rx memory per SOCKET
gS0_RX_MASK = 2K - 1; // 0x07FF, for getting offset address within assigned SOCKET 0 RX
memory
gS1_RX_BASE = gS0_RX_BASE + (gS0_RX_MASK + 1);
gS1_RX_MASK = 2K - 1;
gS2_RX_BASE = gS1_RX_BASE + (gS1_RX_MASK + 1);
gS2_RX_MASK = 2K - 1;
gS3_RX_BASE = gS2_RX_BASE + (gS2_RX_MASK + 1);
qS3_RX_MASK = 2K - 1;
gS4_RX_BASE = gS3_RX_BASE + (gS3_RX_MASK + 1);
gS4_RX_MASK = 2K - 1;
gS5_RX_BASE = gS4_RX_BASE + (gS4_RX_MASK + 1);
gS5_RX_MASK = 2K - 1;
gS6_RX_BASE = gS5_RX_BASE + (gS5_RX_MASK + 1);
gS6_RX_MASK = 2K - 1;
gS7_RX_BASE = gS6_RX_BASE + (gS6_RX_MASK + 1);
gS7_RX_MASK = 2K - 1;
qS0_TX_BASE = 0xFE0000(Chip base address) + 0xFE8000(Internal TX buffer address); // Set
base address of TX memory for SOCKET 0
Sn_TXMEM_SIZE(ch) = (uint8 *) 2; // Assign 2K rx memory per SOCKET
gSO_TX_MASK = 2K - 1;
Same method, set gS1_TX_BASE, gS1_TX_MASK, gS2_TX_BASE, gS2_TX_MASK, gS3_TX_BASE,
gS3_TX_MASK, gS4_TX_BASE, gS4_TX_MASK, gS5_TX_BASE, gS5_TX_MASK, gS6_TX_BASE,
gS6_tx_MASK, gS7_TX_BASE, gS7_TX_MASK.
}
```



Sn_TXMEM_SIZE(ch) = 2K, Chip base address = 0xFE0000

	0xFEC000	
Socket 7	0xFEB800	gS7_TX_BASE = 0xFEB800 gS7_TX_MASK = 0x07FF
Socket 6	0×FEB000	gS6_TX_BASE = 0xFEB000 gS6_TX_MASK = 0x07FF
Socket 5	0×FEA800	gS5_TX_BASE = 0xFEA800 gS5_TX_MASK = 0x07FF
Socket 4	0×FEA000	gS4_TX_BASE = 0xFEA000 gS4_TX_MASK = 0x07FF
Socket 3	0×FE9800	gS3_TX_BASE = 0xFE9800 gS3_TX_MASK = 0x07FF
Socket 2	0xFE9000	gS2_TX_BASE = 0xFE9000 gS2_TX_MASK = 0x07FF
Socket 1	0xFE8800	gS1_TX_BASE = 0xFE8800 gS1_TX_MASK = 0x07FF
Socket 0	0×FE8000	gS0_TX_BASE = 0xFE8000 gS0_TX_MASK = 0x07FF

(a) TX memory allocation

Sn_RXMEM_SIZE(ch) = 2K, Chip base address = 0xFE0000

Socket 7	0xFEF800	gS7_RX_BASE = 0xFEF800 gS7_RX_MASK = 0x07FF
Socket 6	0xFEF000	gS6_RX_BASE = 0xFEF000 gS6_RX_MASK = 0x07FF
Socket 5	0xFEE800	gS5_RX_BASE = 0xFEE800 gS5_RX_MASK = 0x07FF
Socket 4	0xFEE000	gS4_RX_BASE = 0xFEE000 gS4_RX_MASK = 0x07FF
Socket 3	0xFED800	gS3_RX_BASE = 0xFED800 gS3_RX_MASK = 0x07FF
Socket 2	0xFED000	gS2_RX_BASE = 0xFED000 gS2_RX_MASK = 0x07FF
Socket 1	0xFEC800	gS1_RX_BASE = 0xFEC800 gS1_RX_MASK = 0x07FF
Socket 0	0×FEC000	gS0_RX_BASE = 0xFEC000 gS0_RX_MASK = 0x07FF

(b) RX memory allocation

Figure 9.1 Allocation Internal TX/RX memory of SOCKET n

If the W7100A initialization process is finished, the W7100A can perform data communication through Ethernet. From this point, the W7100A can transmit the ping-reply of the request packet which is received from network.



9.2 Data Communication

After the W7100A initialization process, open the SOCKET to TCP or UDP or IPRAW or MACRAW mode. W7100A can transmit and receive the data with others by 'open' the SOCKET. The W7100A supports the independently and simultaneously usable 8 SOCKETS. In this section, the communication method for each mode will be introduced.

9.2.1 TCP

The TCP is a connection-oriented protocol. The TCP make the connection SOCKET by using its own IP address, port number and destination IP address, port number. Then transmits and receives the data by using this SOCKET.

Methods of making the connection to SOCKET are "TCP SERVER" and "TCP CLIENT". It is divided by transmitting the connect-request (SYN packet).

The "TCP SERVER" listens to the connect-request from the "TCP CLIENT", and makes connection SOCKET by accepting the transmitted connect-request (Passive-open).

The "TCP CLIENT" transmits the connect-request first to "TCP SERVER" to make the connection (Active-open).




Figure 9.2 TCP SERVER & TCP CLIENT



9.2.1.1 TCP SERVER

OPEN

LISTEN

ESTABISHED?

Yes

Received DATA

Send DATA ?

No

Received FIN?

No

Disconnect?

No

Timeout ?

No

Receiving Process Sending Process

CLOSED ?

No

Timeout ?

Yes

CLOSE

Ver. 1.1.6

Yes

No

Internet Embedded MCU W7100A Datasheet

Figure 9.3 "TCP SERVER" Operation Flow

Yes

SOCKET Initialization

SOCKET initialization is required for TCP data communication. The initialization is opening the SOCKET. The SOCKET opening process selects one SOCKET from 8 SOCKETS of the W7100A, and sets the protocol mode (Sn_MR(P3:P0)) and Sn_PORT0 which is source port number (Listen port number in "TCP SERVER") in the selected SOCKET, and then executes OPEN command. After the OPEN command, if the status of Sn_SR is changed to SOCK_INIT, the SOCKET initialization process is completed.

The SOCKET initialization process is identically applied in "TCP SEVER" and "TCP CLIENT". The Initialization process of SOCKET n in TCP mode is shown below.

{		
START:		
Sn_MR = 0x0001;	// sets TCP mode	

WIZnet

Sn_PORT = source_port; // sets source port number

Sn_CR = OPEN; // sets OPEN command

```
/* wait until Sn_SR is changed to SOCK_INIT */
```

if (Sn_SR != SOCK_INIT) Sn_CR = CLOSE; goto START;

}

{

}

■ LISTEN

Run as "TCP SERVER" by LISTEN command.

```
/* listen SOCKET */
Sn_CR = LISTEN;
/* wait until Sn_SR is changed to SOCK_LISTEN */
if (Sn_SR != SOCK_LISTEN) Sn_CR = CLOSE; goto START;
```

ESTABLISHMENT


When the status of Sn_SR is SOCK_LISTEN, if it receives a SYN packet, the status of Sn_SR is changed to SOCK_SYNRECV and transmits the SYN/ACK packet. After that, the SOCKET n makes a connection. After it makes the connection of SOCKET n, it enables the data communication. There are two methods to confirm the connection of SOCKET n.

```
First method :
{
    if (Sn_IR(CON) == '1') Sn_IR(CON) = '1'; goto ESTABLISHED stage;
    /* In this case, if the interrupt of SOCKET n is activated, interrupt occurs. Refer to IR, IMR
        Sn_IMR and Sn_IR. */
}
Second method :
{
```

if (Sn_SR == SOCK_ESTABLISHED) goto ESTABLISHED stage;

```
■ ESTABLISHMENT : Check received data
```

Confirm the reception of the TCP data.





```
/* In this case, if the interrupt of SOCKET n is activated, interrupt occurs. Refer to IR, IMR
Sn_IMR and Sn_IR. */
```

```
Second Method :
```

```
{
```

}

if (Sn_RX_RSR != 0x0000000) goto Receiving Process stage;

}

The First method: set the Sn_IR(RECV) to '1' whenever you receive a DATA packet. If the host receives the next DATA packet without setting the Sn_IR(RECV) as '1' in the prior DATA packet, it cannot recognize the Sn_IR(RECV) of the next DATA packet. This is due to the prior Sn_IR(RECV) and next Sn_IR(RECV) being overlapped. So this method is not recommended if the host cannot perfectly process the DATA packets of each Sn_IR(RECV).

■ ESTABLISHMENT : Receiving process

In this process, it processes the TCP data which was received in the Internal RX memory. At the TCP mode, the W7100A cannot receive the data if the size of received data is larger than the RX memory free size of SOCKET *n*. If the prior stated condition is happened, the W7100A holds on to the connection (pauses), and waits until the RX memory's free size is larger than the size of the received data.

The wizmemcpy function, using Receive / Send process for fast memory copy, is defined in the wizmemcpy.c file of W7100A driver. About more detailed information please refer to the section 13 'Performance Improvement about W7100A' for its performance and "W7100A Driver Guide" for its usage. If user don't want to use the wizmemcpy function, just use a common memory copy function.

Since the W7100A internally has data memory and TCPIPCore internal memory, user should classify it by address. So user must pad '0xFE' to the top level address of TCPIPCore internal memory with, or DPX0 register set to '0xFE' when memory copying from TCPIPCore memory to data memory. More detail about the wizmemcpy please refers to the 'W7100A Driver Guide'.

```
{
    /* first, get the received size */
    len = Sn_RX_RSR; // len is received size
    /* calculate offset address */
    src_mask = Sn_RX_RD & gSn_RX_MASK; // src_mask is offset address
    /* calculate start address(physical address) */
    src_ptr = gSn_RX_BASE + src_mask; // src_ptr is physical start address
    /* if overflow SOCKET RX memory */
```

If((src_mask + len) > (gSn_RX_MASK + 1)) { /* copy upper_size bytes of get_start_address to destination_address */ upper_size = (gSn_RX_MASK + 1) - src_mask; wizmemcpy((0xFE0000 + src_ptr), (0x000000 + destination_address), upper_size); /* update destination_address */ destination_address += upper_size; /* copy left_size bytes of gSn_RX_BASE to destination_address */ left_size = len - upper_size; wizmemcpy((0xFE0000 + src_ptr), (0x000000 + destination_address), left_size); } else { copy len bytes of src_ptr to destination_address */ wizmemcpy((0xFE0000 + src_ptr), (0x000000 + destination_address), len); } /* increase Sn_RX_RD as length of len */ Sn_RX_RD += len; /* set RECV command */ $Sn_CR = RECV;$

ESTABLISHMENT : Check send data / Send process

WIZnet

The size of the transmit data cannot be larger than assigned internal TX memory of SOCKET *n*. If the size of transmit data is larger than configured MSS, it is divided by size of MSS and transmits.

To transmit the next data, user must check the completion of prior SEND command. An error may occur if the SEND command executes before completion of prior SEND command. The larger the data size, the more time to complete the SEND command. So the user should properly divide the data to transmit.

At the send process, user must pad '0xFE' to top-level address of TCPIPCore internal memory as in the receive process.

```
{
    /* first, get the free TX memory size */
FREESIZE:
    freesize = Sn_TX_FSR;
    if (freesize < len) goto FREESIZE; // len is send size
    /* calculate offset address */</pre>
```

Internet Embedded MCU W7100A Datasheet

WIZnet

```
dst_mask= Sn_TX_WR & gSn_TX_MASK;
                                         // dst_mask is offset address
/* calculate start address(physical address) */
dst_ptr = gSn_TX_BASE + dst_mask;
                                    // dst_ptr is physical start address
/* if overflow SOCKET TX memory */
if ((dst_mask + len) > (gSn_TX_MASK + 1))
{
   /* copy upper_size bytes of source_addr to dst_ptr */
   upper_size = (gSn_TX_MASK + 1) - dst_mask;
   wizmemcpy((0x000000 + source_addr), (0xFE0000 + dst_ptr), upper_size);
   /* update source_addr*/
   source_addr += upper_size;
   /* copy left_size bytes of source_addr to gSn_TX_BASE */
   left_size = len - upper_size;
   wizmemcpy((0x000000 + source_addr), (0xFE0000 + gSn_TX_BASE), left_size);
}
else
{/* copy len bytes of source_addr to dst_ptr */
   wizmemcpy((0x000000 + source_addr), (0xFE0000 + dst_ptr), len);
}
/* increase Sn_TX_WR as length of Ien */
Sn_TX_WR += send_size;
/* set SEND command */
Sn_CR = SEND;
```

ESTABLISHMENT : Check disconnect-request(FIN packet)

Check if the Disconnect-request(FIN packet) has been received. User can confirm the reception of FIN packet as below.

```
First method :
{
    if (Sn_IR(DISCON) == '1') Sn_IR(DISCON)='1'; goto CLOSED stage;
    /* In this case, if the interrupt of SOCKET n is activated, interrupt occurs. Refer to IR, IMR
        Sn_IMR and Sn_IR. */
}
Second method :
{
    if (Sn_SR == SOCK_CLOSE_WAIT) goto CLOSED stage;
}
```



ESTABLISHMENT : Check disconnect / disconnecting process

When the user does not need data communication with others, or receives a FIN packet, disconnect the connection SOCKET.

```
{ /* set DISCON command */
   Sn_CR = DISCON;
}
```

ESTABLISHMENT : Check closed

Confirm that the SOCKET *n* is disconnected or closed by DISCON or close command.

```
First method :
{
    if (Sn_IR(DISCON) == '1') goto CLOSED stage;
```

/* In this case, if the interrupt of SOCKET n is activated, interrupt occurs. Refer to IR, IMR
Sn_IMR and Sn_IR. */

Second method :

{

}

if (Sn_SR == SOCK_CLOSED) goto CLOSED stage;

}

ESTABLISHMENT : Timeout

The timeout can occur by Connect-request(SYN packet) or its response(SYN/ACK packet), the DATA packet or its response(DATA/ACK packet), the Disconnect-request(FIN packet) or its response(FIN/ACK packet) and transmission all TCP packet. If it cannot transmit the above packets within 'timeout' which is configured at RTR and RCR, the TCP final timeout(TCP_{TO}) occurs and the state of Sn_SR is changed to SOCK_CLOSED. Confirming method of the TCP_{TO} is as below:

```
First method :
{
    if (Sn_IR(TIMEOUT bit) == '1') Sn_IR(TIMEOUT)='1'; goto CLOSED stage;
    /* In this case, if the interrupt of SOCKET n is activated, interrupt occurs. Refer to IR, IMR
        Sn_IMR and Sn_IR. */
}
Second method :
{
    if (Sn_SR == SOCK_CLOSED) goto CLOSED stage;
}
```

}



SOCKET close

It can be used to close the SOCKET n, which disconnected by disconnect-process, or closed by TCP_{TO} or closed by host's need without disconnect-process.

{/* clear the remained interrupts of SOCKET n*/
 Sn_IR = 0x00FF;
 IR(n) = '1';
 /* set CLOSE command */
 Sn_CR = CLOSE;
}



9.2.1.2 TCP CLIENT

It is same as TCP server except 'CONNECT' state. User can refer to the "9.2.1.1 TCP SERVER".





Figure 9.4 "TCP CLIENT" Operation Flow

CONNECT

Transmit the connect-request(SYN packet) to "TCP SERVER". It may occurs the timeout such as ARP_{TO} , TCP_{TO} when make the "connection SOCKET" with "TCP SERVER"





9.2.2 UDP

The UDP is a Connection-less protocol. It communicates without "connection SOCKET". The TCP protocol guarantees reliable data communication, but the UDP protocol use datagram communication which has no guarantees of data communication. Because the UDP do not use "connection SOCKET", it can communicate with many other devices with the known host IP address and port number. This is a great advantage; communication with many others by using just one SOCKET, but also it has many problems such as loss of transmitted data, unwanted data which received from others etc. In the UDP, to avoid these problems and guarantee the reliability, the host retransmits damaged data or ignores the unwanted data which is received from others. The UDP protocol supports unicast, broadcast, and multicast communication. It follows the below communication flow.




Figure 9.5 UDP Operation Flow

9.2.2.1 Unicast & Broadcast

The unicast is one method of UDP communication. It transmits data to one destination at one time. On the other hand, the broadcast communication transmits data to all receivable destinations by using 'broadcast IP address (255.255.255.255)'. For example, suppose that the user transmits data to destination A, B and C. The unicast communication transmits each destication A, B and C at each time. At this time, the ARP_{TO} can also occur when the user gets the destination hardware address of destinations A, B and C. User cannot transmit data to destinations which have ARP_{TO} .

The broadcast communication can simultaneously transmit data to destination A, B and C at one time by using "255.255.255.255.255" IP address. At this time, there is no need to get the



destination hardware address about destination A, B and C, and also ARP_{TO} is not occurred.

• How to make broadcast IP?

The broadcast IP address can be obtained by performing a bitwise logical OR operation between the bit complement of the subnet mask and the host IP address.

$PX > IP \cdot 222 98 173 123$	Subnet Mask	255 255 255 0 then	broadcast IP: 222.98.173.255
C// II . 222.70.175.125	Jubrict Music.	200.200.200.0 then	broddcust II : 222.70.175.255

Description	Decimal	Binary
HOST IP	222.098.173.123	11011110.01100010.10101101.01111011
Bit Complement Subnet mask	000.000.000.255	0000000.0000000.0000000.11111111
Bitwise OR	-	-
Broadcast IP	222.098.173.255	11011110.01100010.10101101.11111111

SOCKET Initialization

For the UDP data communication, SOCKET initialization is needed. It is opening the SOCKET. The SOCKET open process is as follows. At first choose the one SOCKET among the 8 SOCKETS of W7100A, then set the protocol mode(Sn_MR(P3:P0)) of the chosen SOCKET and set the source port number Sn_PORTO for communication. Finally execute the OPEN command. After the OPEN command, the state of Sn_SR is changed to SOCK_UDP. Then the SOCKET initialization is complete.

```
{
START:
Sn_MR = 0x02; /* sets UDP mode */
Sn_PORT = source_port; /* sets source port number */
Sn_CR = OPEN; /* sets OPEN command */
/* wait until Sn_SR is changed to SOCK_UDP */
if (Sn_SR != SOCK_UDP) Sn_CR = CLOSE; goto START;
```

Check received data

Check the reception of UDP data from destination. User can also check for received data via TCP communication. It is strongly recommended that the TCP method is used because of the same reason ing TCP. Please refer to the "9.2.1.1 TCP SERVER".

```
First method :
{
    if (Sn_IR(RECV) == '1') Sn_IR(RECV) = '1'; goto Receiving Process stage;
    /* In this case, if the interrupt of SOCKET n is activated, interrupt occurs. Refer to IR, IMR
        Sn_IMR and Sn_IR. */
```



}
Second Method :
{
 if (Sn_RX_RSR != 0x0000000) goto Receiving Process stage;
}

Receiving process

Process the received UDP data in Internal RX memory. The structure of received UDP data is as below.

PACKET-INFO		DATA packet	
Destination IP Address	Destination Port number	Byte size of DATA packet	Real Data
4 Bytes	2 Bytes	2 Bytes	Size speicified in PACKET-INFO

Figure 9.6 The received UDP data format

The received UDP data consists of 8bytes PACKET-INFO, and DATA packet. The PACKET-INFO contains transmitter's information (IP address, Port number) and the length of DATA packet. The UDP can receive UDP data from many others. User can classify the transmitter by transmitter's information of PACKET-INFO. It also receives broadcast SOCKET by using "255.255.255.255.255." IP address. So the host should ignore unwanted reception by analysis of transmitter's information.

If the DATA size of SOCKET *n* is larger than Internal RX memory free size, user cannot receive that DATA and also cannot receive fragmented DATA.

```
{/* first, get the received size */
len = Sn_RX_RSR; // len is received size
/* calculate offset address */
src_mask = Sn_RX_RD & gSn_RX_MASK; // src_mask is offset address
/* calculate start address(physical address) */
src_ptr = gSn_RX_BASE + src_mask; // src_ptr is physical start address
/* read head information (8 bytes) */
header_size = 8;
/* if overflow SOCKET RX memory */
if ( (src_mask + header_size) > (gSn_RX_MASK + 1) )
{/* copy upper_size bytes of src_ptr to header_addr */
    upper_size = (gSn_RX_MASK + 1) - src_mask;
    wizmemcpy((0xFE0000 + src_ptr), (0x000000 + header_addr), upper_size);
    /* update header_addr*/
```

WIZnet

```
header_addr += upper_size;
   /* copy left_size bytes of gSn_RX_BASE to header_addr */
   left_size = header_size - upper_size;
   wizmemcpy((0xFE0000 + gSn_RX_BASE), (0x000000 + header_addr), left_size);
   /* update src_mask */
   src_mask = left_size;
}
else
{/* copy header_size bytes of get_start_address to header_addr */
   wizmemcpy((0xFE0000 + src_ptr), (0x000000 + header_addr), header_size);
   /* update src_mask */
   src_mask += header_size;
}
/* update src_ptr */
src_ptr = gSn_RX_BASE + src_mask;
/* save remote peer information & received data size */
peer_ip = header[0 to 3];
peer_port = header[4 to 5];
get_size = header[6 to 7];
/* if overflow SOCKET RX memory */
if ( (src_mask + get_size) > (gSn_RX_MASK + 1) )
{/* copy upper_size bytes of src_ptr to destination_addr */
   upper_size = (gSn_RX_MASK + 1) - src_mask;
   wizmemcpy((0xFE0000 + src_ptr), (0x000000 + destination_addr), upper_size);
   /* update destination_addr*/
   destination_addr += upper_size;
   /* copy left_size bytes of gSn_RX_BASE to destination_addr */
   left_size = get_size - upper_size;
   wizmemcpy((0xFE0000 + gSn_RX_BASE), (0x000000 + destination_addr), left_size);
}
else
{/* copy len bytes of src_ptr to destination_addr */
   wizmemcpy((0xFE0000 + src_ptr), (0x000000 + destination_addr), get_size);
}
/* increase Sn_RX_RD as length of len + header_size */
Sn_RX_RD = Sn_RX_RD + get_size + header_size;
/* set RECV command */
Sn_CR = RECV;
```



Check send data / Sending process The size of DATA which user wants to transmit cannot be larger than Internal TX memory. If it is larger than MTU, it is automatically divided by MTU unit and transmits. The Sn_DIPRO is set "255.255.255.255" when user wants to broadcast. {/* first, get the free TX memory size */ **FRFFSIZE**: freesize = Sn_TX_FSR; if (freesize < len) goto FREESIZE; // len is send size /* Write the value of remote_ip, remote_port to the SOCKET n Destination IP Address Register(Sn_DIPR), SOCKET n Destination Port Register(Sn_DPORT). */ Sn_DIPR = remote_ip; Sn_DPORT = remote_port; /* calculate offset address */ dst_mask = Sn_TX_WR & gSn_TX_MASK; // dst_mask is offset address /* calculate start address(physical address) */ dst_ptr = gSn_TX_BASE + dst_mask; // dst_ptr is physical start address /* if overflow SOCKET TX memory */ if $(dst_mask + len) > (gSn_TX_MASK + 1))$ {/* copy upper_size bytes of source_address to dst_ptr */ upper_size = (gSn_TX_MASK + 1) - dst_mask; wizmemcpy((0x000000 + source_address), (0xFE0000 + dst_ptr), upper_size); /* update source_address */ source_address += upper_size; /* copy left_size bytes of source_address to gSn_TX_BASE */ left_size = send_size - upper_size; wizmemcpy((0x000000 + source_address), (0xFE0000 + gSn_TX_BASE), left_size); } else {/* copy len bytes of source_address to dst_ptr */ wizmemcpy((0x000000 + source_address), (0xFE0000 + dst_ptr), len);

```
/* increase Sn_TX_WR as length of len */
Sn_TX_WR += len;
/* set SEND command */
Sn_CR = SEND;
```

© Copyright 2012 WIZnet Co., Inc. All rights reserved.

}



Check complete sending / Timeout

To transmit the next data, user must check that the prior SEND command is completed. The larger the data size, the more time to complete the SEND command. Therefore, the user must properly divide the data to transmit. The ARP_{TO} can occur when user transmits UDP data. If the ARP_{TO} is occurred, the UDP data transmission will be failed.

```
First method :
{/* check SEND command completion */
while(Sn_IR(SENDOK)=='0') /* wait interrupt of SEND completion */
{/* check ARP<sub>TO</sub> */
    if (Sn_IR(TIMEOUT)=='1') Sn_IR(TIMEOUT)='1'; goto Next stage;
    }
    Sn_IR(SENDOK) = '1'; /* clear previous interrupt of SEND completion */
}
Second method :
{
    If (Sn_CR == 0x00) transmission is completed.
    If (Sn_IR(TIMEOUT bit) == '1') goto next stage;
    /* In this case, if the interrupt of SOCKET n is activated, interrupt Register(IR), Interrupt Mask Register (IMR) and SOCKET n Interrupt Register (Sn_IR).
*/
```

Check Finished / SOCKET close

}

If user doesn't need the communication any more, close the SOCKET n.

```
{/* clear remained interrupts */
    Sn_IR = 0x00FF;
    IR(n) = '1';
    /* set CLOSE command */
    Sn_CR = CLOSE;
}
```

9.2.2.2 Multicast

The broadcast communication communicates with many and unspecified others. But the multicast communication communicates with many but specified others who registered at multicast-group. Suppose that A, B and C are registered at specified multicast-group. If user transmits data to multicast-group (contains A), the B and C also receive the DATA for A. To use multicast communication, the destination list registers to multicast-group by using IGMP



protocol. The multicast-group consists of 'Group hardware address', 'Group IP address' and 'Group port number'. User cannot change the 'Group hardware address' and 'Group IP address'. But the 'Group port number' can be changed to what user wants.

The 'Group hardware address' is selected at the assigned range (From "01:00:5e:00:00" to "01:00:5e:7f:ff:ff") and the 'Group IP address' is selected in D-class IP address (From "224.0.0.0" to "239.255.255.255", please refer to the website; http://www.iana.org/assignments/multicast-addresses). When selecting, the upper 23bit of 6bytes 'Group hardware address' and the 4bytes 'Group IP address' must be the same. For example, if the user selects the 'Group IP address' to "244.1.1.11", the 'Group hardware is selected to "01:00:5e:01:01:0b". Please refer to the "RFC1112" address' (http://www.ietf.org/rfc.html).

In the W7100A, IGMP processing to register the multicast-group is internally (automatically) processed. When the user opens the SOCKET *n* with multicast mode, the "Join" message is internally transmitted. If the user closes it, the "Leave" message is internally transmitted. After the SOCKET opens, the "Report" message is periodically and internally transmitted when the user communicates.

The W7100A support IGMP version 1 and version 2 only. If user wants use an updated version, the host processes IGMP directly by using the IPRAW mode SOCKET.

SOCKET Initialization

Choose one SOCKET for multicast communication among 8 SOCKETS of W7100A. Then set the Sn_DHAR0 to 'Multicast-group hardware address' and set the Sn_DIPR0 to 'Multicast-group IP address'. Then set the Sn_PORT0 and Sn_DPORT0 to 'Multicast-group port number'. Then set the Sn_MR(P3:P0) to UDP and set the Sn_MR(MULTI) to '1'. Finally execute OPEN command. If the state of Sn_SR is changed to SOCK_UDP after the OPEN command, the SOCKET initialization is completed.

{	
START:	
<pre>/* set Multicast-Group</pre>	information */
Sn_DHAR0 = 0x01;	/* set Multicast-Group H/W address(01:00:5e:01:01:0b) */
Sn_DHAR1 = 0x00;	
Sn_DHAR2 = 0x5E;	
Sn_DHAR3 = 0x01;	
$Sn_DHAR4 = 0x01;$	
Sn_DHAR5 = 0x0B;	
Sn_DIPR0 = 211;	/* set Multicast-Group IP address(211.1.1.11) */
Sn_DIPR1 = 1;	
Sn_DIPR2 = 1;	



}

```
Sn_DIRP3 = 11;
Sn_DPORT = 0x0BB8;  /* set Multicast-Group Port number(3000) */
Sn_PORT = 0x0BB8;  /* set Source Port number(3000) */
Sn_MR = 0x02 | 0x80; /* set UDP mode & Multicast on SOCKET n Mode Register */
Sn_CR = OPEN;  /* set OPEN command */
/* wait until Sn_SR is changed to SOCK_UDP */
if (Sn_SR != SOCK_UDP) Sn_CR = CLOSE; goto START;
```

Check received data

Refer to the section 9.2.2.1 'Unicast & Broadcast'.

Receiving process

Refer to the section 9.2.2.1 'Unicast & Broadcast'.

Check send data / Sending Process

Since the user sets the information about multicast-group at SOCKET initialization, user does not need to set IP address and port number for destination any more. Therefore, copy the transmission data to internal TX memory and executes SEND command.

```
{/* first, get the free TX memory size */
FREESIZE:
   freesize = Sn_TX_FSR;
   if (freesize < len) goto FREESIZE; // len is send size
   /* calculate offset address */
   dst_mask = Sn_TX_WR & gSn_TX_MASK; // dst_mask is offset address
   /* calculate start address(physical address) */
   dst_ptr = gSn_TX_BASE + dst_mask;
                                         // dst_ptr is physical start address
   /* if overflow SOCKET TX memory */
   if ((dst_mask + len) > (gSn_TX_MASK + 1))
   {/* copy upper_size bytes of source_addr to dst_ptr */
      upper_size = (gSn_TX_MASK + 1) - dst_mask;
      wizmemcpy((0x000000 + source_addr), (0xFE0000 + dst_ptr), upper_size);
      /* update source_addr*/
      source_addr += upper_size;
      /* copy left_size bytes of source_addr to gSn_TX_BASE */
      left_size = len - upper_size;
      wizmemcpy((0x000000 + source_addr), (0xFE0000 + gSn_TX_BASE), left_size);
   }
```

WIZnet

}

```
else
{/* copy len bytes of source_addr to dst_ptr */
    wizmemcpy((0x000000 + source_addr), (0xFE0000 + dst_ptr), len);
}
/* increase Sn_TX_WR as length of len */
Sn_TX_WR += send_size;
/* set SEND command */
Sn_CR = SEND;
```

Check complete sending / Timeout

Since the host manages all protocol process for data communication, the timeout cannot occur.

```
{/* check SEND command completion */
while(Sn_IR(SENDOK)=='0'); /* wait interrupt of SEND completion */
Sn_IR(SENDOK) = '1'; /* clear previous interrupt of SEND completion */
}
```

```
Check finished / SOCKET close
```

Refer to the section 9.2.2.1 'Unicast & Broadcast'.

9.2.3 IPRAW

The IPRAW is data communication using TCP, UDP and IP layers which are the lower protocol layers. The IPRAW supports IP layer protocol such as ICMP (0x01) and IGMP (0x02) according to the protocol number. The 'ping' of ICMP or IGMP v1/v2 is already included in W7100A by hardware logic. But if the user needs, the host can directly process the IPRAW by opening the SOCKET *n* to IPRAW. In the case of using IPRAW mode, user must set the protocol number field of the IP header to what the user wants to use. The protocol number is defined by IANA. Refer to the web (<u>http://www.iana.org/assignments/protocol-numbers</u>). The protocol number must be configured to Sn_PROTO before 'SOCKET open'. In the IPRAW mode, the W7100A does not support TCP (0x06) or UDP (0x11) protocol number. The SOCKET communication of IPRAW mode only allows the communication of an assigned protocol data such as IGMP.






Figure 9.7 IPRAW Operation Flow

SOCKET Initialization

Select the SOCKET and set the protocol number. Then set the Sn_MR(P3:P0) to IPRAW mode and execute 'OPEN' command. If the Sn_SR is changed to SOCK_IPRAW after the 'OPEN' command, the SOCKET initialization is completed.

```
{
START:
    /* sets Protocol number, the protocol number is used in Protocol Field of IP Header. */
    Sn_PROTO = protocol_num;
    /* sets IP raw mode */
    Sn_MR = 0x03;
    /* sets OPEN command */
    Sn_CR = OPEN;
    /* wait until Sn_SR is changed to SOCK_IPRAW */
    if (Sn_SR != SOCK_IPRAW) Sn_CR = CLOSE; goto START;
}
```

Check received data

Refer to the section 9.2.2.1 'Unicast & Broadcast'.

Receiving process

Process the IPRAW data which is received in internal RX memory. The structure of received IPRAW data is as below.



 PACKET-INF	0	DATA packet		
Destination IP Address	Byte size of DATA packet	Real Data		
4 Bytes	2 Bytes	Size speicified in PACKET-INFO		
Figure 9.8 The received IPRAW data format				

The IPRAW data consists of 6bytes PACKET-INFO and DATA packet. The PACKET-INFO contains information about the transmitter (IP address) and the length of the DATA-packet. The data reception of IPRAW is the same as UDP data reception except processing the port number of the transmitter in UDP PACKET-INFO. Refer to the section 9.2.2.1 'Unicast & Broadcast'.

If the transmitted DATA size is larger than RX memory free size of SOCKET n, user cannot receive that DATA and also cannot receive fragmented DATA.

Check send data / Sending process

The size of DATA which user wants to transmit cannot be larger than Internal TX memory and default MTU. The transmission of IPRAW data is the same as transmission of UDP data except setting 'Destination port number'. Refer to the section 9.2.2.1 'Unicast & Broadcast'.

Complete sending / Timeout
 Same as UDP, please refer to the section 9.2.2 'UDP'.

Check finished / SOCKET closed

Same as UDP, please refer to the section 9.2.2 'UDP'.

9.2.4 MACRAW

The MACRAW communication is based on Ethernet MAC, and it can flexibly use upper layer protocol to suit the host's needs.

The MACRAW mode can only be used with a SOCKET. If the user uses the SOCKET in MACRAW mode, not only can it use the SOCKET1~7 in the 'Hardwired TCP/IP stack', but it can also be used as a NIC (Network Interface Controller). Therefore, any SOCKET1~7 can be used with 'Software TCP/IP stack'. Since the W7100A supports 'Hardwired TCP/IP stack' and 'Software TCP/IP stack', it calls 'Hybrid TCP/IP stack'. If user wants more SOCKETs beyond the supported 8 SOCKETS, the SOCKET in which the user wants high performance should be utilizing the "Hardwired TCP/IP stack', and the others should be using 'Software TCP/IP stack' by MACRAW mode. So it overcomes the limited capacity of 8 SOCKETS. The SOCKET of MACRAW mode can process all protocols except using in SOCKET1~7. Since the MACRAW communication is pure Ethernet packet communication (there is no other processing), the MACRAW designer should use the 'Software TCP/IP stack' to process the protocol. The



MACRAW data should basically contain the 6bytes of 'Source hardware address', 6bytes of 'destination hardware address' and 2bytes of 'Ethernet type' because it is based on Ethernet MAC.




Figure 9.9 MACRAW Operation Flow

SOCKET Initialization

Select the SOCKET and set the SN_MR(P3:P0) to MACRAW mode. Then execute the 'OPEN' command. After the 'OPEN' command, if the Sn_SR is successfully changed to 'SOCK_MACRAW', the SOCKET initialization is completed. Since all information about communication (Source hardware address, Source IP address, Source port number, Destination hardware address, Destination IP address, Destination port number, Protocol header, etc.) is in the 'MACRAW data', there is no more register setting.

```
{
START:
    /* sets MAC raw mode */
    S0_MR = 0x04;
    /* sets OPEN command */
    S0_CR = OPEN;
    /* wait until Sn_SR is changed to SOCK_MACRAW */
    if (S0_SR != SOCK_MACRAW) S0_CR = CLOSE; goto START;
```

}

Check received data


Refer to the section 9.2.2.1 'Unicast & Broadcast'.



Receiving process

Process the MACRAW data of the SOCKET which received it in internal RX memory. The structure of the MACRAW data is as below:

PACKET-INFO	DATA packet	CRC
Byte size of	Real Data	Cyclic Redundancy
DATA packet	Destination MAC Source MAC Type Payload (6Bytes) (6Bytes) (2Bytes) (46~1500Bytes)	Check
2 Bytes	Size speicified in PACKET-INFO	4 Bytes



The MACRAW data consists of 'PACKET-INFO', 'DATA packet' and 4bytes CRC. The 'PACKET-INFO' is the length of the DATA packet. The 'DATA packet' consists of 6bytes 'Destination MAC address', 6bytes 'Source MAC address' and 2bytes 'Type', 46~1500 bytes 'Payload'. The 'Payload' of DATA packet consists of Internet protocol such as ARP, IP according to the 'Type'. The details of 'Type' please refer to the web:

(http://www.iana.org/assignments/ethernet-numbers)

```
/* calculate offset address */
{
  src_mask = S0_RX_RD & gS0_RX_MASK;
                                           // src_mask is offset address
  /* calculate start address(physical address) */
  src_ptr = gS0_RX_BASE + src_mask; // src_ptr is physical start address
  /* get the size of packet */
  len = get_Byte_sizeof_DATA_packet(); // Read the 2bytes PACKET-INFO
  /* if overflow SOCKET RX memory */
  If((src_mask + Ien) > (gSO_RX_MASK + 1))
  { /* copy upper_size bytes of get_start_address to destination_address */
     upper_size = (gS0_RX_MASK + 1) - src_mask;
     wizmemcpy((0xFE0000 + src_ptr), (0x000000 + destination_address), upper_size);
     /* update destination_address */
     destination_address += upper_size;
     /* copy left_size bytes of gSn_RX_BASE to destination_address */
     left_size = len - upper_size;
     wizmemcpy((0xFE0000 + src_ptr), (0x000000 + destination_address), left_size);
  }
  else
  { /* copy len bytes of src_ptr to destination_address */
     wizmemcpy((0xFE0000 + src_ptr), (0x000000 + destination_address), len);
  }
      increase Sn_RX_RD as length of len */
  /*
```



```
S0_RX_RD += len;

/* extract 4 bytes CRC from internal RX memory and then ignore it */

wizmemcpy((0xFE0000 + src_ptr), (0x000000 + dummy), len);

/* set RECV command */

S0_CR = RECV;
```

<Notice>

}

If the free size of the internal RX memory is smaller than the MACRAW data, a problem may occasionally occur where some parts of that PACKET-INFO and DATA packet are stored to the internal RX memory. Since the problem occurs as an analysis error for PACKET-INFO, it cannot process the MACRAW data correctly. The closer the internal RX memory is to being full, the higher the probability is for an error to occur. This problem can be resolved if user allows some loss of the MACRAW data.

The solution is as follows:

- Process the internal RX memory as fast as possible to prevent that it closes to full.
- Reduce the receiving load by reception only its MACRAW data by setting the MF (MAC Filter) bit of S0_MR in sample code of SOCKET initialization.

```
{
START:
/* sets MAC raw mode with enabling MAC filter */
S0_MR = 0x44;
/* sets OPEN command */
S0_CR = OPEN;
/* wait until Sn_SR is changed to SOCK_MACRAW */
if (Sn_SR != SOCK_MACRAW) S0_CR = CLOSE; goto START;
}
```

 If the free size of the internal RX memory is smaller than '1528 - Default MTU(1514)+PACKET-INFO(2) + DATA packet(8) + CRC(4)', close the SOCKET and process all received data. Then reopen the SOCKET. After closing the SOCKET, the received MACRAW data from closing time can be lost.

```
{/* check the free size of internal RX memory */
if((S0_RXMEM_SIZE(0) * 1024) - S0_RX_RSR(0) < 1528)
{
    received_size = S0_RX_RSR(0); /* backup Sn_RX_RSR */
    S0_CR = CLOSE; /* SOCKET Closed */
    while(S0_SR != SOCK_CLOSED); /* wait until SOCKET is closed */</pre>
```



```
/* process all data remained in internal RX memory */
   while(recved_size > 0)
   {/* calculate offset address */
       src_mask = S0_RX_RD & gS0_RX_MASK; // src_mask is offset address
       /* calculate start address(physical address) */
       src_ptr = gS0_RX_BASE + src_mask; // src_ptr is physical start address
       /* if overflow SOCKET RX memory */
       If((src_mask + Ien) > (gSO_RX_MASK + 1))
       {/* copy upper_size bytes of get_start_address to destination_address */
         upper_size = (gS0_RX_MASK + 1) - src_mask;
       wizmemcpy((0xFE0000 + src_ptr), (0x000000 + destination_address), upper_size);
         /* update destination_address */
         destination_address += upper_size;
         /* copy left_size bytes of gSn_RX_BASE to destination_address */
         left_size = len - upper_size;
         wizmemcpy((0xFE0000 + src_ptr), (0x000000 + destination_address), left_size);
       }
       else
       { /* copy len bytes of src_ptr to destination_address */
         wizmemcpy((0xFE0000 + src_ptr), (0x000000 + destination_address), len);
       }
       /* increase Sn_RX_RD as length of len */
       S0_RX_RD += len;
       /* extract 4 bytes CRC from internal RX memory and then ignore it */
       wizmemcpy((0xFE0000 + src_ptr), (0x000000 + dummy), len);
       /* calculate the size of remained data in internal RX memory*/
       recved_size = recved_size - 2 - len - 4;
   }
   /* Reopen the SOCKET */
   /* sets MAC raw mode with enabling MAC filter */
   S0_MR = 0x44; /* or S0_MR = 0x04 */
   /* sets OPEN command */
   SO_CR = OPEN;
   /* wait until Sn_SR is changed to SOCK_MACRAW */
   while (S0_SR != SOCK_MACRAW);
}
else /* process normally the DATA packet from internal RX memory */
{/* This block is same as the code of "Receiving process" stage*/
```



}

Check send data / Sending process

The size of the data which the user wants to transmit cannot be larger than the internal TX memory and default MTU. The host generates the MACRAW data in the same format as the "Receiving process" data packet, and transmits it. At this time, if the size of the generated data is smaller than 60bytes, the transmitted Ethernet packet internally fills to 60bytes by "Zero padding" and then it is transmitted.

```
{/* first, get the free TX memory size */
FREESIZE:
   freesize = S0_TX_FSR;
   if (freesize < send_size) goto FREESIZE;
   /* calculate offset address */
   dst_mask = Sn_TX_WR & gSn_TX_MASK; // dst_mask is offset address
   /* calculate start address(physical address) */
   dst_ptr = gSn_TX_BASE + dst_mask; // dst_ptr is physical start address
   /* if overflow SOCKET TX memory */
   if (dst_mask + len) > (gSn_TX_MASK + 1))
   {/* copy upper_size bytes of source_addr to dst_ptr */
      upper_size = (gSn_TX_MASK + 1) - dst_mask;
      wizmemcpy((0x000000 + source_addr), (0xFE0000 + dst_ptr), upper_size);
      /* update source_addr*/
      source_addr += upper_size;
      /* copy left_size bytes of source_addr to gSn_TX_BASE */
      left_size = len - upper_size;
      wizmemcpy((0x000000 + source_addr), (0xFE0000 + gS0_TX_BASE), left_size);
   }
   else
   {/* copy len bytes of source_addr to dst_ptr */
      wizmemcpy((0x000000 + source_addr), (0xFE0000 + dst_ptr), len);
   }
   /* increase Sn_TX_WR as length of len */
   S0_TX_WR += send_size;
   /* set SEND command */
   SO_CR = SEND;
}
```



Check complete sending

Since the host manages all protocol processors to communicate, the timeout can not be occurred.

{/* check SEND command completion */			
while(S0_IR(SENDOK)=='0');			
S0_IR(SENDOK) = '1';	/* clear previous interrupt of SEND completion */		
3			

■ Check finished / SOCKET close

Refer to the section 9.2.2.1 'Unicast & Broadcast'.



10 Electrical Specification

10.1 Absolute Maximum Ratings

Symbol	Parameter	Rating	Unit
V_{DD}	DC supply voltage	-0.5 to 3.6	V
V _{IN}	DC input voltage	-0.5 to 5.5 (5V tolerant)	V
M		0 to 3.3 (GPIO)	v
V _{OUT}	DC output voltage	-0.5 to 3.6 (Others)	v
I _{IN}	DC input current	±5	mA
I _{OUT}	DC output current	2 to 8	mA
T _{OP}	Operating temperature	-40 to 80	°C
T _{STG}	Storage temperature	-55 to 125	°C

*COMMENT: Stressing the device beyond the "Absolute Maximum Ratings" may cause permanent damage.


10.2 DC Characteristics

Symbol	Parameter	Test Condition	Min	Тур	Max	Unit
V _{DD}	DC Supply voltage	Junction	3.0	3.3	3.6	V
		temperature is from				
		-55°C to 125°C				
V _{IH}	High level input voltage		2.0		5.5	V
V _{IL}	Low level input voltage		- 0.5		0.8	V
V _{OH}	High level output voltage	Iон = 2 ~ 16 mA	2.4			V
V _{OL}	Low level output voltage	Iol = -2 ~ -12 mA			0.4	V
l _i	Input Current	$V_{IN} = V_{DD}$			±5	μA
Ι _Ο	Output Current	$V_{OUT} = V_{DD}$	2		8	mA

10.3 Power consumption(Driving voltage 3.3V)


Symbol	Parameter	Test Condition	Max	Unit
I _{Boot}	Current consumption	Booting	250	mA
I _{ldle}	Current consumption	Idle state	220	mA
I _{Active}	Current consumption	Whole 8 SOCKETs running	220	mA
I _{Power-down}	Current consumption	Power-down mode	108	mA

WIZnet



	Description		Max
1	1 Reset Cycle Time		-
2	PLL Lock-in Time	50 us	10 ms

External memory access timing






Description		Min	Max
t _{ALE}	ALE signal duration = ALECON register value + 1 clock (clock speed = 88.4736MHz)	1 clock	256 clock
T _{access}	External memory access period = 3us + EXTWTST register value	3 us	744us

10.5 Crystal Characteristics

Parameter	Range	
Frequency	25 MHz	
Frequency Tolerance (at 25℃)	±30 ppm	
Shunt Capacitance	7pF Max	
Drive Level	1 ~ 500uW (100uW typical)	
Load Capacitance	18pF	
Aging (at 25℃)	±3ppm / year Max	



10.6 Transformer Characteristics



In the case of using the internal PHY mode, be sure to use symmetric transformer in order to support Auto MDI/MDIX (Crossover).

In the case of using the External PHY mode, use the transformer which is suitable for external PHY specification.





11 IR Reflow Temperature Profile (Lead-Free)

Moisture Sensitivity Level: 3

Dry Pack Required: Yes

Average RAMp-Up Rate	3° C/second max.	
(Ts _{max} to Tp)		
Preheat		
- Temperature Min (Ts _{min})	150 °C	
- Temperature Max (Ts _{max})	200 °C	
- Time (ts _{min} to ts _{max})	60-180 seconds	
Time maintained above:		
- Temperature (TL)	217 °C	
- Time (tL)	60-150 seconds	
Peak/Classification Temperature (Tp)	260 + 0 °C	
Time within 5 °C of actual Peak Temperature (tp)	20-40 seconds	
RAMp-Down Rate	6 °C/second max.	
Time 25 °C to Peak Temperature	8 minutes max.	







SYMBOL		MILLIMETER			INCH			
STIMBUL	MIN.	NOM.	MAX.	MIN.	NOM.	MAX.		
А	-	-	1.60	-	-	0.063		
A ₁	0.05	-	0.15	0.002	-	0.006		
A ₂	1.35	1.40	1.45	0.053	0.055	0.057		
b	0.17	0.22	0.27	0.007	0.009	0.011		
b ₁	0.17	0.20	0.23	0.007	0.008	0.009		
С	0.09	-	0.20	0.004	-	0.008		
C ₁	0.09	-	0.16	0.004	-	0.006		
D	15.85	16.00	16.15	0.624	0.630	0.636		
D ₁	13.90	14.00	14.10	0.547	0.551	0.555		
E	15.85	16.00	16.15	0.624	0.630	0.636		
E ₁	13.90	14.00	14.10	0.547	0.551	0.555		
е		0.50 BSC			0.020 BSC			
L	0.45	0.60	0.75	0.018	0.024	0.030		
L ₁		1.00 REF		0.039 REF				
R ₁	0.08	-	-	0.003	-	-		
R ₂	0.08	-	0.20	0.003	-	0.008		
S	0.20	-	-	0.008	-	-		
θ	0°	3.5°	7°	0°	3.5°	7°		
θ ₁	0°	-	-	0°	-	-		
θ ₂	12° TYP				12° TYP			
θ ₃		12° TYP			12° TYP			

Note :


① To be determined at seating plane - C -.

- (2) Dimensions ' D_1 ' and ' E_1 ' do not include mold protrusion. D_1 ' and ' E_1 ' are maximum plastic body size dimensions including mold mismatch.
- ③ Dimension 'b' does not include dambar protrusion. Dambar cannot be located on the lower radius or the foot.
- ④ Exact shape of each corner is optional
- (5) These Dimensions apply to the flat section of the lead between 0.10mm and 0.25mm from the lead tip.
- 6 A₁ is defined as the distance from the seating plane to the lowest point of the package body.
- ⑦ Controlling dimension : Millimeter
- (8) Reference Document : JEDEC MS-026 , BED.



12.2 Package type: QFN 64

* CONTROLLING DIMENSION: mm





CVMDOL		MILLIMETER	2	INCH		
SYMBOL	MIN.	NOM.	MAX.	MIN.	NOM.	MAX.
А	-	-	0.90	-	-	0.035
A1	-	-	0.05	-	-	0.002
A2	-	0.65	0.70	-	0.026	0.028
A3		0.200 REF.			0.008 REF.	
b	0.18	0.25	0.30	0.007	0.010	0.012
D	15.85	16.00	16.15	0.624	0.630	0.636
D	9.00 bsc			0.354 bsc		
D2	5.90	6.00	6.10	0.232	0.236	0.240
E		9.00 bsc			0.354 bsc	
E2	5.90	6.00	6.10	0.232	0.236	0.240
L	0.35	0.40	0.45	0.014	0.016	0.018
е		0.50 bsc		0.020 bsc		
R	0.09	-	-	0.004	-	-
	ТО	LERANCES (OF FORM A	ND POSITIO	N	
ааа	0.10			0.004		
bbb	0.10			0.004		
ССС		0.05			0.002	

Note:

- 1 All dimensions are in millimeters.
- 2 Die thickness allowable is 0.305mm maximum (0.012 inches maximum).
- ③ Dimensioning & tolerances conform to ASME Y14.5M. -1994.
- ④ The pin #1 identifier must be placed on the top surface of the package by using indentation mark of other feature of package body.
- (5) Exact shape and size of this feature is optional.
- 6 Package WARPAGE max 0.08mm.
- ⑦ Applied for exposed pad and terminals, exclude embedding part of exposed pad from measuring.
- (8) Applied to terminals.



13 Appendix:Performance Improvement about W7100A

This section presents the benefits gained about calculation by using W7100A over standard 8051 family.

13.1 Summary

The 8-bit operation cycles of the 80C51 and W7100A with addition, subtraction, multiplication and division are as below. It is briefly shows its performance. The W7100A with 'wizmemcpy' (supported by WIZnet) function is almost 9 times faster than the 80C51.

	80C51 cycle	W7100A cycle / with	W7100A cycle / with
		user code	wizmemcpy
ADD	36	12	4
SUB	36	12	4
MUL	96	12	6
DIV	96	20	10

In the succeeded section shows more detail performance.

13.2 8-Bit Arithmetic Functions

13.2.1 Addition

Immediate data

The following code performs immediate data (constant) addition to an 8-bit register.

RX = RX + #n

Mner	nonic	Opcode	Byte	80C51 Cycle	W7100A Cycle	
					ISP /	FLASH /
					wizmemcpy	user code
MOV	A, Rx	E8h - EFh	1	12	1	4
ADD	A, #n	24h	2	12	2	4
MOV	Rx, A	F8h - FFh	1	12	1	4
Sum :			36	4	12	

Note. 'wizmemcpy' function are built-in inside Boot ROM in W7100A. Refer to the 'Driver Guide.'

Direct addressing

The following code performs direct addressing addition to an 8-bit register.

Rx = Rx + (dir)



Mner	nonic	Opcode	Byte	80C51 Cycle	W7100A Cycle	
					ISP /	FLASH /
					wizmemcpy	user code
MOV	A, Rx	E8h - EFh	1	12	1	4
ADD	A, dir	25h	2	12	2	4
MOV	Rx, A	F8h - FFh	1	12	1	4
Sum :			36	4	12	

Indirect addressing

The following code performs indirect addressing addition to an 8-bit register.

Rx = Rx + (@Rx)

Mnemonic Opcode		Opcode	Byte	80C51 Cycle	W7100A Cycle	
					ISP /	FLASH /
					wizmemcpy	user code
MOV	A, Rx	E8h - EFh	1	12	1	4
ADD	A, @Rx	26h - 27h	1	12	2	4
MOV	Rx, A	F8h - FFh	1	12	1	4
Sum :				36	4	12

Register addressing

The following code performs an 8-bit register to register addition.

Rx = Rx + Ry

Mner	nonic	Opcode	Byte	80C51 Cycle	W7100A Cycle	
					ISP /	FLASH /
					wizmemcpy	user code
MOV	A, Rx	E8h - EFh	1	12	1	4
ADD	A, Ry	28h - 2Fh	1	12	1	4
MOV	Rx, A	F8h - FFh	1	12	1	4
Sum :			36	3	12	



13.2.2 Subtraction

Immediate data

The following code performs immediate data (constant) subtraction from an 8-bit register.

 $\mathsf{R}\mathsf{x} = \mathsf{R}\mathsf{x} - \#n$

Mner	nonic	Opcode	Byte	80C51 Cycle	W7100A Cycle	
					ISP /	FLASH /
					wizmemcpy	user code
MOV	A, Rx	E8h - EFh	1	12	1	4
SUBB	A, #n	24h	2	12	2	4
MOV	Rx, A	F8h - FFh	1	12	1	4
Sum :			36	4	12	

Direct addressing

The following code performs direct addressing subtraction from an 8-bit register.

Rx = Rx - (dir)

Mner	Mnemonic Opcode		Byte	80C51 Cycle	W7100A Cycle	
					ISP /	FLASH /
					wizmemcpy	user code
MOV	A, Rx	E8h - EFh	1	12	1	4
SUBB	A, dir	25h	2	12	2	4
MOV	Rx, A	F8h - FFh	1	12	1	4
Sum :			36	4	12	

■ Indirect addressing subtraction

The following code performs indirect addressing subtraction from an 8-bit register.

Rx = Rx - (@Ry)

Mnei	monic	Opcode	Byte	80C51 Cycle	W7100A Cycle	
					ISP /	FLASH /
					wizmemcpy	user code
MOV	A, Rx	E8h – EFh	1	12	1	4
SUBB	A, @Ry	26h - 27h	1	12	2	4
MOV	Rx, A	F8h - FFh	1	12	1	4
Sum :				36	4	12

Register addressing subtraction

The following code performs an 8-bit register from register subtraction.



Rx = Rx - Ry								
Mner	Inemonic Opcode		Byte	80C51 Cycle	W7100A Cycle			
					ISP /	FLASH /		
					wizmemcpy	user code		
MOV	A, Rx	E8h - EFh	1	12	1	4		
SUBB	A, Ry	28h - 2Fh	1	12	1	4		
MOV	Rx, A	F8h - FFh	1	12	1	4		
Sum :				36	3	12		

13.2.3 Multiplication

The following code performs the 8-bit register multiplication.

Rx = Rx * RyMnemonic Opcode Byte 80C51 Cycle W7100A Cycle ISP / FLASH / user code wizmemcpy MOV A, Rx E8h - EFh 1 12 1 4 MOV B, Ry 88h - 8Fh 2 24 2 4 AB 2 MUL A4h 1 48 4 MOV Rx, A F8h - FFh 1 12 1 4 Sum : 96 6 12

13.2.4 Division

The following code performs the 8-bit register division.

Rx = Rx / Ry

Mner	monic	Opcode	Byte	80C51 Cycle	W7100A Cycle	
				-	ISP /	FLASH /
					wizmemcpy	user code
MOV	A, Rx	E8h - EFh	1	12	1	4
MOV	B, Ry	88h - 8Fh	2	24	2	4
DIV	AB	84h	1	48	6	8
MOV	Rx, A	F8h - FFh	1	12	1	4
Sum :			96	10	20	

13.3 16-Bit Arithmetic Functions

13.3.1 Addition

The following code performs 16-bit addition. The first operand and result are located in registers pair RaRb. The second operand is located in registers pair RxRy.



RaRb = RaRb + RxRy							
Mner	nonic	Opcode	Byte	80C51 Cycle	W7100A Cycle		
					ISP /	FLASH /	
					wizmemcpy	user code	
MOV	A, Rb	E8h - EFh	1	12	1	4	
ADD	A, Ry	28h - 2Fh	1	12	1	4	
MOV	Rb, A	F8h - FFh	1	12	1	4	
MOV	A, Ra	E8h - EFh	1	12	1	4	
ADDC	A, Rx	38h - 3Fh	1	12	1	4	
MOV	Ra, A	F8h - FFh	1	12	1	4	
		Sum :		72	6	24	

13.3.2 Subtraction

The following code performs 16-bit subtraction. The first operand and result are located in registers pair RaRb. The second operand is located in registers pair RxRy.

		, it j				
Mner	nonic	Opcode	Byte	80C51 Cycle	W7100A Cycle	
					ISP /	FLASH /
					wizmemcpy	user code
CLR	С	C3h	1	12	1	4
MOV	A, Rb	E8h - EFh	1	12	1	4
SUBB	A, Ry	98h - 9Fh	1	12	1	4
MOV	Rb, A	F8h - FFh	1	12	1	4
MOV	A, Ra	E8h - EFh	1	12	1	4
SUBB	A, Rx	98h - 9Fh	1	12	1	4
MOV	Ra, A	F8h - FFh	1	12	1	4
		Sum :		84	7	28

RaRb = RaRb - RxRy

13.3.3 Multiplication

The following code performs 16-bit multiplication. The first operand and result are located in registers pair RaRb. The second operand is located in registers pair RxRy.

Mnemonic		Opcode	Byte	80C51 Cycle	W7100A Cycle	
					ISP /	FLASH /
					wizmemcpy	user code
MOV	A, Rb	E8h - EFh	1	12	1	4



MOV	B, Ry	88h - 8Fh	2	24	2	4
MUL	AB	A4h	1	48	2	4
MOV	Rz, B	A8h - AFh	2	24	3	4
ХСН	A, Rb	C8h - CFh	1	12	2	4
MOV	B, Rx	88h - 8Fh	2	24	2	4
MUL	AB	A4h	1	48	2	4
ADD	A, Rz	28h - 2Fh	1	12	1	4
ХСН	A, Ra	C8h - CFh	1	12	2	4
MOV	B, Ry	88h - 8Fh	2	24	2	4
MUL	AB	A4h	1	48	2	4
ADD	A, Ra	28h - 2Fh	1	12	1	4
MOV	Ra, A	F8h - FFh	1	12	1	4
		Sum :		312	23	52

13.4 32-bit Arithmetic Functions

13.4.1 Addition

The following code performs 32-bit addition. The first operand and result are located in four registers RaRbRcRd. The second operand is located in four registers RvRxRyRz.

RaRbRcRd = RaRbRcRd + RvRxRyRz

Mnemonic		Opcode	Byte	80C51 Cycle	W7100A Cycle	
				-	ISP /	FLASH /
					wizmemcpy	user code
MOV	A, Rd	E8h - EFh	1	12	1	4
ADD	A, Rz	28h - 2Fh	1	12	1	4
MOV	Rd, A	F8h - FFh	1	12	1	4
MOV	A, Rc	E8h - EFh	1	12	1	4
ADDC	A, Ry	38h - 3Fh	1	12	1	4
MOV	Rc, A	F8h - FFh	1	12	1	4
MOV	A, Rb	E8h - EFh	1	12	1	4
ADDC	A, Rx	38h - 3Fh	1	12	1	4
MOV	Rb, A	F8h - FFh	1	12	1	4
MOV	A, Ra	E8h - EFh	1	12	1	4
ADDC	A, Rv	38h - 3Fh	1	12	1	4
MOV	Ra, A	F8h - FFh	1	12	1	4
		Sum :		144	12	48



13.4.2Subtraction

The following code performs 32-bit subtraction. The first operand and result are located in four registers RaRbRcRd. The second operand is located in four registers RvRxRyRz.

RaRbRcRd = RaRbRcRd - RvRxRyRz

Mnemonic		Opcode	Byte	80C51 Cycle	W7100A Cycle	
					ISP /	FLASH /
					wizmemcpy	user code
CLR	С	C3h	1	12	1	4
MOV	A, Rd	E8h - EFh	1	12	1	4
SUBB	A, Rz	98h - 9Fh	1	12	1	4
MOV	Rd, A	F8h - FFh	1	12	2	4
MOV	A, Rc	E8h - EFh	1	12	1	4
SUBB	A, Ry	98h - 9Fh	1	12	2	4
MOV	Rc, A	F8h - FFh	1	12	2	4
MOV	A, Rb	E8h - EFh	1	12	1	4
SUBB	A, Rx	98h - 9Fh	1	12	1	4
MOV	Rb, A	F8h - FFh	1	12	1	4
MOV	A, Ra	E8h - EFh	1	12	1	4
SUBB	A, Rv	98h - 9Fh	1	12	1	4
MOV	Ra, A	F8h - FFh	1	12	1	4
	Sum :			156	13	52

13.4.3Multiplication

The following code performs 32-bit multiplication. The first operand and result are located in four registers RaRbRcRd. The second operand is located in four registers RvRxRyRz.

RaRbRcRd = RaRbRcRd * RvRxRyRz

nonic	Opcode	Byte	80C51 Cycle	W7100/	A Cycle
				ISP /	FLASH /
				wizmemcpy	user code
A, R0	E8h - EFh	1	12	1	4
B, R7	88h - 8Fh	2	24	2	4
AB	A4h	1	48	2	4
A, R4	C8h - CFh	1	12	2	4
B, R3	88h - 8Fh	2	24	2	4
AB	A4h	1	48	2	4
A, R4	28h - 2Fh	1	12	1	4
R4, A	F8h - FFh	1	12	1	4
	B, R7 AB A, R4 B, R3 AB A, R4	A, R0 E8h - EFh B, R7 88h - 8Fh AB A4h A, R4 C8h - CFh B, R3 88h - 8Fh AB A4h A, R4 C8h - CFh A, R4 28h - 2Fh	A, R0 E8h - EFh 1 B, R7 88h - 8Fh 2 AB A4h 1 A, R4 C8h - CFh 1 B, R3 88h - 8Fh 2 AB A4h 1 A, R4 C8h - 2Fh 1 AB A4h 1 A, R4 28h - 2Fh 1	A, R0 E8h - EFh 1 12 B, R7 88h - 8Fh 2 24 AB A4h 1 48 A, R4 C8h - CFh 1 12 B, R3 88h - 8Fh 2 24 AB A4h 1 48 A, R4 C8h - CFh 1 12 B, R3 88h - 8Fh 2 24 AB A4h 1 48 A, R4 28h - 2Fh 1 12	ISP / ISP / ISP / wizmemcpy A, R0 E8h - EFh 1 12 1 B, R7 88h - 8Fh 2 24 2 AB A4h 1 48 2 A, R4 C8h - CFh 1 12 2 B, R3 88h - 8Fh 2 24 2 AB A4h 1 48 2 A, R4 C8h - CFh 1 12 2 A, R4 28h - 2Fh 1 12 1

VIZn	VIZnet					
MOV	A, R1	E8h - EFh	1	12	1	4
MOV	B, R6	88h - 8Fh	2	24	2	4
MUL	AB	A4h	1	48	2	4
ADD	A, R4	28h - 2Fh	1	12	1	4
MOV	R4, A	F8h - FFh	1	12	1	4
MOV	B, R2	88h - 8Fh	2	24	2	4
MOV	A, R5	E8h - EFh	1	12	2	4
MUL	AB	A4h	1	48	2	4
ADD	A, R4	28h - 2Fh	1	12	1	4
MOV	R4, A	F8h - FFh	1	12	1	4
MOV	A, R2	E8h – EFh	1	12	1	4
MOV	B, R6	88h - 8Fh	2	24	2	4
MUL	AB	A4h	1	48	2	4
XCH	A, R5	C8h - CFh	1	12	2	4
MOV	R0, B	A8h - AFh	2	24	3	4
MOV	B, R3	88h - 8Fh	2	24	2	4
MUL	AB	A4h	1	48	2	4
ADD	A, R5	28h - 2Fh	1	12	1	4
XCH	A, R4	C8h - CFh	1	12	2	4
ADDC	A, R0	38h - 3Fh	1	12	1	4
ADD	А, В	25h	2	12	2	4
MOV	R5, A	F8h - FFh	1	12	1	4
MOV	A, R1	E8h - EFh	1	12	1	4
MOV	B, R7	88h - 8Fh	2	24	2	4
MUL	AB	A4h	1	48	2	4
ADD	A, R4	28h - 2Fh	1	12	1	4
ХСН	A, R5	C8h - CFh	1	12	2	4
ADDC	А, В	35h	2	12	2	4
MOV	R4, A	F8h - FFh	1	12	1	4
MOV	A, R3	E8h - EFh	1	12	1	4
MOV	B, R6	88h - 8Fh	2	24	2	4
MUL	AB	A4h	1	48	2	4
MOV	R6, A	F8h - FFh	1	12	1	4
MOV	R1, B	A8h - AFh	2	24	3	4
MOV	A, R3	E8h - EFh	1	12	1	4
MOV	B, R7	88h - 8Fh	2	24	2	4
MUL	AB	A4h	1	48	2	4

Internet Embedded MCU W7100A Datasheet

© Copyright 2012 WIZnet Co., Inc. All rights reserved.

155

Ver. 1.1.6

WIZ
WIZnet

XCH	A, R7	C8h - CFh	1	12	2	4
XCH	А, В	C5h	2	12	3	4
ADD	A, R6	28h - 2Fh	1	12	1	4
XCH	A, R5	C8h - CFh	1	12	2	4
ADDC	A, R1	38h - 3Fh	1	12	1	4
MOV	R6, A	F8h - FFh	1	12	1	4
CLR	А	E4h	1	12	1	4
ADDC	A, R4	38h - 3Fh	1	12	1	4
MOV	R4, A	F8h - FFH	1	12	1	4
MOV	A, R2	E8h - EFh	1	12	1	4
MUL	AB	A4h	1	48	2	4
ADD	A, R5	28h - 2Fh	1	12	1	4
XCH	A, R6	C8h - CFh	1	12	2	4
ADDC	А, В	38h - 3Fh	2	12	2	4
MOV	R5, A	F8h - FFh	1	12	1	4
CLR	А	E4h	1	12	1	4
ADDC	A, R4	38h - 3Fh	1	12	1	4
MOV	R4, A	F8h - FFh	1	12	1	4
		Sum :		1248	99	252

156



Document History Information

Version	Date	Descriptions
Ver.0.9.1 Beta	Sep. 2009	Release with W7100A launching
Ver.0.9.2	Dec. 2009	Delete about "How to program FLASH memory in W7100" document Section 2.4.7, "APP Entry RD/WR Enable" => "APP Entry(0xFFF7 ~ 0xFFFF) RD/WR Enable" Section 3 I/O Ports, Delete about tri-state signals in I/O pins
Ver.0.9.3	Feb. 2010	Modify the XTLP0 and XTLP1 explaination
Ver.0.9.4	Apr. 2010	Modify the Sn_IMR initial value 0x00 => 0xFF Add the INTLEVEL register to TCPIPCore common register
Ver.0.9.5	May. 2010	Delete about PPPoE protocol cause of errata
Ver.0.9.6	Jan. 2011	Add new SFR definition, modify the GPIO in/out voltage, delete the UIPR and UPORT register for W7100A
Ver.1.0.0	Mar. 2011	Remove information about external memory accessing Added 64pin number information to "Pin Description" section
Ver.1.1.0	May. 2011	Define voltage of OSC (clock source) input, modify the Package description of QFN 64
Ver.1.1.1	May. 2011	Modify the Pin Layout(nWR, nRD) and Add the External Memory Interface to Pin Description Add the Description details of GPIO Pin Description
Ver.1.1.2	May. 2011	Correct the GPIO pull-up, pull-down resistor value
Ver.1.1.3	Nov. 2011	Modify the VCC3V3 power supply descriptions (KR)
Ver.1.1.4	Jan. 2012	Add the product endurance at W7100A Features Add the recommendation note at section 2. Memory Modify the pin number of PLOCK (table 1.4.2.1, add the QFN64 pin number of PLOCK)

6	WIZnet		
	Ver.1.1.5	May. 2012	Modify the Table 2.2 WTST Register Values of 2.5.2 Program Code Wait States Register. The access time of WTST[2:0] values '3' changed to 'Not Used'.
	Ver. 1.1.6	Jun. 2012	Modify the Figure 2.13 description of 2.5.2 Program Code

Wait States Register. WTST value changed to '4'.

Copyright Notice

Copyright 2012 WIZnet, Inc. All Rights Reserved. Technical Support: <u>support@wiznet.co.kr</u> Sales & Distribution: <u>sales@wiznet.co.kr</u> For more information, visit our website at <u>http://www.wiznet.co.kr</u>

© Copyright 2012 WIZnet Co., Inc. All rights reserved.

158