

FLUKE®

365 True-rms AC Clamp Meter

Rugged meters where access is difficult

The Fluke 365 is a new, innovative Fluke clamp meter, offering a thin, small jaw design that makes it easy to get around tightly packed wires. The detachable jaw on a flexible lead makes access to wires and viewing the display easier than ever. The Fluke 365 measures current up to 200 A ac and dc with true-rms measurement.

New



Technical Data

Measurement capability

- 200 A ac and dc current measurement with detachable jaw
- 600 V ac and dc voltage measurement
- True-rms ac voltage and current for accurate measurements on non-linear signals
- 6000 Ω resistance measurement with continuity detection

Features

- Detachable jaw makes accessing wires and viewing the display easier
- Built in flashlight/torch allows for easy illumination and identification of wires
- CAT III 600 V safety rating
- Compact design fits in your hand and can be used while wearing personal protective equipment
- State of the art signal processing allows for use in noisy electrical environments while providing stable readings
- Large, easy to read backlight display automatically sets the correct measurement range so you do not need to change switch positions while taking a measurement
- Three-year warranty
- Soft case

Specifications

| Fluke 365 | Range | Resolution | Accuracy |
|------------------|--------|---------------|----------------|
| AC current | 200 A | 0.1 A | 2 % ± 5 digits |
| DC current | 200 A | 0.1 A | 2 % ± 5 digits |
| AC voltage | 600 V | 0.1 V | 2 % ± 5 digits |
| DC voltage | 600 V | 0.1 V | 2 % ± 5 digits |
| Resistance | 6000 Ω | 0.1 Ω | 1 % ± 5 digits |
| True-rms | | • | |
| Continuity | | • | |
| Hold | | • | |
| Backlight | | • | |
| Flashlight/torch | | • | |
| Wire capacity | | 17 mm | |
| Safety rating | | CAT III 600 V | |

Ordering information

365 True-rms AC/DC
Clamp Meter

Included

Clamp meter, test leads,
soft case, users manual.

Fluke. *Keeping your world
up and running.®*

Fluke Europe B.V.
P.O. Box 1186
5602 BD Eindhoven
The Netherlands
Web: www.fluke.eu

For more information call:
In Europe/M-East/Africa +31 (0)40 2 675 200
or Fax +31 (0)40 2 675 222

Fluke (UK) Ltd.
52 Hurricane Way
Norwich, Norfolk
NR6 6JB
United Kingdom

Tel.: (020) 7942 0700
Fax: (020) 7942 0701
E-mail: industrial@uk.fluke.nl
Web: www.fluke.co.uk/clamps

©2010 Fluke Corporation.
Specifications subject to change without notice.
Pub_ID: 11710-eng

**Modification of this document is not permitted
without written permission from Fluke Corporation.**